


Honeywell

LYNX Touch Series Security Systems

Installation and Setup Guide



RECOMMENDATIONS FOR PROPER PROTECTION

The Following Recommendations for the Location of Fire and Burglary Detection Devices Help Provide Proper Coverage for the Protected Premises.

Recommendations for Smoke and Heat Detectors


With regard to the number and placement of smoke/heat detectors, we subscribe to the recommendations contained in the National Fire Protection Association's (NFPA) Standard #72 noted below.

- Early warning fire detection is best achieved by the installation of fire detection equipment in all rooms and areas of the household as follows: For minimum protection a smoke detector should be installed outside of each separate sleeping area, and on each additional floor of a multi-floor family living unit, including basements. The installation of smoke detectors in kitchens, attics (finished or unfinished), or in garages is not normally recommended.
- For additional protection the NFPA recommends that you install heat or smoke detectors in the living room, dining room, bedroom(s), kitchen, hallway(s), attic, furnace room, utility and storage rooms, basements and attached garages.

In addition, we recommend the following:

- Install a smoke detector inside every bedroom where a smoker sleeps.
- Install a smoke detector inside every bedroom where someone sleeps with the door partly or completely closed. Smoke could be blocked by the closed door. Also, an alarm in the hallway outside may not wake up the sleeper if the door is closed.
- Install a smoke detector inside bedrooms where electrical appliances (such as portable heaters, air conditioners or humidifiers) are used.
- Install a smoke detector at both ends of a hallway if the hallway is more than 40 feet (12 meters) long.
- Install smoke detectors in any room where an alarm control is located, or in any room where alarm control connections to an AC source or phone lines are made. If detectors are not so located, a fire within the room could prevent the control from reporting a fire or an intrusion.

THIS CONTROL COMPLIES WITH NFPA REQUIREMENTS FOR TEMPORAL PULSE SOUNDING OF FIRE NOTIFICATION APPLIANCES.



Recommendations For Proper Intrusion Protection

- For proper intrusion coverage, sensors should be located at every possible point of entry to a home or premises. This would include any skylights that may be present, and the upper windows in a multi-level building.
- In addition, we recommend that radio backup be used in a security system. This will ensure that alarm signals can be sent to the alarm monitoring station in the event that the telephone lines are out of order (alarm signals are normally sent over the phone lines, if connected to an alarm monitoring station).

Table of Contents

System Features 5
 Features 5
Mounting the Control 6
 Wall Mounting 6
 Desktop Mounting 6
 Wiring Overview 6
Wiring Connections 7
 Installing the L5000-RJ-31X in the LYNX Touch Control 8
AC Power and Backup Battery 9
Installing/Configuring Communications & Home Automation Modules 10
 General 10
 Connecting and Configuring Communications Modules 10
 Installing the GSMVLP5-4G/GSMVLP5CN4G 10
 Installing the ILP5 11
 Installing the L5100-WiFi Module 12
 Installing the L5100-ZWAVE Module 12
Installing Wireless Zones 13
 General Information 13
 Zones 13
 Range 13
 Transmitters 13
 House Identification 13
 Transmitter Supervision 13
 Transmitter Input Types 13
 Transmitter Battery Life 13
 RF Sniffer Mode Test 14
 Go/No Go Test 14
 5800 Series Transmitter Loop Numbers 15
Mechanics of Programming 16
 Navigating Menus 16
 Touch-screen Display 16
 Navigation Keys 16
 Dashboard Screen 16
 Security Screen Menus 17
 Installer Tools Menu 17
 User Tools Menu 17
 General Programming Information 18
 Programming 18
 Enter Installer Programming Mode 18
 Loading Factory Defaults 18
 Select a Default Configuration 18
 Exiting programming Mode 19
Zone Response Type Definitions 20
 General Information 20
Programming the Control 22
 Enter Installer Programming Mode without using Installer Code 22
 Change Installer Code 22
 Select a Language 22
 System Type 23
 Program Date and Time 25
 Program the Communications Module 26
 Program the Z-Wave Module 28
 Program Zones 29
 Program Keys 31
 Program Reporter 33
 Sounder 39
 System Settings 40
 Communications Diagnostics 43
 Communications Status 43
 Ethernet Information 43

Table of Contents (Continued)

| | |
|---|------------|
| GSM Information..... | 43 |
| Communications ID Numbers | 44 |
| Test Communications..... | 44 |
| Setup Communications | 44 |
| Registering the LYNX Touch | 44 |
| Register through AlarmNet Direct Website..... | 45 |
| Register by Phone..... | 45 |
| Register through LYNX Touch Diagnostics | 45 |
| Register Device with PIN | 46 |
| Update Server..... | 47 |
| Enroll the L5100-WiFi Module | 48 |
| Enroll Using Scan Access Points | 48 |
| Manually Configure Access Points | 48 |
| WiFi Protected Set-up (WPS)..... | 49 |
| Factory Defaults | 49 |
| Remote Programming/Control (Downloading) | 50 |
| General Information | 50 |
| Remote Programming Information..... | 50 |
| Remote Programming Advisory Notes | 51 |
| System Operation | 52 |
| Key/Touchscreen Operation | 52 |
| Panic Key/Icons..... | 52 |
| Security Codes | 52 |
| Installer Code | 52 |
| Master Code..... | 52 |
| Enter/Change the Master Code by Installer | 52 |
| Secondary User Codes..... | 53 |
| Reset Master User Code..... | 53 |
| Security Code Notes | 53 |
| “Follow Me” System Announcement Feature..... | 54 |
| “Follow Me” Reminder Feature..... | 55 |
| Remote Phone Control Feature..... | 55 |
| System Displays..... | 56 |
| Zone Status Displays | 56 |
| Audio Alarm Verification (Two-Way Voice Feature)..... | 57 |
| Activation..... | 57 |
| Operator Commands | 57 |
| Event Log | 58 |
| Contact ID & SIA Event Log Codes..... | 58 |
| Testing the System | 59 |
| Test Modes | 59 |
| Testing the System | 59 |
| Armed System Test | 59 |
| Dialer Test | 59 |
| Zone Discovery Mode | 60 |
| Rebooting the System | 60 |
| LYNX Touch (L5100CN) Canada Programming Default Values | 61 |
| LYNX Touch Programming Default Values | 64 |
| Zone Programming Default Values | 66 |
| Regulatory Agency Statements | 68 |
| Limitations of this System Statement | 69 |
| UL Notices | 70 |
| SIA Quick Reference Guide | 71 |
| Specifications | 72 |
| Contacting Technical Support | 73 |
| Glossary | 74 |
| Index | 77 |
| Summary of Connections Diagram | 79 |
| Warranty Information | Rear Cover |

System Features

The LYNX Touch control is a self-contained, rechargeable wireless control/communicator that features easy installation and usage. A built-in speaker provides voice annunciation of system status along with voice descriptors of each zone. An internal module (if provided) allows the LYNX Touch to communicate with the Central Station via the Internet or GSM Cellular Wireless.

UL LYNX Touch is not intended for UL985 Household Fire applications unless a 24-hour backup battery (P/N 300-03866/LYNXRCHKIT-SHA) is installed.

Features

System Features

- 4.7-inch color graphic touch screen
- Message center (for user recorded messages)
- Voice announcement of system and zone status
- Voice chime
- Reminders
- Automatic stay arming
- Remote phone control
- Speaker phone operation
- "Follow me" reminder and system announcements
- 16 User Codes (Installer, Master, Babysitter, Duress)
- 3 Panic Functions
- 16 Programmable reminders
- Supports up to four Mobile Internet Devices (MID) (WiFi Tablet) that duplicates functions of the LYNX Touch i.e.; Security, Web Content and Home Automation control)

Home Automation

- Control Z-Wave Home Automation devices (requires installation of a Communications Module). Control up to:
 - 3 thermostats
 - 4 door locks
 - 40 devices (outlets, switches, lamps/appliances)
- Supports Z-Wave Network Wide Inclusion (NWI) Mode
- Supports Garage Door Feature (5877 Relay Receiver)
- Up to 20 Programmable scheduled events, rules and scenes.

Zones and Devices

- 64 total zones including 1 Hardwire (EOLR, N/C, N/O) zone and up to 63 wireless zones (5800 Series transmitters)
- 2 Resident Monitor Zone Types
- Supports wireless keypads
- Built-in Case tamper

Communication

- ADEMCO Contact ID
- SIA (DC-03)
- Internet central station communication
- GSM cellular central station communication
- WiFi Central station communication
- Two-way voice communication
- Supports AlarmNet remote services

System Power

- Primary Power: Plug-in Power Supply, 110VAC to 9VDC, 2.7A output 300-04705 or 300-04065 (300-04063 in Canada)
- Backup battery: Rechargeable nickel-metal hydride battery pack rated at 7.2Vdc. (P/N 300-03864-1/LYNXRCHKIT-SC or 300-03866/LYNXRCHKIT-SHA)

Alarm Output

- Built-in sounder
- Steady output for burglary/panic
- Temporal (3) pulse output for fire alarms
- Temporal (4) pulse output for carbon monoxide alarms
- Long Range Radio (GSM)/Audio Alarm Verification
- Trigger output

Programming

- Options stored in EEROM
- Can be uploaded, downloaded or controlled via IBM-compatible computer using Compass downloader software and specified HAYES or Honeywell CIA modem or via capable GSM, IP or WiFi communications module
- Flash downloading


Other Features

- Exit error feature (detects difference between an actual alarm and exit alarm caused by leaving a door open after the exit delay expires)
- Event log stores up to 128 events
- RF jam detection
- Two installer programmable user (Follow Me) phone numbers
- Advanced Protection Logic™ (APL) (Minimizes the likelihood of the system being disabled before notification can be sent to the Central Station indicating that the premise has been compromised.)
- Displays web content including Local News, Weather and Traffic (requires Total Connect Service)
- Dealer/Central Station messages (requires Total Connect Service)

Mounting the Control

Wall Mounting

1. Release the front case from the back case by depressing the two locking tabs at the top of the unit with the blade of a medium size screwdriver.
2. Separate the front and back case assemblies by rotating the front case so that it is perpendicular to the back case and unsnapping (releasing) the two hooks from the back case.
3. Feed the field wiring through the appropriate openings in the back case. Use tie-wraps to secure the wiring to the built-in wire loops as needed.
4. Mount the back case to a sturdy wall using self tapping screws.
5. If required, install an additional mounting screw in the case tamper (see Detail A).
6. Attach the front and back cases by connecting the hooks on the front case to the attachments on the back case. Once attached, the hooks will support the front case and allow you to make the wiring connections.
7. After all wiring connections have been made, snap the front case and back case closed and ensure that the case is secured by the locking tabs.




5100-100-064-V0

Desktop Mounting

For desktop mounting, the optional mounting base (model L5000DM, purchased separately) must be used.


1. Slide the control panel onto the mounting base locking tabs.
2. Bring all wiring through the bottom of the mounting base, using one of the wire entry locations, before making connections to the control panel.
3. Use tie-wraps to secure the wiring to the built-in wire loops as needed.
4. Use the supplied screws to secure the control panel to the mounting base.



5100-500-004-V0

Wiring Overview

The following summarizes the connections required. Refer to the Wiring Connections paragraph and the Summary of Connections diagram on the inside back cover when making connections.



5100-100-062-V0

Wiring Connections

1. **Make Earth Ground Connection** - The designated earth ground terminal EGND must be terminated in a good earth ground for the lightning transient protective devices in this product to be effective. The following are examples of good earth grounds available at most installations:

Metal Cold Water Pipe - Secure a non-corrosive metal strap (copper is recommended) to the pipe that is electrically connected and secured to which the ground lead is electrically connected and secured.

AC Power Outlet Ground - Available from 3-prong, 120VAC power outlets only. To test the integrity of the ground terminal, use a three-wire circuit tester with neon lamp indicators, such as the UL Listed Ideal Model 61-035, or equivalent, available at most electrical supply stores.

- a. Connect terminal EGND to a good earth ground as shown on the Summary of Connections.

2. **Make Phone Line Connections** - For local or full line seizure follow the appropriate steps below.

Local Seizure

- a. Connect the incoming phone line to either the 8 position jack or terminals TIP and RING on the LYNX Touch as shown on the Summary of Connections.
- b. Connect the handset phone lines to terminals H/S T (TIP) and H/S R (RING) as shown on the Summary of Connections. terminals as shown in the diagram or plug into the 8-position

Full Line Seizure: The control must be placed in series with the incoming phone line. Plugging the Direct Connect Cord directly into the RJ31X jack, allows the control to seize the phone line when an alarm occurs and normal phone line usage by the premises phones if the plug needs to be removed.

- c. Cut the incoming RING and TIP phone lines (typically red and green, respectively) and connect them to RJ31X terminals 4 (red) and 5 (green).
- d. Connect the premises end of the cut RING and TIP wires to RJ31X terminals 1 (grey) and 8 (brown) respectively.
- e. Wire the flying leads of a Direct Connect Cord to the control's phone terminals as shown in the diagram or plug into the 8-position jack.
- f. Plug the Direct Connect Cord into the RJ31X jack.



HARDWIRED ZONE: If the EOLR is not at the end of the loop, the zone will not be properly supervised, and the system may not respond to an open circuit on the zone.


3. **Hardwired Zone Connections** - One EOLR supervised zone supports both open circuit and closed circuit devices and has a response time of 350msec. Maximum zone resistance: 300 ohms, plus EOLR

Note: The hardwire zone cannot be used as a fire zone.

- a. Connect sensors/contacts to the hardwired zone terminals GND (-) and HWZ1 (+). Refer to the Summary of Connections diagram.
- b. Connect closed circuit devices in series in the high (+) side of the loop. The EOL resistor must be connected in series with the devices, following the last device.
- c. Connect open circuit devices in parallel across the loop. The 2000-ohm EOLR must be connected across the loop at the last device.

4. **AC Power Connections** - Connect the Power Supply to the receptacle on the LYNX Touch.

OR
Connect wires from the Power Supply to +9VDC and EGND terminals as shown on the summary of connections diagram.



FULL LINE SEIZURE CONNECTIONS

WIRING TABLE

| MAXIMUM DISTANCE BETWEEN POWER SUPPLY AND CONTROL | WIRE GAUGE |
|---|------------|
| Up to 11 feet | # 22 |
| Up to 20 feet | # 20 |
| Up to 26 feet | # 18 |

Wiring Connections


Installing the L5000-RJ31X in the LYNX Touch Control

An auxiliary L5000-RJ31X receptacle can be installed in the LYNX Touch that will allow the telephone cable to be disconnected without requiring the unit to be opened up.

1. Using a wire cutter or knife cut the plastic tabs that secure the receptacle knockout from the left side of the LYNX Touch back case.
2. Connect four wires between the L5000-RJ31X receptacle terminal strip and the incoming phone line and the premises telephones as shown on the figure below.
3. Install the L5000-RJ31X receptacle into the slot on the back case.
4. Connect one end of the L5000-RJ31X cable to the 8-position jack on the LYNX Touch PC board.
5. Route the cable through the opening in the back case and along the wire channel in the back case.
6. Connect the other end of the cable to the L5000-RJ31X receptacle on the side of the back case as shown below.
7. Secure the wires to the tie wrap points on LYNX Touch front and back case with the provided tie wraps.



To allow flush wall or desk mounting of the control, ensure that L5000-RJ31X cable is routed through the channel in the case back. Ensure enough slack is left in the wires to allow the case to close without pinching the wires.



AC Power and Backup Battery

The system is powered by a 9 Volt DC, 2.7 Amp Plug-in Power Supply, 300-04705 or 300-04065 (300-04063 in Canada). Refer to the wiring table below for wire gauge and length. In the event of an AC power loss, the system is supported by a long life backup battery that is supervised for connection and for low voltage conditions. If the battery is missing, or a low battery condition is detected, a "low battery" message is displayed and a report is sent to the central station. In addition, the system will beep once every 45 seconds to audibly indicate a low battery condition (press any key to stop the beeping).



Use only the provided 300-04705 or 300-04065 (300-04063 Canada) Power Supply. Do not plug the power supply into the AC outlet until after all wiring connections have been made. Ensure the cover is snapped closed prior to applying AC power

The LYNX Touch is equipped with an integral, replaceable, rechargeable battery pack rated at 7.2Vdc. Select the appropriate battery pack, based on the installation's requirement, and install the battery pack.

Installing the Rechargeable Backup Battery


1. Remove battery retainer.
2. Insert battery pack into back case.
3. Route cable through channel (cutout) on left side of compartment.
4. Install battery retainer.
5. Secure battery retainer with the provided screw.
6. Secure battery wiring in the wire routing clips (3).
7. Connect the battery connector to the receptacle on the PC board.
8. After the wiring connection has been made, snap the front and the back case closed.
9. Plug the power supply into a 24-hour, 110VAC unswitched outlet. Upon powerup, the system will display "Please Wait Checking System Integrity".

Replacing the Rechargeable Backup Battery

1. When battery replacement is required, unplug the transformer from the wall outlet, and open the control panel cover.
2. Disconnect the battery pack connector from the receptacle on the PC Board.
3. Remove the screw that secures the battery retainer and remove the battery retainer.
4. Remove the battery pack from the back case.
5. Install a replacement battery pack (P/N 300-03864-1/ LYNXRCHKIT-SC or P/N 300-03866/ LYNXRCHKIT-SHA) into the back case.
6. Route cable through channel (cutout) on left side of compartment.
7. Install the battery retainer.
8. Secure battery retainer with the provided screw. Secure battery wiring in the wire routing clips (3).
9. Connect the battery connector to the receptacle on the PC board.
10. After the wiring connection has been made, snap the front and the back case closed.
11. Plug the power supply into a 24-hour, 110VAC unswitched outlet. Upon powerup, the system will display "Please Wait Checking System Integrity".



Ensure the control panel assembly is snapped closed prior to applying AC power. Rechargeable batteries may take up to 48-hours to fully charge. The "Low Battery" message should clear within four hours or by entering an OFF sequence.



Battery Selection

The LYNX Touch is equipped with an integral, replaceable, rechargeable battery pack rated at 7.2Vdc. Select the appropriate battery pack, based on the installation's requirement, and install the battery pack.

| Battery Part Number | Battery StandbyTime | Low Battery Notification |
|-------------------------------|---------------------|---|
| 300-03864-1/ LYNXRCHKIT-SC | 4-hours (minimum) | Approximately 1-hour before battery depletion |
| 300-03866/ LYNXRCHKIT-SHA | 24-hours (minimum) | At least 1-hour before battery depletion |

Installing/Configuring Communication & Home Automation Modules

General

This LYNX Touch control supports central station reporting using wireless (GSM) and hardwire (IP) communications modules. It also supports upload/download programming capability via the Internet or a Private local area network (Intranet). This allows site maintenance independent of central station monitoring, and modification to sites globally via the Internet or through a private LAN. Refer to the instructions provided with the LRR/IP Communications Module being installed for additional information regarding its installation, programming, and registration. The control is compatible with the following AlarmNet Communications Modules:

- GSMVLP5-4G/GSMVLP5CN4G GSM Communication Module
- ILP5 Ethernet Communications Module

Communications Module 24-Hour Standby Power

If you require 24-hour standby, you must install the Super High Capacity battery P/N LYNX-RCHB-SHA in the control.



RF Exposure

WARNING: The LYNX Touch must be installed to provide a separation distance of at least 7.8 in (20 cm) from all persons and not co-located or operated in conjunction with any other transmitter except in accordance with FCC multi-transmitter product procedures.

Connecting and Configuring Communication Modules

Connect and configure the communications module as follows:

Installing the GSMVLP5-4G/GSMVLP5CN4G




Ensure that **SIM card and the connector board are securely installed in the GSMVLP5-4G/GSMVLP5CN4G before installing the communications module in the LYNX Touch.**

1. Install the GSMVLP5-4G/GSMVLP5CN4G into the LYNX Touch control front case. Ensure that the connector board is properly seated into the receptacle on the control.
2. Secure the GSMVLP5-4G/GSMVLP5CN4G with the three provided screws.
3. Enable the GSMVLP5-4G/GSMVLP5CN4G device, configure alarm reporting and module supervision and register the device. Refer to the "Program the Communications Module" and "Communications Diagnostics" sections.



The communications module must be registered with AlarmNet before downloading or alarm reporting can take place.



5000-100-151-V2

Installing/Configuring Communication & Home Automation Modules

Installing the ILP5 Ethernet Communications Module



Do not install the ILP5 if the L5100-WiFi communications module is being installed.

Ensure that the connector board and cable are securely installed in the ILP5 before installing the communications module in the LYNX Touch.


1. Using a wire cutter or knife cut the plastic tabs that secure the ILP5 spacer to the back case of the LYNX Touch.
2. Remove the ILP5 receptacle knockout from the left side of the LYNX Touch back case.
3. Install the ILP5 into the LYNX Touch control front case. Ensure that the connector board is properly seated into the receptacle on the control.
4. Secure the ILP5 with the three provided screws.
5. Insert the ILP5 receptacle and spacer into the slot on the back case.
6. Secure the communications cable to the tie wrap point on the ILP5 with the provided tie wrap.
7. Connect the Ethernet cable to the RJ45 receptacle.
8. Enable the ILP5 and configure alarm reporting and module supervision and register the device. Refer to the "Program the Communications Module" and "Communications Diagnostics" sections.

Alternate Installation (Refer to the Alternate Installation as shown on the figure below)

1. Install the ILP5 into the LYNX Touch control front case. Ensure that the connector board is properly seated into the receptacle on the control.
2. Secure the ILP5 with the three provided screws.
3. Insert the ILP5 receptacle into the slot on the back case as shown on the figure below.
4. Secure the communications cable to the tie wrap point on the ILP5 with the provided tie wrap.
5. Connect the Ethernet cable to the RJ45 receptacle.
6. Enable the ILP5 and configure alarm reporting and module supervision and register the device. Refer to the "Program the Communications Module" and "Communications "Diagnostics" sections.



The communications module must be registered with AlarmNet before downloading or alarm reporting can take place.



Installing/Configuring Communication & Home Automation Modules



Do not install the L5100-WiFi if the ILP5 Ethernet communications module is being installed.

Installing the L5100-WiFi module


1. Install the L5100-WiFi into the LYNX Touch control front case as shown below. Ensure that the receptacle is properly seated into the edge connector on the right (speaker) side of the control's circuit board.
2. Enable the L5100-WiFi module, configure alarm reporting and module supervision and register the device. Refer to the "Program the Communications Module" and "Communications Diagnostics" sections.



The communications module must be registered with AlarmNet before downloading or alarm reporting can take place.

Installing the L5100-ZWAVE Home Automation module

1. Enable the L5100-ZWAVE module. Refer to the "Program the Z-Wave Module".
2. Install the L5100-ZWAVE into the LYNX Touch control front case as shown below. Ensure that the receptacle is properly seated into the edge connector on the left (TELCO terminal) side of the control's circuit board.



Installing Wireless Zones

General Information

Zones

The control supports up to 63 total wireless zones using 5800 Series transmitters, and wireless buttons.

Range

The built-in RF receiver can detect signals from wireless transmitters within a nominal range of 200 feet.

Transmitters

5800 Series transmitters have built-in serial numbers that must be entered into the system using the “Zones” programming section, or input to the control via the downloader. 5800 Series transmitters (except the 5800RL) do not have DIP switches. Each transmitter's zone number is also programmed into the system in the “Zones” programming section. Some transmitters, such as the 5816 and 5817, can support more than one "zone" (referred to as loops or inputs). On the 5816, for example, the wire connection terminal block is loop 1; the reed contact is loop 2. Each loop must be assigned a different zone number.

For button transmitters (RF "keys") such as the 5804, you must assign a unique zone number to each individual button used on the transmitter. Each button on the transmitter also has a pre-designated loop or input number, which is automatically displayed.

UL The 5816 and 5817 Transmitters do not have EOL supervision of their loop wiring, which must not exceed 3 feet. The 5800RL, 5802MN, 5802MN2, 5804, 5804BD, 5804BDV, 5804E, 5814, 5816TEMP, 5819, 5819S(WHS & BRS), 5828/5828V and 5850(GBD) transmitters have not been evaluated by UL.

House Identification

If you are using a 5804BD/5804BDV Wireless Keypad with the system, you must program a House ID Code (01–31) as described in the “SYSTEM TYPE” programming section to establish proper communication, and the keypad must be set to the same ID. House ID 00 disables all wireless keypads. An RF House ID is not necessary for other 5800 Series transmitters; the entry should be left at “00” (default) in those cases.

Transmitter Supervision

With the exception of some transmitters/keypads that may be carried off-premises (5804, 5804BD, 5804BDV, 5804E and 5805-6), each transmitter is supervised by a check-in signal that is sent to the receiver at 70–90 minute intervals. If at least one check-in is not received from each supervised transmitter within a 12-hour period, the "missing" transmitter zone number(s) and "Supervision" will be displayed. The supervision for a particular transmitter in the system that may also be carried off the premises (5802/5802MN2, 5802MN) may be turned off by entering it as a Unsupervised RF (UR) type, as described in the “ZONES” programming section. 5800 Series transmitters have built-in tamper protection and will announce as a fault condition if covers are removed. In Canada the RF supervision period is 3-hours for Fire zones and 12 hours for all other zone types.

Transmitter Input Types

Each of the transmitters has one or more unique factory-assigned input (loop) ID codes. Each of the inputs requires a programming zone (e.g., a 5804's four inputs require four button zones). Transmitters can be entered as one of the following types (see transmitter's instructions for appropriate input type):

| Type | Description |
|-------------------------------|--|
| Supervised RF ("RF") | Sends periodic check-in signals, as well as fault, restore, and low battery signals. The transmitter must remain within the receiver's range. |
| Unsupervised RF ("UR") | Sends all the signals that the "RF" type does, but the control does not supervise the check-in signals. The transmitter may therefore be carried off-premises. |
| Unsupervised Button RF ("BR") | Sends only fault signals. They do not send low battery signals until they are activated. The transmitter may be carried off-premises. |



Transmitter Battery Life

- Batteries in the wireless transmitters may last from 4–7 years, depending on the environment, usage, and the specific wireless device being used. Factors such as humidity, high or low temperatures, as well as large swings in temperature may all reduce the actual battery life in a given installation. The wireless system can identify a true low battery situation, thus allowing the dealer or user of the system time to arrange a change of battery and maintain protection for that point within the system.
- Button-type transmitters should be periodically tested for battery life. The 5802MN, 5802MN2, 5804, 5804BD, 5804BDV, and 5804E button transmitters have replaceable batteries.

Installing Wireless Zones

RF Sniffer Test Mode

This mode is used after all transmitters have been entered to check that all transmitters have been properly programmed. Sniffer mode does not automatically expire. You must manually exit Sniffer mode by selecting Off and entering the Installer Code to return to normal operation.

| SCREEN | ACTION | | | | |
|---|--|-----------|-----------------|---------------|-------------|
|  | 1. At the Tools Screen, select "Test". The following options are displayed. <table style="width: 100%; border: none;"> <tr> <td style="width: 50%; border: none;">Walk Test</td> <td style="width: 50%; border: none;">RF Sniffer Test</td> </tr> <tr> <td style="border: none;">Go-No-Go Test</td> <td style="border: none;">Dialer Test</td> </tr> </table> | Walk Test | RF Sniffer Test | Go-No-Go Test | Dialer Test |
| Walk Test | RF Sniffer Test | | | | |
| Go-No-Go Test | Dialer Test | | | | |
|  | 2. Select "RF Sniffer Test" from the options. Note: If the communicator is in the process of sending a report to the central station, the system will not go into the Sniffer mode. If so, wait a few minutes and try again. 3. The system displays all programmed zone numbers and zone descriptors, which have a non-zero Zone Type. Fault each transmitter in turn, causing each one to send a signal. As the system receives a signal from each of the transmitters, the zone number of that transmitter disappears from the display. The transmitters may be checked upon installation, or in an installed system. The system will beep once every 30-40 seconds while the RF Sniffer Test mode is active. 4. When all transmitters have been checked, Exit RF Sniffer Test mode by depressing the Off key and entering the Installer or a User Code. | | | | |



- Notes:**
- (1) All button-type (BR) units must physically be activated to clear the display, since they do not automatically send check-in signals.
 - (2) When one button of a button type, supervised or unsupervised RF transmitter (RF, UR, or BR) is activated, all zones assigned to other buttons on that transmitter are cleared. This also applies to 5816 and 5817 transmitters that have multiple loops (zones).
 - (3) Any transmitter that is not "entered" will not turn off its zone number.
 - (4) For SIA installations, the following devices may be used as specified for panic (24-hour) alarm response:
 - wireless keys which have two-button panic pairs available (e.g., 5804BDV), on which only the two-button panic pairs may be programmed for any 24-hour alarm response
 - wireless keypads (e.g., 5828/5828V) keypads that have a two-second delay on the special function keys, or two-button panic pairs
 - built-in keypad panic key

Go/No Go Test Mode



Conducting this test with your hand wrapped around the transmitter will cause inaccurate results. On button type transmitters that have been programmed to set ARM AWAY, ARM STAY, or DISARM, pressing a button will take the system out of the Go/No Go Test mode causing the programmed action to occur.

The Go/No Go tests will verify adequate RF signal strength from the proposed transmitter location, and allow you to reorient or relocate transmitters if necessary, before mounting the transmitters permanently. This mode is similar to the transmitter Test mode, except that the wireless receiver gain is reduced. This will enable you to make sure that the RF signal from each transmitter is received with sufficient signal amplitude when the system is in the normal operating mode.


| SCREEN | ACTION | | | | |
|---|--|-----------|-----------------|---------------|-------------|
|  | 1. At the Tools Screen, select "Test". The following options are displayed. <table style="width: 100%; border: none;"> <tr> <td style="width: 50%; border: none;">Walk Test</td> <td style="width: 50%; border: none;">RF Sniffer Test</td> </tr> <tr> <td style="border: none;">Go-No-Go Test</td> <td style="border: none;">Dialer Test</td> </tr> </table> | Walk Test | RF Sniffer Test | Go-No-Go Test | Dialer Test |
| Walk Test | RF Sniffer Test | | | | |
| Go-No-Go Test | Dialer Test | | | | |
|  | 2. Select "Go-No-Go Test". 3. Once you have placed transmitters in their desired locations, and the approximate length of wire to be run to sensors is connected to the transmitter's screw terminals (if used), fault each transmitter. <ol style="list-style-type: none"> a. The keypad beeps three times indicating signal reception, displays the appropriate zone number and announced the zone description. b. If the keypad does not beep, reorient or move the transmitter to another location. Usually a few inches in either direction is all that is required. 4. If each transmitter produces the proper keypad response when faulted, they can be permanently mounted according to their respective instructions. 5. The system will beep once every 30-40 seconds while the Go-No-Go Test mode is active. 6. Exit Go-No-Go Test mode by depressing the Off key and entering the Installer or a User Code. | | | | |

Installing Wireless Zones

5800 Series Transmitter Loop Numbers

(Refer to this information when programming transmitters)

The following illustration shows the compatible transmitters, their associated input types and loop designations.



- Notes:**
- (1) The 5806W3 smoke detector must be used in SIA applications.
 - (2) Button type (BR) devices send only fault and low battery signals; no restore or check-in signals. Supervised RF (RF) devices send periodic check-in signals, faults, restore and low battery signals. Unsupervised RF (UR) devices send periodic check-in signals, faults, restore and low battery signals but the control does not supervise the check-in signals.
 - (3) If an external sounder is required, the 5800WAVE should be used.
 - (4) The 5804E and 5834-4 encrypted (High-Security) devices must be activated while the system is in Go/No-Go Test Mode. Refer to the transmitter's Installation Instruction for complete details. The system will confirm the enrollment of the encrypted device by beeping two times




The 5800RL, 5802MN, 5802MN2, 5804, 5804BD, 5804BDV, 5814, 5816TEMP, 5819, 5819S(WHS & BRS), and 5828/5828V wireless transmitters have not been evaluated by UL.

Mechanics of Programming

Navigating Menus

Touch-screen Display

LYNX Touch’s Liquid Crystal Display (LCD) touch-screen displays variable icons and text on “screens”. The screen displays status icons and associated text, the current time and date, system status information and menu choices. The Menu area includes a list of commands, or choices that apply to the current selection. The status area provides information about various system events and a colored bar also provides an indication of system status. A “Home Screen” is displayed whenever power is applied to the system. In addition the Green (Ready) LED is lit when the system is ready or flashes when it is not. The Red (Armed) LED is lit when the system is Armed.



Home Screen (page 1)

Function Keys

| | |
|--|---|
| | Panic key Initiates panic alarm options when depressed for 4 seconds. |
| | Away key Initiates Arm Away option. |
| | Off (Disarm) key Initiates disarm process. |
| | Home key Used to exit from a screen or return to the home screen. |


Navigation Keys

Navigating through the screens is accomplished by lightly touching the menu item on the touch-screen. Once activated, the control will take you to the next screen. Selecting the “Home” (cancel) key or the “↶” Key will return you to the previous screen at any time unless System Programming mode is active. By Touching (selecting) an icon or key the system, depending on the function, advances to another screen, toggles between options or scrolls through multiple options that can be selected. The system provides a prompt when a specific input is required.

Note: You may find it convenient to adjust the volume setting before entering the Program Mode. This will allow you to clearly hear the feedback announcements or system beeps from the system’s built-in speaker. To adjust the volume, select “More” on the “Home Screen” and then select “Settings”. Adjust the volume using the slide displayed on the Settings screen and then select “Save” to accept. Upon exiting the Program Mode, the system resets the volume to the default value (mid level).

Dashboard Screen

When Total Connect Services are connected and web content is enabled, the Home Screen is replaced by the Dashboard Screen. System Status is displayed at the top of each screen. In addition to the system status, the Dashboard Screen displays time and date, weather and five selection “icons”.



| Selection | Function |
|------------------|--|
| Security | Provides access to Security Menu. |
| Notices * | Provides access to Notices page. |
| Automation * | Provides access to Automation page. |
| News * | Provides access to News page. |
| Traffic * | Provides access to Traffic page. |
| 5-Day Forecast * | Provides access to local 5-Day weather forecast page. |
| Weather * | Provides local forecast and severe weather alerts (if enabled) |

* Requires Total Connect Services

Mechanics of Programming

Security Menu Screens

System Status is displayed at the top of each screen. The time and date are displayed at the bottom of the Home Screen. The Security Home Screen consists of two pages. The first page displays the system status and eight selection “buttons” and “tabs”. The displayed pages and options may vary slightly depending upon the devices and services that are installed in or connected to the system.

| Selection | Function |
|---------------|--|
| Zones | Provides access to Zone information and options. |
| Automation | Provides access to the Z-Wave Device and Home Automation Screen. |
| Arm Away | Used to Arm the system in Away mode (displayed on both Home Screen pages). |
| Arm Stay | Used to Arm the system in Stay mode (displayed on both Home Screen pages). |
| Message | Provides access to Message Center. |
| Phone | Provides access to Speaker Phone mode. (if programmed) |
| Delay/Instant | Used to toggle between exit delay and instant arming options (displayed on Home Screen pages). |
| More | Advances system to second page of the Home Screen. |


The second page also displays the system status and seven selection “buttons” and “tabs”.

| Selection | Function |
|---------------|--|
| System | Provides information about system status |
| Tools | Provides access to Installer and User Programming Menus (Master User Code required for access). |
| Arm Away | Used to Arm the system in Away mode (displayed on both Home Screen pages). |
| Arm Stay | Used to Arm the system in Stay mode (displayed on both Home Screen pages). |
| Dashboard | Used to return to the Dashboard Screen (displayed if connected to Total Connect Services) |
| Settings | Provides access to various keypad functions (i.e.; Brightness, Contrast, Volume, Voice, Chime & Ringer). |
| Delay/Instant | Used to toggle between exit delay and instant arming options (displayed on both Home Screen pages). |
| Back | Returns system to first page of the Home Screen. |

Installer Tools Menu

The Tools/Installer Menu provides access to the Installer configurable features and displays six options. Entering the Installer Code is required to access the Installer Menu.

Note: For information regarding the Rules, Events and Schedules programming screens, refer to the User Manual.




5100-100-066-V0

Installer Menu Page

User Tools Menu

The User Menu provides access to the User configurable features and displays eight options. Entering the Master User Code is required to access the User Menu.



5100-100-066-V0

User Menu Page

Mechanics of Programming

General Programming Information



When power cycling the control, remove AC power first and wait approximately 1 minute before disconnecting battery.

Programming options are stored in non-removable, electrically erasable, nonvolatile EEROM memory. The system can be programmed at any time, even at the installer's premises prior to the actual installation. Simply apply power temporarily to the Control and then program the unit as desired.

The "Initiate Download" button is used to initiate remote programming using an IBM PC compatible Personal Computer, and Compass Downloader and modem or via capable GSM or IP communications modules. See the *Remote Programming/Control (Downloading)* section for additional information.

Programming



If the system is Armed or in Alarm, the Tools icon will not be functional. The system must first be disarmed.

Enter Installer Programming Mode

| SCREEN | ACTION | | | | | | | | | | | | | | |
|-------------------|---|----------------|-------------|-----------|--------------|-------|-------------------|------|----------|---------|-----------------|-----------------|-----------|-------------------|--------|
| | <ol style="list-style-type: none"> At the Home Screen select "More". Select "Tools". The touchscreen displays a keypad. Enter the Installer Code 4112. The System Programming Screen is displayed. Select "Program" to display the following options: <table border="0" style="width: 100%;"> <tr> <td style="width: 50%;">Installer Code</td> <td style="width: 50%;">System Type</td> </tr> <tr> <td>Date Time</td> <td>Communicator</td> </tr> <tr> <td>Zones</td> <td>Comm. Diagnostics</td> </tr> <tr> <td>Keys</td> <td>Reporter</td> </tr> </table> Use the down ▼ arrow to scroll to the next page of options. <table border="0" style="width: 100%;"> <tr> <td style="width: 50%;">Sounder</td> <td style="width: 50%;">System Settings</td> </tr> <tr> <td>Default Config.</td> <td>Language*</td> </tr> <tr> <td>Reset Master Code</td> <td>Z-Wave</td> </tr> </table> The system advances to the Programming screen of the selected option. <p>* This programming field may not be available with the system being installed.</p> | Installer Code | System Type | Date Time | Communicator | Zones | Comm. Diagnostics | Keys | Reporter | Sounder | System Settings | Default Config. | Language* | Reset Master Code | Z-Wave |
| Installer Code | System Type | | | | | | | | | | | | | | |
| Date Time | Communicator | | | | | | | | | | | | | | |
| Zones | Comm. Diagnostics | | | | | | | | | | | | | | |
| Keys | Reporter | | | | | | | | | | | | | | |
| Sounder | System Settings | | | | | | | | | | | | | | |
| Default Config. | Language* | | | | | | | | | | | | | | |
| Reset Master Code | Z-Wave | | | | | | | | | | | | | | |

Mechanics of Programming

Loading Factory Defaults

To load the factory defaults, enter the Installer Programming Mode and advance to second page of the System Programming and refer to following procedure. Refer to the Programming Default Values section of this manual to view the Default Values.



If a default configuration is loaded, any data that has already been programmed into the system will be changed according to the default configuration selected!

Select a Default Configuration

| SCREEN | | | ACTION | | | | | | |
|-----------------------|------------------|---|---|------------------|------------------|------------------|------------------|--------------------|--|
| System Programming... | | | <ol style="list-style-type: none"> Select "Default Configuration" to display the following options: <table style="width: 100%; border: none;"> <tr> <td style="width: 50%;">Default Config 1</td> <td style="width: 50%;">Default Config 2</td> </tr> <tr> <td>Default Config 3</td> <td>Default Config 4</td> </tr> <tr> <td>Default Downloader</td> <td></td> </tr> </table> Note: For a list of the pre-programmed defaults refer to the Default Values section. Select the desired Default Configuration. A Confirmation screen is displayed. If "Yes" is selected, the System beeps three times and returns to the Default option screen. If "No" is selected, the System returns to the Default option screen. | Default Config 1 | Default Config 2 | Default Config 3 | Default Config 4 | Default Downloader | |
| Default Config 1 | Default Config 2 | | | | | | | | |
| Default Config 3 | Default Config 4 | | | | | | | | |
| Default Downloader | | | | | | | | | |
| Sounder | System Settings | ↩ | | | | | | | |
| Default Config. | Language | △ | | | | | | | |
| Reset Master Code | Z-Wave | □ | | | | | | | |
| □ | | | | | | | | | |

Exiting Program Mode

- Select the "↩" key to exit the current screen. The system returns to the previous screen.
- Select the "↩" key as required until system displays a Confirmation screen.
- Select "Yes" to allow the installer to re-enter Programming mode or "No" to prevent re-entry.
- Select the "↩" key again to return to the Home Screen.

Zone Response Type Definitions

General Information

During programming, you must assign a zone type to each zone, which defines the way in which the system responds to faults in that zone. Zone types are defined below.


| Type | Function | Characteristics |
|---------------------------------|---|--|
| Not Used | Used to program a zone that is not used. | <ul style="list-style-type: none"> • None |
| Entry/Exit 1 (Burglary) | Usually assigned to sensors or contacts on primary entry and exit doors. | <ul style="list-style-type: none"> • Entry delay #1 is programmable. • Exit delay is independently programmable. • Exit and entry delays when armed in AWAY or STAY mode. • No entry delay when armed in STAY INSTANT or AWAY INSTANT mode. • Exit delay regardless of the arming mode selected. |
| Entry/Exit 2 (Burglary) | Usually assigned to sensors or contacts on secondary entry and exit doors that might be further from the keypad (typically used for a garage, loading dock, or basement door). | <ul style="list-style-type: none"> • Entry delay #2 is programmable. • Exit delay is independently programmable. • Secondary entry delay, if armed in the AWAY or STAY mode. • No entry delay when armed in the STAY INSTANT or AWAY INSTANT mode. • Exit delay begins regardless of the arming mode selected. |
| Perimeter (Burglary) | Usually assigned to all sensors or contacts on exterior doors and windows | <ul style="list-style-type: none"> • Instant alarm, when armed in AWAY, STAY, STAY NO DELAY, or AWAY INSTANT mode. |
| Interior, Follower | Usually assigned to a zone covering an entry area (i.e.: foyer, lobby, or hallway) that one must pass upon entry (after faulting the entry/exit zone) to reach the keypad. It provides an instant alarm if the entry/exit zone is not violated first, and protects an area in the event an intruder has hidden on the premises before the system is armed, or gains access to the premises through an unprotected area. | <ul style="list-style-type: none"> • Delayed alarm (using the programmed entry/exit time) if entry/exit (types 01 or 02) or interior-with-delay (type 10) zone is faulted first. • Instant alarm in all other situations. • Active when armed in AWAY or AWAY INSTANT mode. • Bypassed automatically when armed in STAY or STAY INSTANT mode. |
| Trouble by Day/ Alarm by Night | Usually assigned to a zone that covers a sensitive area (i.e.: stock room, drug supply room, etc.) It can also be used on a sensor or contact in an area where immediate notification of an entry is desired. | <ul style="list-style-type: none"> • Instant alarm, when armed in AWAY, STAY, STAY INSTANT, or AWAY INSTANT (night) mode. • Provides a latched trouble sounding from the keypad and, if desired, a central station report when disarmed (day). |
| 24-hour Silent Alarm | Usually assigned to a zone containing an Emergency button (silent emergency). | <ul style="list-style-type: none"> • Sends a report to the central station but provides no keypad display or sounding. • In disarmed state sends a report to the central station displays "Not Ready to Arm" on the keypad and "AWAY", "STAY" and "TOOLS" buttons are disabled. |
| 24-hour Audible Alarm | Usually assigned to a zone containing an Emergency button (audible emergency). | <ul style="list-style-type: none"> • Follows sounder timeout • Sends a report to the central station, and provides alarm sounds at the keypad. |
| 24-hour Auxiliary Alarm | Usually assigned to a zone containing a button for use in personal emergencies or to a zone containing monitoring devices (i.e.: water or temperature sensors, etc.). | <ul style="list-style-type: none"> • Sends a report to the central station and provides an alarm sound at the keypad. (There is no keypad timeout.) |
| Interior with Delay | Provides entry delay (using the programmed entry time), if tripped when the panel is armed in the Away mode. Bypassed when the panel is armed in the STAY or STAY INSTANT mode. | <ul style="list-style-type: none"> • Entry delay #1 (with programmed entry time) when armed in the AWAY mode. • Entry delay begins whenever sensors in this zone are violated, regardless of whether an entry/exit delay zone was tripped first. • No entry delay when armed in the AWAY INSTANT mode. • Exit delay regardless of the arming mode selected. |
| Fire No Verification | Can be assigned to any wireless zone used as a fire zone. This zone type is always active and cannot be bypassed. | <ul style="list-style-type: none"> • Alarm sound will pulse when this zone type is alarmed. |
| Fire with Verification | Can be assigned to any wireless zone used as a fire zone. Fire with verification is available with smoke detector device type. It can not be used with heat detectors, combination heat/smoke detectors, wireless sensors or fire pull stations. This zone type is always active and cannot be bypassed. | <ul style="list-style-type: none"> • Alarm sound will pulse when this zone type is alarmed. Only after the alarm has been verified. • System verifies alarm by delaying reporting and control panel alarm sounding for 30 seconds after alarm is detected. If the zone remains faulted after 30 seconds a fire alarm is provided. If any other fire zone is faulted during the 30 second delay window a fire alarm is immediately provided for that zone. An alarm for original fire zone will also be provided if that zone is still faulted afterward. If there are no fire alarms after the 30 second delay expires, the system will open a 60 second window. If any fire zone is faulted during that window a fire alarm will immediately be provided for that zone. |
| 24-hour Carbon Monoxide Monitor | Can be assigned to any wireless zone with a carbon monoxide detector. This zone type is always active and cannot be bypassed. | <ul style="list-style-type: none"> • Local keypad and detector will sound when this zone type is alarmed. (Pulse Temporal 4) |

Zone Response Type Definitions


| Type | Function | Characteristics |
|-------------------|---|--|
| Arm–Stay | Special-purpose zone type used with 5800 Series wireless pushbutton units. | <ul style="list-style-type: none"> Exit delay regardless of the arming mode selected. System is armed in the STAY mode when the zone is activated. |
| Arm–Away | Special-purpose zone type used with 5800 Series wireless pushbutton units. | <ul style="list-style-type: none"> System is armed in the AWAY mode when the zone is activated. |
| Disarm | Special-purpose zone type used with 5800 Series wireless pushbutton units. | <ul style="list-style-type: none"> Disarms the system when the zone is activated. |
| No Alarm Response | Assigned when no-alarm response is required | <ul style="list-style-type: none"> No reports to the central station. No keypad sounding or chime System can still be armed No display on the screen |
| Silent Burglary | Usually assigned to sensors or contacts on exterior doors and windows where sirens are NOT desired. | <ul style="list-style-type: none"> Instant alarm, with NO audible indication when is armed in the AWAY, STAY, STAY NO DELAY, or AWAY INSTANT mode. Report sent to the central station. |
| Monitor | Can be assigned to any wireless zone used for asset protection. Works as a dynamic monitor of a zone fault/trouble (not alarm). | <ul style="list-style-type: none"> Reports to the central station, if enabled. Fault/restore events are logged by the system. Activity Zone No. and Zone Descriptor displayed on LCD. Restore will be stored in event log. No keypad sounding or chime System can still be armed |
| General Monitor | Assigned sensors or contacts on doors and windows or asset protection within the premises. Used to track activity of the occupant and alert occupant of the activity of others. | <ul style="list-style-type: none"> No reports to the central station. Fault/restore events are logged by the system. Monitors entry into a monitored area. Activates a one-time unique chime sound and announcement when faulted. Activity Zone No. and Zone Descriptor displayed on LCD. |
| General Response | Assigned sensors or contacts on doors and windows or asset protection within the premises. Used to track activity of the occupant and alert occupant of the activity of others. | <ul style="list-style-type: none"> No reports to the central station. Fault/restore events are logged by the system. Monitors entry into a monitored area. Activates a unique chime sound and zone announcement when faulted. Activity Zone No. and Zone Descriptor displayed on LCD. System re-triggers audible sounding every ten seconds until acknowledged (Off sequence or wireless key button). |
| Resident Monitor | Used to monitor a resident in an area deemed to be dangerous by a caregiver. | <ul style="list-style-type: none"> No reports to the central station. Monitors entry into a monitored area. Activates a unique chime sound and zone announcement when faulted. Activity Zone No. and Zone Descriptor displayed on LCD. If programmed, triggers a voice message (follow me) report. Fault/Restore events are not logged by the system. |
| Resident Response | Used to monitor a resident in an area deemed to be dangerous by a caregiver. Requires acknowledgement by caregiver. | <ul style="list-style-type: none"> No reports to the central station. Monitors entry into a monitored area. Activates a unique chime sound and zone announcement when faulted. Activity Zone No. and Zone Descriptor displayed on LCD. If programmed, triggers a voice message (follow me) report. System re-triggers audible sounding every ten seconds until acknowledged (Off sequence or wireless key button). Fault/Restore events are not logged by the system |
| Trouble | Used with Other response type | <ul style="list-style-type: none"> The system will provide a trouble sounding from the keypad (and a central station report, if desired). |
| Garage (Burglary) | Assigned to Automatic Garage Door applications. Provides a status of the garage door close/open real time state | <ul style="list-style-type: none"> Associated With Entry Delay #2 Programmed Time. Exit delays when armed in AWAY or STAY mode. No Entry Delay when armed in Away or Stay Instant modes System can be armed with zone in the faulted state. When the zone is closed it will automatically be inclusive within protection points. If the point is subsequently violated, it will initiate an alarm. Zone type can be bypassed by any User Code except Babysitter. |
| Garage Monitor | Assigned to Automatic Garage Door applications. Provides a status of the garage door close/open real time state | <ul style="list-style-type: none"> Can be assigned to any wireless zone used for automatic "Garage Door" Open/Close status. Will not initiate an alarm condition on the control. When zone is in the open state will display "FAULT." Does not report alarms to central station. Zone will chime if enabled to do so System can be armed if this zone type is in fault Zone can be Bypassed by a valid code except babysitter |

Programming the Control

After entering the System Programming mode select from the options provided on the First and Second Installer Programming tools screens as shown in the accompanying figure.



Page 1



Page 2

Enter Installer Programming Mode without using Installer Code

| SCREEN | ACTION |
|--------|--|
| | <ol style="list-style-type: none"> 1. During the initial system power-up initialization delay (while "SYSTEM STANDBY!" is displayed), depress the OFF key. Wait for system to terminate the system initialization delay. 2. Depress the OFF key again. The touchscreen displays a keypad. 3. Press the "Clear" key. A blue vertical bar is displayed below the "Enter Code". 4. Enter "00" on the keypad. The system will enter Installer Programming mode and the Installer Tools Menu will be displayed. |

Change Installer Code

The factory default Installer Code for the LYNX Touch Control is set to 4-1-1-2.

| SCREEN | ACTION |
|--------|--|
| | <ol style="list-style-type: none"> 1. Select "Installer Code". The current four-digit Installer Code is displayed on the left side of the screen. 2. Select the "Clear" button, then enter a new four-digit Installer Code on the displayed keypad. The system will display the new code on the left side of the screen. 3. Select "Done" when you are finished. 4. The system returns to the "System Programming" Screen. |

Select a Language

Note: This programming field may not be available with the system being installed.

| SCREEN | ACTION |
|--------|---|
| | <ol style="list-style-type: none"> 1. If applicable, select "Language" to display the following options: Installer Language User Language 2. Select "Installer Language. The system toggles between "English" and "French". 3. Select the desired language. 4. Select "User Language. The system toggles between "English" and "French". 5. Select the desired language. 6. Select "Save" when you are finished. 7. A confirmation screen appears. If "Yes" is selected, the System returns to the second page of the Programming screen, which will be displayed in the selected language. |

Programming the Control

System Type

The following system options are programmed in this section:

| Option | Function |
|----------------------|--|
| RF Jam | Enable or disable RF Jam Log and Reporting |
| Speaker Phone | Enable or disable Speaker Phone mode. (End User feature) |
| Two Way Voice | Enable or disable Two Way Voice communication with the Central Station. |
| RF House Code | Set RF House Code. (Bi-directional RF Devices) |
| Phone Notification | Enable or disable Phone Notification mode. (Phone Line-cut) |
| Phone Detect Time | Select a delay period between phone line-cut & system response (allows phone to restore) Note: This field is displayed if Phone Notification is enabled. |
| Remote Phone | Enable or disable Remote Phone Control mode. (End User feature) |
| Events | Enable or disable multiple options for event logging (i.e.; alarms, troubles, open/close, bypass, all) |
| Non-Security | Enable or disable non-security event logging |
| Remote Access Serial | Enable or disable end user to access their system via a website |
| Multi Mode Serial | Enable or disable transmission of panel status events via email (Active only when Remote Access Serial is enabled) |

Note: If applicable, preprogrammed defaults for the LYNX Touch Control are shown on the screen unless otherwise noted.

| Screen | ACTION | | | | | | | | | | | | | | | | |
|---|--|--------|---------------|---------------|---------------|--------------------|--------------|-------------------|--|------------------|--------------------|---------------------|-------------------------|----------------------|--------------|----------------------|-------------------|
| <div style="border: 1px solid black; padding: 5px; width: fit-content;"> System Type <small>5000-100-130-V0</small> </div> | <p>System Type Note: If applicable, the pre-programmed default will be displayed beneath the option.</p> <p>1. Select "System Type" from the following options:</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; text-align: center;">RF Jam</td> <td style="width: 50%; text-align: center;">Speaker Phone</td> </tr> <tr> <td style="text-align: center;">Two Way Voice</td> <td style="text-align: center;">RF House Code</td> </tr> <tr> <td style="text-align: center;">Phone Notification</td> <td style="text-align: center;">Remote Phone</td> </tr> <tr> <td style="text-align: center;">Phone Detect Time</td> <td></td> </tr> </table> <p>Use the down ▼ arrow to scroll to the next page of options.</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; text-align: center;">Events – Log All</td> <td style="width: 50%; text-align: center;">Events – Log Alarm</td> </tr> <tr> <td style="text-align: center;">Events – Log Bypass</td> <td style="text-align: center;">Events – Log Open/Close</td> </tr> <tr> <td style="text-align: center;">Events – Log Trouble</td> <td style="text-align: center;">Non Security</td> </tr> <tr> <td style="text-align: center;">Remote Access Serial</td> <td style="text-align: center;">Multi Mode Serial</td> </tr> </table> | RF Jam | Speaker Phone | Two Way Voice | RF House Code | Phone Notification | Remote Phone | Phone Detect Time | | Events – Log All | Events – Log Alarm | Events – Log Bypass | Events – Log Open/Close | Events – Log Trouble | Non Security | Remote Access Serial | Multi Mode Serial |
| RF Jam | Speaker Phone | | | | | | | | | | | | | | | | |
| Two Way Voice | RF House Code | | | | | | | | | | | | | | | | |
| Phone Notification | Remote Phone | | | | | | | | | | | | | | | | |
| Phone Detect Time | | | | | | | | | | | | | | | | | |
| Events – Log All | Events – Log Alarm | | | | | | | | | | | | | | | | |
| Events – Log Bypass | Events – Log Open/Close | | | | | | | | | | | | | | | | |
| Events – Log Trouble | Non Security | | | | | | | | | | | | | | | | |
| Remote Access Serial | Multi Mode Serial | | | | | | | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;"> RF Jam Disabled </div> | <p>2. Select "RF Jam". The System scrolls between the following: Disabled RF Jam Log RF Jam Log & Report</p> | | | | | | | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;"> Speaker Phone Enabled </div> | <p>3. Select "Speaker Phone". The System toggles between the following: Disabled Enabled</p> | | | | | | | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;"> Two Way Voice Disabled </div> | <p>4. Select "Two-Way Voice". The System toggles between the following: Disabled Enabled</p> | | | | | | | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;"> RF House Code 0 </div> | <p>5. Select "RF House Code". 6. After entering a code (00-31) on the displayed keypad, select "Done".</p> | | | | | | | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;"> Phone Notification Disabled </div> | <p>7. Select "Phone Notification" (phone line cut). The System scrolls between the following options: Disabled Keypad Trouble If "Keypad" or "Trouble" is selected proceed to Step 8.</p> | | | | | | | | | | | | | | | | |










Programming the Control

| Screen | ACTION |
|---|--|
| <p>Phone Detect Time 2 Minutes</p> | <p>8. If Keypad or Trouble was selected in Step 7, the "Phone Detect Time" option is displayed. Select "Phone Detect Time". The system scrolls between the following options: 1 Minute 2 Minutes 3 Minutes 4 Minutes</p> |
| <p>Remote Phone Enabled</p> | <p>9. Select "Remote Phone". The System toggles between the following options: Disabled Enabled</p> |
| <p>Events - Log All Press To Log All</p> | <p>Use the down ▼ arrow to scroll to the next page of options. 10. Select "Events - Log All". The system displays "Press To Log All". Selecting this option programs the system to log all events and "Log All Set" is displayed. Additionally all of the options listed below are enabled. Events – Log Alarm Events – Log Bypass Events – Log Open/Close Events – Log Trouble Non-Security OR Proceed to step 11 and select the options individually.</p> |
| <p>Events – Log Alarm Enabled</p> | <p>11. Select "Events – Log Alarm". The System toggles between "Enabled" and "Disabled". 12. Select "Events – Log Bypass". The System toggles between "Enabled" and "Disabled". 13. Select "Events – Log Open/Close". The System toggles between "Enabled" and "Disabled". 14. Select "Events – Log Trouble". The System toggles between "Enabled" and "Disabled".</p> |
| <p>Remote Access Serial Disabled</p> | <p>15. Select "Remote Access Serial". The System toggles between "Enabled" and "Disabled". If the Remote Access Serial" option is enabled, the "Multi Mode Serial" option is displayed.</p> |
| <p>Non Security Disabled</p> | <p>16. Select "Non Security". The System toggles between "Enabled" and "Disabled".</p> |
| <p>Multi Mode Serial Disabled</p> | <p>17. Select "Multi Mode Serial". The System toggles between "Enhanced Reports" and "Disabled". 18. Select "Save" when complete.</p> |

Programming the Control

Program Date and Time

Note: If applicable, preprogrammed defaults for the LYNX Touch Control are shown on the screen unless otherwise noted.

| SCREEN | ACTION | | | | | | | | | | | | |
|---|--|-------------------|----------------|----------------|---------------|---------------|-------------------|---------------|---------------|-----------|---------|----------|----------|
|  | <p>Note: If you are installing a GSMVLP5-4G/GSMVLP5CN4G or ILP5 Communication Module, the time and date will be programmed and updated automatically via Central Station. You must still program the correct Time Zone below.</p> <ol style="list-style-type: none"> 1. Select "Date Time". | | | | | | | | | | | | |
|  | <ol style="list-style-type: none"> 2. Using the left ◀ and right ▶ arrows select the Month and Year then select the date. Select the ▼ key to advance to the next screen. | | | | | | | | | | | | |
|  | <ol style="list-style-type: none"> 3. To set the correct time, touch the "Clear" button. 4. Enter the correct time and then select AM or PM. Select the ▼ key to advance to the next screen or select "Save" to return to the System Programming Screen. | | | | | | | | | | | | |
|  | <ol style="list-style-type: none"> 5. Select "Time Zone". The system scrolls between the following options: <table border="1" data-bbox="753 1045 1403 1125"> <tr> <td>Eastern (EST)</td> <td>Mountain (MST)</td> <td>Atlantic (AST)</td> </tr> <tr> <td>Central (CST)</td> <td>Pacific (PST)</td> <td>Newfoundland (NT)</td> </tr> <tr> <td>Hawaii (HAST)</td> <td>Alaska (AKST)</td> <td></td> </tr> </table> | Eastern (EST) | Mountain (MST) | Atlantic (AST) | Central (CST) | Pacific (PST) | Newfoundland (NT) | Hawaii (HAST) | Alaska (AKST) | | | | |
| Eastern (EST) | Mountain (MST) | Atlantic (AST) | | | | | | | | | | | |
| Central (CST) | Pacific (PST) | Newfoundland (NT) | | | | | | | | | | | |
| Hawaii (HAST) | Alaska (AKST) | | | | | | | | | | | | |
|  | <ol style="list-style-type: none"> 6. Select "Day Light Savings Time". The system toggles between "Yes" and "No". If "Yes" is selected the following options will become active. | | | | | | | | | | | | |
|  | <ol style="list-style-type: none"> 7. Select "Start Month". The system displays the following options. <table border="1" data-bbox="753 1255 1029 1367"> <tr> <td>January</td> <td>February</td> </tr> <tr> <td>March</td> <td>April</td> </tr> <tr> <td>May</td> <td>June</td> </tr> <tr> <td>July</td> <td>August</td> </tr> </table> Use the down ▼ arrow to scroll to the next page of options. <table border="1" data-bbox="753 1402 1045 1455"> <tr> <td>September</td> <td>October</td> </tr> <tr> <td>November</td> <td>December</td> </tr> </table> | January | February | March | April | May | June | July | August | September | October | November | December |
| January | February | | | | | | | | | | | | |
| March | April | | | | | | | | | | | | |
| May | June | | | | | | | | | | | | |
| July | August | | | | | | | | | | | | |
| September | October | | | | | | | | | | | | |
| November | December | | | | | | | | | | | | |
|  | <ol style="list-style-type: none"> 8. Select "Start Week". The system scrolls between the following options. <table border="1" data-bbox="753 1497 1289 1577"> <tr> <td>First</td> <td>Fourth</td> <td>3rd from Last</td> </tr> <tr> <td>Second</td> <td>Last</td> <td></td> </tr> <tr> <td>Third</td> <td>Next to Last</td> <td></td> </tr> </table> | First | Fourth | 3rd from Last | Second | Last | | Third | Next to Last | | | | |
| First | Fourth | 3rd from Last | | | | | | | | | | | |
| Second | Last | | | | | | | | | | | | |
| Third | Next to Last | | | | | | | | | | | | |
|  | <ol style="list-style-type: none"> 9. Select "End Month". The system displays the following options. <table border="1" data-bbox="753 1623 1029 1734"> <tr> <td>January</td> <td>February</td> </tr> <tr> <td>March</td> <td>April</td> </tr> <tr> <td>May</td> <td>June</td> </tr> <tr> <td>July</td> <td>August</td> </tr> </table> Use the down ▼ arrow to scroll to the next page of options. <table border="1" data-bbox="753 1770 1045 1822"> <tr> <td>September</td> <td>October</td> </tr> <tr> <td>November</td> <td>December</td> </tr> </table> | January | February | March | April | May | June | July | August | September | October | November | December |
| January | February | | | | | | | | | | | | |
| March | April | | | | | | | | | | | | |
| May | June | | | | | | | | | | | | |
| July | August | | | | | | | | | | | | |
| September | October | | | | | | | | | | | | |
| November | December | | | | | | | | | | | | |
|  | <ol style="list-style-type: none"> 10. Select "End Week". The system will scrolls through the available weeks. <table border="1" data-bbox="753 1864 1289 1944"> <tr> <td>First</td> <td>Fourth</td> <td>3rd from Last</td> </tr> <tr> <td>Second</td> <td>Last</td> <td></td> </tr> <tr> <td>Third</td> <td>Next to Last</td> <td></td> </tr> </table> 11. After programming these options, select the "Save" key. | First | Fourth | 3rd from Last | Second | Last | | Third | Next to Last | | | | |
| First | Fourth | 3rd from Last | | | | | | | | | | | |
| Second | Last | | | | | | | | | | | | |
| Third | Next to Last | | | | | | | | | | | | |

Programming the Control

Program the Communications Module



A router is required if you are installing the L5100-WiFi module. The router must be powered on and connected for WiFi operation (alarm reporting) to occur.

The following system options are programmed in this section:

| Option | Function |
|-----------------------|--|
| Communications Path | Selects type of Communications Module |
| APL | Enables Advanced Protection Logic |
| City ID | Enter Central Station Primary City ID |
| CS ID | Enter Primary Central Station ID |
| Sub ID | Enter Central Station Primary Subscriber ID |
| Supervision | Selects how often the Communications Module sends supervisory messages to the Central Sta. |
| Old Alarm Time | Selects how long an undeliverable alarm delivery is retried to the Central Station. |
| Remote Acc. Comm. | Enables or disables user remote access via internet and/or GSM. |
| Multi Mode Comm. | (appears only if Remote Access IP or GSM is enabled.) Enables or disables multi mode feature. |
| IP Fault Time | (Appears only if IP is enabled in Communications Path field.) Selects time delay before the Communications Module notifies the control panel of a loss of contact with the internet. |
| Use DHCP | Dynamically selects the IP addresses |
| NIC IP Address | (Appears only if "No" is selected in Use DHCP field.) Enter NIC IP Address. |
| Subnet Mask | (Appears only if "No" is selected in Use DHCP field.) Enter Subnet Address. |
| Gateway IP Address | (Appears only if "No" is selected in Use DHCP field.) Enter Gateway IP Address |
| DNS Server IP Address | (Appears only if "No" is selected in Use DHCP field.) Enter Domain Name Server IP Address. |
| GSM Fault Time | (Appears only if GSM is enabled in Communications Path field.) Selects time delay before the Communications Module notifies the control panel of a loss of contact with the network. |
| GSM Rollover | Allows messages to be sent over GSM in the event that contact with the internet is lost. (Appears only if "WiFi & GSM" is selected as the Communications Path.) |
| GSM 24 Hour Test | Enables daily test of GSM module operation. (Appears only if "WiFi & GSM" is selected as the Communications Path.) |

Note: If applicable, preprogrammed defaults for the LYNX Touch Control are shown on the screen unless otherwise noted.



Remote Access (Total Connect) and Multi Mode (PSD) over IP or GSM cannot be enabled in the panel alone. Availability of this service is controlled via the web-based programming tool on the AlarmNet Direct website. These features must to be enabled through the AlarmNet Direct website first and transferred to the device.

| SCREEN | ACTION | | | | | | | | | | | | |
|--|---|---------------------|------|---------|------------|-------------|----------------|-------------------|------------------|---------------|----------|----------------|--|
| <div style="border: 1px solid black; padding: 5px; text-align: center;"> Communicator <small>5000-100-132-V0</small> </div> | <p>Communicator</p> <ol style="list-style-type: none"> Select "Communicator". The System displays several pages of options that vary depending upon the selections that are made. Use the down ▼ arrow to scroll through the pages of options. <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; border-right: 1px solid black;">Communications Path</td> <td style="text-align: center;">APL</td> </tr> <tr> <td style="text-align: center; border-right: 1px solid black;">City ID</td> <td style="text-align: center;">Sub ID</td> </tr> <tr> <td style="text-align: center; border-right: 1px solid black;">Supervision</td> <td style="text-align: center;">Old Alarm Time</td> </tr> <tr> <td style="text-align: center; border-right: 1px solid black;">Remote Acc. Comm.</td> <td style="text-align: center;">Multi Mode Comm.</td> </tr> <tr> <td style="text-align: center; border-right: 1px solid black;">IP Fault Time</td> <td style="text-align: center;">Use DHCP</td> </tr> <tr> <td style="text-align: center; border-right: 1px solid black;">GSM Fault Time</td> <td></td> </tr> </table> | Communications Path | APL | City ID | Sub ID | Supervision | Old Alarm Time | Remote Acc. Comm. | Multi Mode Comm. | IP Fault Time | Use DHCP | GSM Fault Time | |
| Communications Path | APL | | | | | | | | | | | | |
| City ID | Sub ID | | | | | | | | | | | | |
| Supervision | Old Alarm Time | | | | | | | | | | | | |
| Remote Acc. Comm. | Multi Mode Comm. | | | | | | | | | | | | |
| IP Fault Time | Use DHCP | | | | | | | | | | | | |
| GSM Fault Time | | | | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;"> Communications Path None </div> | <ol style="list-style-type: none"> Select "Communications Path". The system scrolls between the following options. <p>Notes: The available options are dependant upon which communications module(s) are installed. If Communication Path is set to GSM, the L5100 will report to AlarmNet over GSM/GPRS not WiFi.</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">None</td> <td style="text-align: center;">WiFi</td> </tr> <tr> <td style="text-align: center;">IP</td> <td style="text-align: center;">WiFi & GSM</td> </tr> <tr> <td style="text-align: center;">GSM</td> <td></td> </tr> </table> | None | WiFi | IP | WiFi & GSM | GSM | | | | | | | |
| None | WiFi | | | | | | | | | | | | |
| IP | WiFi & GSM | | | | | | | | | | | | |
| GSM | | | | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;"> APL Disabled </div> | <ol style="list-style-type: none"> Select "APL". The system scrolls between "Enabled" and "Disabled". <p>Note: If APL is used, GSM or IP must be selected as the Primary Communicator Type in the Reporter programming.</p> | | | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;"> City ID </div> | <ol style="list-style-type: none"> Select "City ID". Enter the 2-digit Primary City ID (Decimal). <p>Options 01-99</p> | | | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;"> CS ID </div> | <ol style="list-style-type: none"> Select "CS ID". Enter the 2-digit Primary Central Station ID (HEX). <p>Options 01-FE</p> | | | | | | | | | | | | |

Programming the Control

| SCREEN | ACTION | | | | | | | | | | |
|---|--|------------|------------|------------|--------|---------|---------|---------|----------|----------|--|
| <div style="border: 1px solid black; padding: 5px; text-align: center;">Sub ID</div> | 6. Select "Sub ID". Enter the 4-digit Subscriber Account Number (Decimal). Options 0001-9999 | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;">Supervision 24 Hours</div> | 7. Select "Supervision". The system scrolls between the following options: 24 Hours None 30 Days | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;">Old Alarm Time 10 Minutes</div> | 8. Select "Old Alarm Time". The system scrolls between the following options. Use the down ▼ arrow to scroll to the next page of options. <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">10 Minutes</td> <td style="width: 50%;">15 Minutes</td> </tr> <tr> <td>30 Minutes</td> <td>1 Hour</td> </tr> <tr> <td>2 Hours</td> <td>4 Hours</td> </tr> <tr> <td>8 Hours</td> <td>12 Hours</td> </tr> <tr> <td>24 Hours</td> <td></td> </tr> </table> | 10 Minutes | 15 Minutes | 30 Minutes | 1 Hour | 2 Hours | 4 Hours | 8 Hours | 12 Hours | 24 Hours | |
| 10 Minutes | 15 Minutes | | | | | | | | | | |
| 30 Minutes | 1 Hour | | | | | | | | | | |
| 2 Hours | 4 Hours | | | | | | | | | | |
| 8 Hours | 12 Hours | | | | | | | | | | |
| 24 Hours | | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;">Remote Acc. Comm. Disabled</div> | 9. Select "Remote Acc. Comm.". The system toggles between "Disabled" and "Enabled". Note: This field will not be programmable unless it is enabled when creating the Communications Module account in AlarmNet. | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;">Multi Mode Comm. Disabled</div> | 10. If "Remote Access Comm." was enabled in the previous step, the "Multi Mode Comm." option is displayed. The system scrolls between the following options. Disabled Relay Reports Enhanced Reports Note: This field will not be programmable unless it is enabled when creating the Communications Module account in AlarmNet. The Relay Reports option should not be selected when using TotalConnect 2.1 Service. 11. Use the down ▼ arrow to scroll to the next page of options. If IP was selected in step 2, proceed to step 12. If GSM was selected in step 2, proceed to step 19. | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;">IP Fault Time (min) 00</div> | 12. Select "IP Fault Time (min)". Enter the time delay (in minutes) on the keypad. Options 00-99 | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;">Use DHCP Yes</div> | 13. Select "Use DHCP". The system toggles between "Yes" and "No". If "No" is selected the system displays four additional options. If "Yes" is selected, skip to step 18. | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;">NIC IP Address 255.255.255.255</div> | 14. Select "NIC IP Address". Enter the 4-part address on the displayed keypad. | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;">Subnet Mask 255.255.255.255</div> | 15. Select "Subnet Mask". Enter the 4-part address on the displayed keypad. | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;">Gateway IP Address 255.255.255.255</div> | 16. Select "Gateway IP Address". Enter the 4-part address on the displayed keypad. | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;">DNS Server IP Address 255.255.255.255</div> | 17. Select "DNS Server IP Address". Enter the 4-part address on the displayed keypad. 18. If "IP" was selected in step 2, select "Save" and then select "OK" when the "Programming Done" screen appears. Proceed to "Diagnostics" section in order to register the device. | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;">GSM Fault Time (min) 00</div> | 19. Select "GSM Fault Time (min)". Enter the time delay (in minutes) on the keypad. Options 00-99 | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;">GSM Rollover No</div> | 20. If "WiFi and GSM" was selected in step 2, two additional programming fields are displayed. Select "GSM Rollover", the system toggles between "Yes" and "No". | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; text-align: center;">GSM 24 Hour Test No</div> | 19. Select "GSM 24 Hour Test", the system toggles between "Yes" and "No". 20. If "GSM" was selected in step 2, select "Save" and then select "OK" when the "Programming Done" screen appears. Proceed to "Diagnostics" section in order to register the device. | | | | | | | | | | |

Programming the Control

Program the Z-Wave Module

The following system options are programmed in this section:

| Option | Function |
|---------------------|--|
| Z-Wave | Enables or disables the Z-Wave Module |
| Temperature Display | Toggles between Fahrenheit and Celsius (for Z-Wave Theromstat) |

- Notes:**
1. This programming field will only be visible if a Z-Wave Module is installed in the control.
 2. If applicable, preprogrammed defaults for the LYNX Touch Control are shown on the screen unless otherwise noted.
 3. The Z-Wave option must be enabled before installing the Z-Wave Module in the LYNX Touch Control.
 4. In the event that the Z-Wave option has been changed to "Disabled" and then enabled, the LYNX Touch power must be recycled or the system must be rebooted. Refer to the *Rebooting the System* section for additional information.

| SCREEN | ACTION |
|--|---|
| <div style="border: 1px solid black; padding: 10px; width: fit-content; margin: auto;"> <p>Z - Wave</p> <p style="font-size: small; margin-top: 5px;">5100-100-067-V0</p> </div> | <p>Note: This procedure must be completed any time that the panel has been defaulted or updated.</p> <ol style="list-style-type: none"> 1. Enter Program Mode and default the panel (Refer to "Loading Factory Defaults"). 2. Select "Z-Wave" The System displays the following options: <div style="text-align: center;"> Z-Wave Temperature Display </div> |
| <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> <p>Z-Wave Enabled-Installed Telephone</p> </div> | <ol style="list-style-type: none"> 3. Select "Z-Wave". The system scrolls between the following options: Enabled – Installed Telephone Side Disabled Select "Enabled – Installed Telephone Side". |
| <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> <p>Temperature Display Fahrenheit</p> </div> | <ol style="list-style-type: none"> 4. If you wish to change the temperature format, select "Temperature Display". The system scrolls between the following options: Fahrenheit Celsius 5. Select "Save". 6. Exit Programming mode. 7. Remove AC power and disconnect battery. 8. Install Z-Wave module. 9. Connect battery and apply AC power. 10. At the Security Home screen Select "Automation". 11. At the next screen Select "Tools". 12. At the next screen Select "Advanced Tools". 13. Enter the Master User Code "1-2-3-4" on the displayed keypad. 14. At the next screen select "Reset Controller". 15. The system displays "Done". Select OK. 16. Select the "↩" key to return to the previous screen. 17. Include Z-Wave devices. (Refer to Including/Excluding Z-Wave Devices in the Home Automation Guide P/N 800-11309 or higher.) |

Programming the Control

Program Zones

The following system options are programmed in this section:

| Option | Function |
|----------------------|--|
| Serial Number | Manually enter device serial number or enroll via RF transmission |
| Loop Number | Manually enter device loop number or enroll via RF transmission |
| Zone Description 1/2 | Enter Zone Descriptors for the device being enrolled |
| Device Type | Select the type of device being enrolled |
| Response Type | Select the alarm response for the device being enrolled (refer to Zone Response Type Table) |
| Alarm Report | Activate reporting option for the device being enrolled |
| Chime | Enable/disable chime mode for specific device being enrolled (applies to Entry/ Exit, Perimeter, and Interior Response types only) |
| Supervision | Select supervision for device being enrolled |

Note: If applicable, preprogrammed defaults for the LYNX Touch Control are shown on the screen unless otherwise noted.

| SCREEN | ACTION | | | | | | | | | | | | | | | | | | |
|---|--|--|---------------|--------------|-----------|------------------|--------|-----------------|---------------|--|--------------------|--------------------|--|-------------|---------------|--|--------------|-------|-------------|
| <div style="border: 1px solid black; padding: 5px; width: fit-content;">Zones</div> <p style="font-size: small; margin-top: 5px;">5000-100-133-V0</p> | <ol style="list-style-type: none"> Select "Zones" The System displays the following options: <table style="margin-left: 20px; border-collapse: collapse;"> <tr> <td style="border-right: 1px solid black; padding-right: 10px;">1. New</td> <td>2. Front Door</td> </tr> <tr> <td style="border-right: 1px solid black; padding-right: 10px;">3. Back Door</td> <td>4. Window</td> </tr> <tr> <td style="border-right: 1px solid black; padding-right: 10px;">5. Motion Sensor</td> <td>6. New</td> </tr> </table> Use the down ▼ arrow to scroll to the next page of options. Use the ▲ arrow to return to the previous page. 7. – 45. New 46. – 48 New (Main) (reserved for Garage Door Zones) 49. – 56. 4 Button 57. – 64. New 80. – 85. Temperature (Z-Wave Thermostat zones) 95. Fire 96. Medical 99. Police Select a zone and then select "Edit" or "Add New" to program the next available zone. The following options are displayed (dependant upon Zone Type): <table style="margin-left: 20px; border-collapse: collapse;"> <tr> <td style="border-right: 1px solid black; padding-right: 10px;">Serial Number *</td> <td style="border-right: 1px solid black; padding-right: 10px;">Loop Number *</td> <td style="padding-left: 10px;">* This field does not apply to Hardwire Zone 1 or Temperature Zones 80-85.</td> </tr> <tr> <td style="border-right: 1px solid black; padding-right: 10px;">Zone Description 1</td> <td style="border-right: 1px solid black; padding-right: 10px;">Zone Description 2</td> <td></td> </tr> <tr> <td style="border-right: 1px solid black; padding-right: 10px;">Device Type</td> <td style="border-right: 1px solid black; padding-right: 10px;">Response Type</td> <td></td> </tr> <tr> <td style="border-right: 1px solid black; padding-right: 10px;">Alarm Report</td> <td style="border-right: 1px solid black; padding-right: 10px;">Chime</td> <td>Supervision</td> </tr> </table> Select an option to display the next programming field. | 1. New | 2. Front Door | 3. Back Door | 4. Window | 5. Motion Sensor | 6. New | Serial Number * | Loop Number * | * This field does not apply to Hardwire Zone 1 or Temperature Zones 80-85. | Zone Description 1 | Zone Description 2 | | Device Type | Response Type | | Alarm Report | Chime | Supervision |
| 1. New | 2. Front Door | | | | | | | | | | | | | | | | | | |
| 3. Back Door | 4. Window | | | | | | | | | | | | | | | | | | |
| 5. Motion Sensor | 6. New | | | | | | | | | | | | | | | | | | |
| Serial Number * | Loop Number * | * This field does not apply to Hardwire Zone 1 or Temperature Zones 80-85. | | | | | | | | | | | | | | | | | |
| Zone Description 1 | Zone Description 2 | | | | | | | | | | | | | | | | | | |
| Device Type | Response Type | | | | | | | | | | | | | | | | | | |
| Alarm Report | Chime | Supervision | | | | | | | | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;">Serial Number</div> | <p>Serial Number (This field does not apply to Temperature Zones 80-85) When "Serial Number" has been selected "Enter Serial Number or Activate" is displayed. The transmitter serial number and loop number can be enrolled via RF transmission OR manually.</p> <p>Enroll via RF Learning To enroll the device using RF Learning mode three transmissions (open/close) of the device will be required. The initial transmission activates the RF Learning mode and the system will emit a single beep. A second transmission enrolls the serial number and the system beeps two times and displays "Activate Sensor Again To Confirm". A third transmission will confirm the serial number. The system beeps two times and returns to the Zone programming Screen.</p> <p>Enroll Manually Enter the 7-digit serial number printed on the transmitter using the displayed keypad and select "Done". The system beeps one time and returns to the Zone programming Screen.</p> | | | | | | | | | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;">Loop Number 1</div> | <p>Loop Number (This field does not apply to Temperature Zones 80-85) Select "Loop Number" to toggle between 1, 2, 3 and 4. Enter Save.</p> | | | | | | | | | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;">Zone Description 1</div> | <p>Zone Description 1/Zone Description 2 When programming the Zone Description, after entering the first letter of the description on the keypad you can use the up ▲ and down ▼ arrows to scroll through the available preprogrammed zone descriptions. For a list of the pre-programmed Zone Descriptors, please visit http://www.security.honeywell.com/hsc/resources/MyWebTech</p> <p>Select "Zone Description 1 or Zone Description 2". Using the displayed keypad enter Zone Description 1 or Zone Description 2. The system announces the Zone Description. Enter "Done", when you are finished. The system returns to the Zone Programming page.</p> | | | | | | | | | | | | | | | | | | |

Programming the Control

| SCREEN | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|----------|--------------|--------------|---------------|-------------------|----------------|----------------|-------------------|-------------------|----------------------|---------------------|---------|-----------------|--------|-------------|----------|--------|-------------|-----------------|------------------|-------------------|-----------------|------------------|------------------------|-----------|----------------|
| <p>Device Type</p> | <p>Device Type Select "Device Type". The system displays the following options (dependant upon the Device Type selection):</p> <table border="0"> <tr> <td>New</td> <td>Door</td> </tr> <tr> <td>Window</td> <td>Motion Sensor</td> </tr> <tr> <td>Glass Break</td> <td>Smoke Detector</td> </tr> <tr> <td>Heat Sensor</td> <td>Carbon Mono. Det.</td> </tr> </table> <p>Use the down ▼ arrow to scroll to the next page of options:</p> <table border="0"> <tr> <td>Temperature</td> <td>Flood</td> </tr> <tr> <td>Environmental</td> <td>Medical</td> </tr> <tr> <td>Fire</td> <td>Police</td> </tr> <tr> <td>Garage Door</td> <td>Other</td> </tr> </table> | New | Door | Window | Motion Sensor | Glass Break | Smoke Detector | Heat Sensor | Carbon Mono. Det. | Temperature | Flood | Environmental | Medical | Fire | Police | Garage Door | Other | | | | | | | | | | |
| New | Door | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Window | Motion Sensor | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Glass Break | Smoke Detector | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Heat Sensor | Carbon Mono. Det. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Temperature | Flood | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Environmental | Medical | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Fire | Police | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Garage Door | Other | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>Response Type</p> <p>Not Used</p> | <p>Response Type</p> <p>1. Select "Response Type". The system displays the specific options, which are dependant upon the Device Type that was selected for the zone. Use the down ▼ arrow to scroll to the next page of options. Use the ▲ arrow to return to the previous page.</p> <table border="0"> <tr> <td>Not Used</td> <td>Entry Exit 1</td> </tr> <tr> <td>Entry Exit 2</td> <td>Perimeter</td> </tr> <tr> <td>Interior Follower</td> <td>Trouble</td> </tr> <tr> <td>24 Hour Silent</td> <td>24 Hour Audible</td> </tr> <tr> <td>24 Hour Auxiliary</td> <td>Fire No Verification</td> </tr> <tr> <td>Interior With Delay</td> <td>Monitor</td> </tr> <tr> <td>Carbon Monoxide</td> <td>Garage</td> </tr> <tr> <td>Arm Stay</td> <td>Arm Away</td> </tr> <tr> <td>Disarm</td> <td>No Response</td> </tr> <tr> <td>Silent Burglary</td> <td>Resident Monitor</td> </tr> <tr> <td>Resident Response</td> <td>General Monitor</td> </tr> <tr> <td>General Response</td> <td>Fire With Verification</td> </tr> <tr> <td>Day/Night</td> <td>Garage Monitor</td> </tr> </table> <p>2. Select the desired Response Type and select "Save". The system will return to the Zone screen.</p> <p>Note: For threshold monitoring to be configurable on the LYNX Touch Z-wave thermostat screen, the respective zones will first need to be assigned with a response type in zone programming. The recommended response type is Trouble.</p> | Not Used | Entry Exit 1 | Entry Exit 2 | Perimeter | Interior Follower | Trouble | 24 Hour Silent | 24 Hour Audible | 24 Hour Auxiliary | Fire No Verification | Interior With Delay | Monitor | Carbon Monoxide | Garage | Arm Stay | Arm Away | Disarm | No Response | Silent Burglary | Resident Monitor | Resident Response | General Monitor | General Response | Fire With Verification | Day/Night | Garage Monitor |
| Not Used | Entry Exit 1 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Entry Exit 2 | Perimeter | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Interior Follower | Trouble | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 24 Hour Silent | 24 Hour Audible | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 24 Hour Auxiliary | Fire No Verification | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Interior With Delay | Monitor | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Carbon Monoxide | Garage | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Arm Stay | Arm Away | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Disarm | No Response | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Silent Burglary | Resident Monitor | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Resident Response | General Monitor | | | | | | | | | | | | | | | | | | | | | | | | | | |
| General Response | Fire With Verification | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Day/Night | Garage Monitor | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>Alarm Report</p> <p>Yes</p> | <p>Alarm Report</p> <p>Note: This field is for Alarms. If Response Type "Trouble" is set up and Alarm Report is set to "No" the system will still report if Report Alarms was enabled in the Reporter programming.</p> <p>Select "Report" to toggle between "No" or "Yes". Select "Save".</p> | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>Chime</p> <p>No</p> | <p>Chime</p> <p>Note: Chime only applies to entry/exit, perimeter and interior zone types.</p> <p>Select "Chime" to toggle between "No" or "Yes". Select "Save".</p> | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>Supervision</p> <p>Supervised</p> | <p>Supervision</p> <p>The system displays the applicable Supervision options based upon the Device Type that was selected. Select "Supervision" to scroll between the following options:</p> <p>Hardwire Zone</p> <p>Normal Open Normal Closed End of Line</p> <p>RF Zone</p> <p>Supervised Unsupervised</p> <p>Temperature (Defaulted for Zones 80-85) High Temp (Default selection for Zones 80, 82 and 84) Low Temp (Default selection for Zones 81, 83 and 85)</p> <p>After making a Supervision selection, select "Save".</p> | | | | | | | | | | | | | | | | | | | | | | | | | | |

Programming the Control Program Keys

The following system options are programmed in this section

| Option | Function |
|---------------------|--|
| Key Type | Select the specific type of key being entered or enrolled |
| User | Associates the Key with a specific User |
| Serial Number | Manually enter key serial number or enroll via RF transmission |
| Zone | Manually enter key zone number (between 49 and 64) or enroll via RF transmission |
| Button Key * - Zn * | Associate the selected button with a specific function |

* Key number and Zn number are dependant upon the Key Type selected.

Note: If applicable, preprogrammed defaults for the LYNX Touch Control are shown on the screen unless otherwise noted.

| SCREEN | ACTION | | | | | | | | | | | | | | | |
|---------------------------------|---|--------------|--------------|--------------|--------------|--------------|---------------|--------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|
| Keys | <p>1. Select "Keys"</p> <p>The System displays the following options:</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 33%;">Edit</td> <td style="text-align: center; width: 33%;">Add New</td> <td style="text-align: center; width: 33%;">Delete</td> </tr> </table> <p>2. Select "Add New".</p> <p>3. The following options are displayed (dependant upon the "Key Type" selected):</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 50%;">Key Type</td> <td style="text-align: center; width: 50%;">User</td> </tr> <tr> <td style="text-align: center;">Serial Number</td> <td style="text-align: center;">Zone</td> </tr> <tr> <td style="text-align: center;">Button Key 1 – Zn 49</td> <td style="text-align: center;">Button Key 2 – Zn 50</td> </tr> <tr> <td style="text-align: center;">Button Key 3 – Zn 51</td> <td style="text-align: center;">Button Key 4 – Zn 52</td> </tr> <tr> <td style="text-align: center;">Button Key 5 – Zn 53</td> <td style="text-align: center;">Button Key 6 – Zn 54</td> </tr> <tr> <td style="text-align: center;">Button Key 7 – Zn 55</td> <td style="text-align: center;">Button Key 8 – Zn 56</td> </tr> </table> <p>Select an option to display the next programming field.</p> | Edit | Add New | Delete | Key Type | User | Serial Number | Zone | Button Key 1 – Zn 49 | Button Key 2 – Zn 50 | Button Key 3 – Zn 51 | Button Key 4 – Zn 52 | Button Key 5 – Zn 53 | Button Key 6 – Zn 54 | Button Key 7 – Zn 55 | Button Key 8 – Zn 56 |
| Edit | Add New | Delete | | | | | | | | | | | | | | |
| Key Type | User | | | | | | | | | | | | | | | |
| Serial Number | Zone | | | | | | | | | | | | | | | |
| Button Key 1 – Zn 49 | Button Key 2 – Zn 50 | | | | | | | | | | | | | | | |
| Button Key 3 – Zn 51 | Button Key 4 – Zn 52 | | | | | | | | | | | | | | | |
| Button Key 5 – Zn 53 | Button Key 6 – Zn 54 | | | | | | | | | | | | | | | |
| Button Key 7 – Zn 55 | Button Key 8 – Zn 56 | | | | | | | | | | | | | | | |
| Key Type 4 Button key | <p>Key Type</p> <p>Select "Key Type". The system scrolls between the following:</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 50%;">1 Button key</td> <td style="text-align: center; width: 50%;">6 Button key</td> </tr> <tr> <td style="text-align: center;">2 Button key</td> <td style="text-align: center;">8 Button key</td> </tr> <tr> <td style="text-align: center;">4 Button key</td> <td></td> </tr> </table> | 1 Button key | 6 Button key | 2 Button key | 8 Button key | 4 Button key | | | | | | | | | | |
| 1 Button key | 6 Button key | | | | | | | | | | | | | | | |
| 2 Button key | 8 Button key | | | | | | | | | | | | | | | |
| 4 Button key | | | | | | | | | | | | | | | | |
| User | <p>User</p> <p>Select "User" then select from the following options (or the list of Users that have been programmed):</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 50%;">Master</td> <td style="text-align: center; width: 50%;">Babysitter</td> </tr> <tr> <td style="text-align: center;">Duress</td> <td style="text-align: center;">User 3</td> </tr> <tr> <td style="text-align: center;">User 4</td> <td style="text-align: center;">User 5</td> </tr> <tr> <td style="text-align: center;">User 6</td> <td style="text-align: center;">User 7</td> </tr> </table> <p>Use the down ▼ arrow to scroll to the next page. The system displays options for User 8 through 14.</p> <p>Note: The Key must be associated with a specific User/User Code in order for it to operate. Refer to the LYNX Touch User Guide for additional Information regarding User Codes.</p> | Master | Babysitter | Duress | User 3 | User 4 | User 5 | User 6 | User 7 | | | | | | | |
| Master | Babysitter | | | | | | | | | | | | | | | |
| Duress | User 3 | | | | | | | | | | | | | | | |
| User 4 | User 5 | | | | | | | | | | | | | | | |
| User 6 | User 7 | | | | | | | | | | | | | | | |
| Serial Number 0 | <p>Serial Number</p> <p>When "Serial Number" has been selected "Enter Serial Number or Activate" is displayed. The transmitter serial number and loop number can be enrolled via RF transmission OR manually.</p> <p>Enroll via RF Learning To enroll the device using RF Learning mode three transmissions (open/close) of the device will be required. The initial transmission activates the RF Learning mode. A second transmission enrolls the serial number and the system beeps two times and displays "Activate Sensor Again To Confirm". A third transmission will confirm the serial number. The system beeps three times and returns to the Zone programming Screen.</p> <p>Enroll Manually</p> <p>Enter the 7-digit serial number printed on the transmitter using the displayed keypad and select "Done". The system beeps one time and returns to the Zone programming Screen.</p> | | | | | | | | | | | | | | | |
| Zone 49 | <p>Zone</p> <p>The system displays the next available key Zone number. Select "Zone" to manually enter a specific Zone Number on the displayed keypad (49-64). If the desired Zone Number is not available, the system returns to the previous screen.</p> <p>Select "Done". The system returns to the previous screen. Repeat the previous step to enter another Zone Number.</p> | | | | | | | | | | | | | | | |

Programming the Control

| SCREEN | ACTION | | |
|---|---|---|---|
| <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> Button Key * - Zn * </div> | <p>Button Key * Zn * Select the desired Button Key and enter a function for each button key. The system displays the following options:</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; vertical-align: top;"> <ul style="list-style-type: none"> Disarm Arm Stay 24 Hour Silent 24 Hour Auxiliary Fire No Verification </td> <td style="width: 50%; vertical-align: top; border-left: 1px solid black; padding-left: 10px;"> <ul style="list-style-type: none"> Arm Away No Response 24 Hour Audible Silent Burglary </td> </tr> </table> <p>* Options are the same for each Button/Zone combination.</p> | <ul style="list-style-type: none"> Disarm Arm Stay 24 Hour Silent 24 Hour Auxiliary Fire No Verification | <ul style="list-style-type: none"> Arm Away No Response 24 Hour Audible Silent Burglary |
| <ul style="list-style-type: none"> Disarm Arm Stay 24 Hour Silent 24 Hour Auxiliary Fire No Verification | <ul style="list-style-type: none"> Arm Away No Response 24 Hour Audible Silent Burglary | | |

Programming the Control Reporter



When Compass service is required and GSM or IP are the only reporting channels: As part of Primary Central Station programming; the "Phone Type" must be set to any selection other than "None", the "Communicator Type" must be set to GSM or IP, as applicable, and must match the compass value; "Phone number" field must be left blank and an "Account number" must be programmed.

The following system options are programmed in this section:

| Option | Function |
|-------------------------------------|---|
| Primary or Secondary CS Info | Enroll information pertaining to the Primary and/or Secondary Central Station. |
| Phone Type | Select the Report Format that will be used to send reports to the Primary or Secondary Central Station, as applicable. |
| Phone Number | Enter the Phone Number for the Primary or Secondary Central Station, as applicable. |
| Communicator Type | Select the type of Communications Module that will be used to communicate with the Primary or Secondary Central Station, as applicable. |
| Account Number | Enter the account number for the Primary or Secondary Central Station, as applicable. |
| Dynamic Priority | Select the primary method for sending Reports to the Primary or Secondary Central Station, as applicable. |
| Dynamic Delay | Selects delay between switching between reporting methods. Active if Dynamic Delay feature has been set to Preferred Telco or Preferred Radio. |
| Report All | Enable All Reports to be sent to the Primary or Secondary Central Station, as applicable. |
| Report Alarms | Enable Alarm Reporting to the Primary or Secondary Central Station, as applicable. |
| Report Troubles | Enable Trouble Reporting to the Primary or Secondary Central Station, as applicable. |
| Report Open/Close | Enable Open/Close Reporting to the Primary or Secondary Central Station, as applicable. |
| Report Tests | Enable Test Reporting to the Primary or Secondary Central Station, as applicable. |
| Follow Me Phone 1 or Phone 2 | Enroll information Primary and/or Secondary telephone numbers for "Follow Me" Announcements and/or Reminders. |
| Phone Type | Enter Number for Follow Me Phone 1 or Phone 2, as applicable. |
| Phone Number | Enter Primary and/or Secondary telephone numbers for "Follow Me" Announcements and/or Reminders. |
| Report All | Enable All Reports to be sent to the Follow Me Phone 1 or Phone 2, as applicable. |
| Report Alarms | Enable Alarm Reporting to the Follow Me Phone 1 or Phone 2, as applicable. |
| Report Troubles | Enable Trouble Reporting to the Follow Me Phone 1 or Phone 2, as applicable. |
| Report Open/Close | Enable Open/Close Reporting to the Follow Me Phone 1 or Phone 2, as applicable. |
| Report Tests | Enable Test Reporting to the Follow Me Phone 1 or Phone 2, as applicable. |
| Report Selection | Enable Reporting of Specific Events |
| Options | |
| PBX | Enter the digits required to access an outside line, if applicable |
| Call Wait Cancel | Enter the digits required to cancel call waiting, if applicable |
| Number of Reports | Limit the number of messages sent to the Central Station during an armed period. (applies to LYNX Touch only) |
| Alarm Report Delay | Disable or select the time delay for alarm reporting (applies to LYNX Touch only) |
| Swinger Shutdown | Select the number of times reports are sent and sounder sounds for non-fire alarms before the system ignores subsequent alarms (applies to LYNX Touch SIA only) |
| Abort Window | Select the time delay for alarm reporting (applies to LYNX Touch SIA only) |
| First Offset Report | Select the time for the first test report following power-up/programming or downloading |
| Report Frequency | Select the test report frequency |
| Downloader | |
| Phone Answer | Enable or disable to allow control to answer incoming phone line. |
| Modem Speed | (Future Use) |
| Ans. Machine Defeat | Enable to defeat answering machine mode. (Active if Phone Answer is enabled.) |
| Ring Counter | Enter the number of rings before control picks up phone line. (Active if Ans. Machine Defeat is not enabled.) |
| Callback Number | Enter the phone number the control will use to call back the downloading computer. (Active if Phone Answer is enabled.) |
| Flexible Callback | Allows Download operator to temporarily change the callback number by the number of digits selected. Active if Phone Answer is enabled |
| Number | Enter the number of flexible callback numbers that will be used. Active if Flexible Callback is enabled. |

Programming the Control

Notes: If applicable, preprogrammed defaults for the LYNX Touch Control are shown on the screen unless otherwise noted. When GSM is used as the Primary Communications channel for any Total Connect service, the GSM Radio must be selected as the Primary Reporting Path (Preferred Radio).

| SCREEN | ACTION | | | | | | | | |
|--|---|-----------------|-------------------|-------------------|-------------------|------------------|---------|------------|--|
| <p>Reporter</p> | <p>Select "Reporter" The System displays the following options:</p> <table border="0" style="width: 100%;"> <tr> <td style="width: 50%;">Primary CS Info</td> <td style="width: 50%;">Secondary CS Info</td> </tr> <tr> <td>Follow Me Phone 1</td> <td>Follow Me Phone 2</td> </tr> <tr> <td>Report Selection</td> <td>Options</td> </tr> <tr> <td>Downloader</td> <td></td> </tr> </table> | Primary CS Info | Secondary CS Info | Follow Me Phone 1 | Follow Me Phone 2 | Report Selection | Options | Downloader | |
| Primary CS Info | Secondary CS Info | | | | | | | | |
| Follow Me Phone 1 | Follow Me Phone 2 | | | | | | | | |
| Report Selection | Options | | | | | | | | |
| Downloader | | | | | | | | | |
| <p>Primary CS Info</p> | <p>Select "Primary CS Info". The System displays the following options:</p> <table border="0" style="width: 100%;"> <tr> <td style="width: 50%;">Phone Type</td> <td style="width: 50%;">Communicator Type</td> </tr> </table> | Phone Type | Communicator Type | | | | | | |
| Phone Type | Communicator Type | | | | | | | | |
| <p>Phone Type Contact Id: 4 Digit</p> | <p>Select "Phone Type". The System scrolls though the following options: None Contact Id: 4 Digit Contact Id: 10 Digit SIA</p> | | | | | | | | |
| <p>Communicator Type None</p> | <p>Select "Communicator Type". The System scrolls though the following options: None GSM WiFi WiFi & GSM IP Note: The system will display the communications (GSM or IP) paths based upon the selection made in Communicator Programming. The Communication Path selection can be enabled for either Primary Central Station or Secondary Central Station but not both. If it is enabled in one it will not be available for the other Central Station. If APL is used, GSM or IP must be selected as the Primary Communicator Type.</p> | | | | | | | | |
| <p>Phone Number</p> | <p>If any option other than "None" is selected in "Phone Type" The "Phone Number" option will be displayed. Select "Phone Number". Enter the Primary Central Station Phone Number on the displayed keypad. (Up to 20 digits)</p> | | | | | | | | |
| <p>Account Number FFFF</p> | <p>If any option other than "None" is selected in "Phone Type" The "Account Number" option will be displayed. Select "Account Number". Enter the Primary Central Station Account Number on the displayed keypad.</p> | | | | | | | | |
| <p>Dynamic Priority Redundant Reports</p> | <p>If any option other than "None" is selected in "Communicator Type" The "Dynamic Priority" option will be displayed. "Select "Dynamic Priority". The system scrolls between "Redundant Reports", "Preferred Telco" and Preferred Radio".</p> | | | | | | | | |
| <p>Dynamic Delay 30 Seconds</p> | <p>If any option other than "Redundant Reports" is selected in "Dynamic Priority" The "Dynamic Delay" option will be displayed. "Select "Dynamic Delay". The system scrolls between "15 Seconds", "30 Seconds", "60 Seconds" and "90 Seconds". Note: If GSM is selected as the primary reporting channel Dynamic Delay should be set to minimum of 60 seconds.</p> | | | | | | | | |
| <p>Report All Press to Report All</p> | <p>Select "Report All". The System toggles between "Press to Report All" and "Report All Set". If "Report All" is selected all reporting options will be "Enabled". Select the "Save" key to return to the Reporter options screen.</p> | | | | | | | | |
| <p>Report Alarms Enabled</p> | <p>Select "Report Alarms". The System toggles between "Disabled" and "Enabled". SIA: The LYNX Touch default is "Enabled".</p> | | | | | | | | |
| <p>Report Troubles Enabled</p> | <p>Select "Report Troubles". The System toggles between "Disabled" and "Enabled". SIA: The LYNX Touch default is "Enabled".</p> | | | | | | | | |
| <p>Report Open/Close Disabled</p> | <p>Select "Open/Close". The System toggles between "Disabled" and "Enabled".</p> | | | | | | | | |
| <p>Report Tests Enabled</p> | <p>Select "Report Tests". The System toggles between "Disabled" and "Enabled". SIA: The LYNX Touch default is "Enabled" and is not selectable.</p> | | | | | | | | |
| <p>Secondary CS Info</p> | <p>Select "Secondary CS Info". The System displays the following options:</p> <table border="0" style="width: 100%;"> <tr> <td style="width: 50%;">Phone Type</td> <td style="width: 50%;">Communicator Type</td> </tr> </table> | Phone Type | Communicator Type | | | | | | |
| Phone Type | Communicator Type | | | | | | | | |

Programming the Control

| SCREEN | ACTION |
|--|---|
| <p>Phone Type None</p> | <p>Select "Phone Type". The System displays the following options: None Contact Id: 4 Digit Contact Id: 10 Digit SIA</p> |
| <p>Communicator Type None</p> | <p>Select "Communicator Type". The System displays the following options: None GSM or IP Note: The system will display the communications path (GSM or IP) selected in Communications Programming. The path can be enabled for either primary Central Station or Secondary Central Station but not both. If it is enabled in one it will not be available for the other Central Station.</p> |
| <p>Phone Number</p> | <p>If any option other than "None" is selected in "Phone Type", the "Phone Number" option will be displayed. Select "Phone Number". Enter the Secondary Central Station Phone Number on the displayed keypad. (Up to 20 digits)</p> |
| <p>Account Number FFFF</p> | <p>If any option other than "None" is selected in "Phone Type" The "Account Number" option will be displayed. Select "Account Number". Enter the Secondary Central Station Account Number on the displayed keypad.</p> |
| <p>Dynamic Priority Redundant Reports</p> | <p>If any option other than "None" is selected in "Communicator Type" The "Dynamic Priority" option will be displayed. "Select "Dynamic Priority". The system scrolls between "Redundant Reports", "Preferred Telco" and Preferred Radio".</p> |
| <p>Dynamic Delay 30 Seconds</p> | <p>If any option other than "Redundant Reports" is selected in "Dynamic Priority" The "Dynamic Delay" option will be displayed. "Select "Dynamic Delay". The system scrolls between "15 Seconds", "30 Seconds", "60 Seconds" and "90 Seconds". Note: If GSM is selected as the primary reporting channel Dynamic Delay should be set to minimum of 60 seconds.</p> |
| <p>Report All Press to Report All</p> | <p>Select "Report All". The System toggles between "Press to Report All" and "Report All Set". If "Report All" is selected all reporting options will be "Enabled". Select the "Save" key to return to the Reporter options screen.</p> |
| <p>Report Alarms Enabled</p> | <p>Select "Report Alarms". The System toggles between "Disabled" and "Enabled".</p> |
| <p>Report Troubles Enabled</p> | <p>Select "Report Troubles". The System toggles between "Disabled" and "Enabled".</p> |
| <p>Report Open/Close Disabled</p> | <p>Select "Open/Close". The System toggles between "Disabled" and "Enabled".</p> |
| <p>Report Tests Enabled</p> | <p>Select "Report Tests". The System toggles between "Disabled" and "Enabled". SIA: The LYNX Touch default is "Enabled" and is not selectable.</p> |
| <p>Follow Me Phone 1</p> | <p>Select "Follow Me Phone 1" to program the "Follow Me" Reminder telephone number 1</p> |
| <p>Phone Type None</p> | <p>Select "Phone Type". The System toggles between "None" and "Follow Me".</p> |
| <p>Phone Number</p> | <p>Select "Phone Number". Enter the "Follow Me" Phone Number 1 on the displayed keypad.</p> |
| <p>Report All Press to Report All</p> | <p>Select "Report All". The System toggles between "Press to Report All" and "Report All Set". If "Report All" is selected all reporting options will be "Enabled". Select the "Save" key to return to the Reporter options screen.</p> |
| <p>Report Alarms Disabled</p> | <p>Select "Report Alarms". The System toggles between "Disabled" and "Enabled".</p> |
| <p>Report Troubles Disabled</p> | <p>Select "Report Troubles". The System toggles between "Disabled" and "Enabled".</p> |

Programming the Control

| SCREEN | ACTION | | |
|--|--|--|---|
| Report Open/Close Disabled | Select "Open/Close". The System toggles between "Disabled" and "Enabled". | | |
| Report Tests Disabled | Select "Report Tests". The System toggles between "Disabled" and "Enabled". | | |
| Follow Me Phone 2 | Select "Follow Me Phone 2" to program the "Follow Me" Reminder telephone number 2. | | |
| Phone Type None | Select "Phone Type". The System toggles between "None" and "Follow Me". | | |
| Phone Number | Select "Phone Number". Enter the "Follow Me" Phone Number 2 on the displayed keypad. | | |
| Report All Press to Report All | Select "Report All". The System toggles between "Press to Report All" and "Report All Set". If "Report All" is selected all reporting options will be "Enabled". Select the "Save" key to return to the Reporter options screen. | | |
| Report Alarms Enabled | Select "Report Alarms". The System toggles between "Disabled" and "Enabled". | | |
| Report Troubles Enabled | Select "Report Troubles". The System toggles between "Disabled" and "Enabled". | | |
| Report Open/Close Disabled | Select "Open/Close". The System toggles between "Disabled" and "Enabled". | | |
| Report Tests Enabled | Select "Report Tests". The System toggles between "Disabled" and "Enabled". | | |
| Report Selection | <p>Select "Report Selection". The System displays the following options:</p> <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; text-align: center; vertical-align: top;"> Arm Away Disarm Recent Closing Trouble Alarm Restore Test Bypass AC Loss Low Battery RF Low Battery </td> <td style="width: 50%; text-align: center; vertical-align: top;"> Arm Stay Exit Error Event Log Full Trouble Restore Alarm Cancel Test Restore Bypass Restore AC Loss Restore Low Battery Restore RF Low Battery Restore </td> </tr> </table> <p>Use the down ▼ arrow to scroll to the next page of options.</p> <p>Use the down ▼ arrow to scroll to the next page of options.</p> | Arm Away Disarm Recent Closing Trouble Alarm Restore Test Bypass AC Loss Low Battery RF Low Battery | Arm Stay Exit Error Event Log Full Trouble Restore Alarm Cancel Test Restore Bypass Restore AC Loss Restore Low Battery Restore RF Low Battery Restore |
| Arm Away Disarm Recent Closing Trouble Alarm Restore Test Bypass AC Loss Low Battery RF Low Battery | Arm Stay Exit Error Event Log Full Trouble Restore Alarm Cancel Test Restore Bypass Restore AC Loss Restore Low Battery Restore RF Low Battery Restore | | |
| Arm Away Enabled | Select "Arm Away". The System toggles between "Disabled" and "Enabled". | | |
| Arm Stay Enabled | Select "Arm Stay". The System toggles between "Disabled" and "Enabled". | | |
| Disarm Enabled | Select "Disarm". The System toggles between "Disabled" and "Enabled". | | |
| Exit Error Enabled | Select "Exit Error". The System toggles between "Disabled" and "Enabled". SIA: The LYNX Touch default is "Enabled" and is not selectable. | | |
| Recent Closing Enabled | Select "Recent Closing". The System toggles between "Disabled" and "Enabled". SIA: The LYNX Touch default is "Enabled" and is not selectable. | | |
| Event Log Full Enabled | Select "Event Log Full". The System toggles between "Disabled" and "Enabled". | | |

Programming the Control

| SCREEN | ACTION | | |
|--|--|---|--|
| <p>Trouble Enabled</p> | <p>Select "Trouble". The System toggles between "Disabled" and "Enabled".</p> | | |
| <p>Trouble Restore Enabled</p> | <p>Select "Trouble Restore". The System toggles between "Disabled" and "Enabled".</p> | | |
| <p>Alarm Restore Enabled</p> | <p>Select "Alarm Restore". The System toggles between "Disabled" and "Enabled".</p> | | |
| <p>Alarm Cancel Enabled</p> | <p>Select "Alarm Cancel". The System toggles between "Disabled" and "Enabled".</p> | | |
| <p>Test Enabled</p> | <p>Select "Test". The System toggles between "Disabled" and "Enabled". SIA: The LYNX Touch default is "Enabled" and is not selectable.</p> | | |
| <p>Test Restore Enabled</p> | <p>Select "Test Restore". The System toggles between "Disabled" and "Enabled". SIA: The LYNX Touch default is "Enabled" and is not selectable.</p> | | |
| <p>Bypass Enabled</p> | <p>Select "Bypass". The System toggles between "Disabled" and "Enabled".</p> | | |
| <p>Bypass Restore Enabled</p> | <p>Select "Bypass Restore". The System toggles between "Disabled" and "Enabled".</p> | | |
| <p>AC Loss Enabled</p> | <p>Select "AC Loss". The System toggles between "Disabled" and "Enabled".</p> | | |
| <p>AC Loss Restore Enabled</p> | <p>Select "AC Loss Restore". The System toggles between "Disabled" and "Enabled".</p> | | |
| <p>Low Battery Enabled</p> | <p>Select "Low Battery". The System toggles between "Disabled" and "Enabled".</p> | | |
| <p>Low Battery Restore Enabled</p> | <p>Select "Low Battery Restore". The System toggles between "Disabled" and "Enabled".</p> | | |
| <p>RF Low Battery Enabled</p> | <p>Select "RF Low Battery". The System toggles between "Disabled" and "Enabled".</p> | | |
| <p>RF Low Battery Restore Enabled</p> | <p>Select "RF Low Battery Restore". The System toggles between "Disabled" and "Enabled".</p> | | |
| <p>Options</p> | <p>Select "Options". The System displays the following options:</p> <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; text-align: center; border-right: 1px solid black;"> PBX Number of Reports First Report Offset </td> <td style="width: 50%; text-align: center;"> Call Wait Cancel Alarm Report Delay Report Frequency </td> </tr> </table> | PBX Number of Reports First Report Offset | Call Wait Cancel Alarm Report Delay Report Frequency |
| PBX Number of Reports First Report Offset | Call Wait Cancel Alarm Report Delay Report Frequency | | |
| <p>PBX</p> | <p>Select "PBX", and enter PBX Prefix on the displayed keypad.</p> | | |
| <p>Call Wait Cancel</p> | <p>Select "Call Wait Cancel", and enter Call Wait Cancel Prefix on the displayed keypad</p> | | |

Programming the Control

| SCREEN | ACTION | | | | | | |
|---|---|--------------|-------------|---------------------|-----------------|--------------|--------------------------|
| <p>Number of Reports 2 Reports</p> | <p>Select "Number of Reports" LYNX Touch The system scrolls between the following options: 1, 2, 3, 4, 5 and 6 Reports LYNX Touch (L5100CN) Canada The system toggles between "Unlimited" and "10 Reports".</p> | | | | | | |
| <p>Alarm Report Delay 30 Sec.</p> | <p>Select "Alarm Report Delays". The System scrolls between the following options: 15 Sec. 30 Sec. 45 Sec. No delay SIA The Alarm Report Delay (burglary abort window) must be set to a minimum of 15 seconds. The sum of the burglary abort window and the entry delays should not exceed 1 minute. Note: The LYNX Touch control validates the data entered in this field. If the selection is not valid the control will emit a single long beep indicating that the selection has been rejected. The control replaces the selection with the default value "30 Sec".</p> | | | | | | |
| <p>First Report Offset 6 Hrs</p> | <p>Select "First Report Offset" for the Test Report. The System scrolls between the following options: 6 Hrs 12 Hrs 18 Hrs 24 Hrs</p> | | | | | | |
| <p>Report Frequency Never</p> | <p>Select "Report Frequency" for the Test Report. The System scrolls between the following options: Never Every Day Every 7 Days Every 30 Days</p> | | | | | | |
| <p>Downloader</p> | <p>Select "Downloader". The System displays the following options:</p> <table border="0" style="width: 100%;"> <tr> <td style="width: 50%;">Phone Answer</td> <td style="width: 50%;">Modem Speed</td> </tr> <tr> <td>Ans. Machine Defeat</td> <td>Callback Number</td> </tr> <tr> <td>Ring Counter</td> <td>Flexible Callback Number</td> </tr> </table> | Phone Answer | Modem Speed | Ans. Machine Defeat | Callback Number | Ring Counter | Flexible Callback Number |
| Phone Answer | Modem Speed | | | | | | |
| Ans. Machine Defeat | Callback Number | | | | | | |
| Ring Counter | Flexible Callback Number | | | | | | |
| <p>Phone Answer Yes</p> | <p>Select "Phone Answer", the system toggles between "Yes" and "No".</p> | | | | | | |
| <p>Modem Speed Slow</p> | <p>(Future Use)</p> | | | | | | |
| <p>Ans. Machine Defeat Yes</p> | <p>Select "Ans. Machine Defeat", the system toggles between "Yes" and "No".</p> | | | | | | |
| <p>Callback Number</p> | <p>Select "Callback Number" and enter callback number on the displayed keypad.</p> | | | | | | |
| <p>Ring Counter 2</p> | <p>This option only appears if Answering Machine defeat is set to "No". Enter ring counter (1 – 14 rings) on the displayed keypad.</p> | | | | | | |
| <p>Flexible Callback No</p> | <p>Select "Flexible Callback", the system toggles between "Yes" and "No".</p> | | | | | | |
| <p>Number 1</p> | <p>This option only appears if "Flexible Callback" is set to "Yes". The system scrolls between options 1, 2 and 3.</p> | | | | | | |

Programming the Control Sounder

The following system options are programmed in this section:

| Option | Function |
|-----------------------|--|
| Burglary Alarm Sound | Switches the full 110 dB alarm sound for burglary On/Off. |
| Burglary Bell Timeout | Select the time for timeout of the Burglary Alarm sounder. |
| Fire Bell Timeout | Select the time for timeout of the Fire Alarm sounder. |
| Arm Confirm | Enable sounder "ding" when system is armed via the selected RF device. |
| Alarm Options | Select a limit for the number of times an alarm can sound for a specific zone. Note: This option does not apply to the LYNX Touch SIA control. |

Note: If applicable, preprogrammed defaults for the LYNX Touch Control are shown on the screen unless otherwise noted.

| SCREEN | ACTION |
|---|--|
| <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> Sounder </div> | Select "Sounder" The System displays the following options: <div style="display: flex; justify-content: space-around; text-align: center;"> <div style="width: 45%;"> Burglary Alarm Sound Fire Bell Timeout Alarm Options </div> <div style="width: 45%;"> Burglary Bell Timeout Arm Confirm </div> </div> |
| <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> Burglary Alarm Sound Yes </div> | Select "Burglary Alarm Sound". The System toggles between Yes* and No: |
| <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> Burglary Bell Timeout 4 Minutes </div> | Select "Burglary Bell Timeout". The System scrolls between the following options: No 4 Minutes 8 Minutes 12 Minutes 16 Minutes |
| <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> Fire Bell Timeout 4 Minutes </div> | Select "Fire Bell Timeout". The System scrolls between the following options: No 4 Minutes 8 Minutes 12 Minutes 16 Minutes |
| <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> Arm Confirm None </div> | Select "Arm Confirm". The System scrolls between the following options: None All RF RF Key Fob RF Keypad |
| <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> Alarm Options Unlimited </div> | Note: This option does not apply to the LYNX Touch SIA Control. Select "Alarm Options". The System scrolls between the following options: Unlimited 1 2 10 Select "Save". |

Programming the Control

System Settings

The following system options are programmed in this section:

| Option | Function |
|----------------------------|--|
| Entry Delay1/Entry Delay 2 | Selects an Entry Delay time in seconds. The system will wait the time entered before sounding alarm upon entering if system is not disarmed. Note: The Default values differ for the LYNX Touch and LYNX Touch SIA controls. |
| Exit Delay | Selects an Exit Delay time in seconds for both Entry Delay 1 and 2 Zone Types. The system will wait the time entered before sounding an alarm if the exit door is left open after the system has been armed. Note: The Default values differ for the LYNX Touch and LYNX Touch SIA controls. |
| Backlight Timeout | Enable or disable display backlight turnoff after 30 seconds. |
| Quick Arm | Enables or disables Quick Arm Mode. If enabled, security code is not required to arm the system. The user simply presses the AWAY button (ICON) and then selects the "Quick Arm" button on the displayed keypad to arm the system. |
| Quick Exit | Enables or disables Quick Exit Mode. If enabled allows the user restart the exit delay to allow entry or exit when the system is armed |
| Restart Exit Time | Enables or disables Restart Exit Time Mode. This option allows the control to restart the exit delay time after arming in STAY mode by entering the User Code and pressing the STAY key (if quick arming is disabled) or by pressing the STAY key (if quick arming is enabled). This option also enables automatic exit delay reset, which resets exit delay if the entry/exit door is re-opened and closed before exit delay time expires after arming. |
| Force Bypass | Enables or disables Force Bypass Mode. All zones bypassed by this function will be displayed after the bypass is initiated. The Fire and CO Zones are not bypassed in the LYNX Touch. |
| Exit Warning | Enables or disables Exit Warning sound. Audible Exit Warning sound consists of slow continuous beeps until last 10 seconds, when it changes to fast beeps. The warning sound will end at the termination of exit delay. Note: This field is not programmable in the LYNX Touch SIA and is always enabled. |
| Auto Stay Arming | Enables or disables Auto Stay Arming Mode. If this feature is enabled and the control panel has been armed "Armed Away" at the LYNX Touch keypad or RF keypad, the system will switch to the "Armed Stay" mode if the Exit Time has expired and no exit has been made. |
| Lack of Usage Notify | Enables or disables Lack of Usage Notification feature. If enabled, notifies the central station if an end user is not operating their security system by sending a System Inactivity report 654. The report will be sent only to the Primary phone number and only if Contact ID® format was selected. |
| Power-Up in Previous | Enables or disables Power-Up in Previous Mode feature. When the system powers up armed, an alarm will occur 1 minute after arming if a zone is faulted. For the LYNX Touch control any bypassed zones will be unbypassed. For the LYNX Touch SIA any bypassed zones will remain bypassed. |
| Display Alarm Cancel | Enables or disables display of Cancelled Alarm. |
| Display Exit Time | Enables or disables display of Exit Time. |
| Cross Zone Delay | Sets the maximum amount of time in which two zones must be tripped in an armed system to send an alarm message to the Central Station. If only one cross zone is tripped during this time, a trouble message (CID code 380) for that zone is sent to the Central Station. |
| Cross Zone 1/Cross Zone 2 | Select the zones that will be used for Cross Zoning |

Programming the Control

Note: If applicable, preprogrammed defaults for the LYNX Touch Control are shown on the screen unless otherwise noted.

| SCREEN | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|------------------------------------|--|------------------------------------|------------|--|-------------------|------------|--|------------|--------------|--|--------------|------------|--|-------------------|------------|--|------------------|----------------------|--|----------------------|----------------------|--|-------------------|-----------|--|------------------|--------------|--|--------------|
| <p style="text-align: center;">System Settings</p> | <p>Select "System Settings" The System displays the following options:</p> <table style="width: 100%; border: none;"> <tr> <td style="width: 50%; border: none;">Entry Delay 1</td> <td style="width: 5%; border: none;"> </td> <td style="width: 45%; border: none;">Entry Delay 2</td> </tr> <tr> <td style="border: none;">Exit Delay</td> <td style="border: none;"> </td> <td style="border: none;">Backlight Timeout</td> </tr> <tr> <td style="border: none;">Quick Arm</td> <td style="border: none;"> </td> <td style="border: none;">Quick Exit</td> </tr> <tr> <td style="border: none;">Force Bypass</td> <td style="border: none;"> </td> <td style="border: none;">Exit Warning</td> </tr> <tr> <td style="border: none;"></td> <td style="border: none;"> </td> <td style="border: none;">Restart Exit Time</td> </tr> <tr> <td style="border: none;"></td> <td style="border: none;"> </td> <td style="border: none;">Auto Stay Arming</td> </tr> </table> <p>Use the down ▼ arrow to scroll to the next page of options. Use the ▲ arrow to return to the previous page:</p> <table style="width: 100%; border: none;"> <tr> <td style="width: 50%; border: none;">Lack of Usage Notify</td> <td style="width: 5%; border: none;"> </td> <td style="width: 45%; border: none;">Power-Up In Previous</td> </tr> <tr> <td style="border: none;">Display Alarm Cancel</td> <td style="border: none;"> </td> <td style="border: none;">Display Exit Time</td> </tr> <tr> <td style="border: none;"></td> <td style="border: none;"> </td> <td style="border: none;">Cross Zone Delay</td> </tr> <tr> <td style="border: none;">Cross Zone 1</td> <td style="border: none;"> </td> <td style="border: none;">Cross Zone 2</td> </tr> </table> | Entry Delay 1 | | Entry Delay 2 | Exit Delay | | Backlight Timeout | Quick Arm | | Quick Exit | Force Bypass | | Exit Warning | | | Restart Exit Time | | | Auto Stay Arming | Lack of Usage Notify | | Power-Up In Previous | Display Alarm Cancel | | Display Exit Time | | | Cross Zone Delay | Cross Zone 1 | | Cross Zone 2 |
| Entry Delay 1 | | Entry Delay 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Exit Delay | | Backlight Timeout | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Quick Arm | | Quick Exit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Force Bypass | | Exit Warning | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Restart Exit Time | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Auto Stay Arming | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Lack of Usage Notify | | Power-Up In Previous | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Display Alarm Cancel | | Display Exit Time | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Cross Zone Delay | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Cross Zone 1 | | Cross Zone 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p style="text-align: center;">Entry Delay 1 30 Seconds</p> | <p>Select "Entry Delay 1". The System scrolls between the following options:</p> <table style="width: 100%; border: none;"> <tr> <td style="width: 50%; border: none;">LYNX Touch</td> <td style="width: 5%; border: none;"> </td> <td style="width: 45%; border: none;">LYNX Touch (L5100CN) Canada</td> </tr> <tr> <td style="border: none;">None</td> <td style="border: none;"> </td> <td style="border: none;">None</td> </tr> <tr> <td style="border: none;">15 Seconds</td> <td style="border: none;"> </td> <td style="border: none;">15 Seconds</td> </tr> <tr> <td style="border: none;">30 Seconds</td> <td style="border: none;"> </td> <td style="border: none;">30 Seconds</td> </tr> <tr> <td style="border: none;">45 Seconds</td> <td style="border: none;"> </td> <td style="border: none;">45 Seconds</td> </tr> <tr> <td style="border: none;">60 Seconds</td> <td style="border: none;"> </td> <td style="border: none;">60 Seconds</td> </tr> <tr> <td style="border: none;">90 Seconds</td> <td style="border: none;"> </td> <td style="border: none;">90 Seconds</td> </tr> <tr> <td style="border: none;">2 Minutes</td> <td style="border: none;"> </td> <td style="border: none;">2 Minutes</td> </tr> <tr> <td style="border: none;">3 Minutes</td> <td style="border: none;"> </td> <td style="border: none;"></td> </tr> <tr> <td style="border: none;">4 Minutes</td> <td style="border: none;"> </td> <td style="border: none;"></td> </tr> </table> <p>UL installations: The Entry Delay must be set for a maximum of 45 seconds. SIA: The Entry delay must be set to a minimum of 30 seconds. The sum of entry delay 1 and the burglary abort window should not exceed 1 minute. "None" is only allowed for use in Commercial High-Security applications.</p> | LYNX Touch | | LYNX Touch (L5100CN) Canada | None | | None | 15 Seconds | | 15 Seconds | 30 Seconds | | 30 Seconds | 45 Seconds | | 45 Seconds | 60 Seconds | | 60 Seconds | 90 Seconds | | 90 Seconds | 2 Minutes | | 2 Minutes | 3 Minutes | | | 4 Minutes | | |
| LYNX Touch | | LYNX Touch (L5100CN) Canada | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| None | | None | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 Seconds | | 15 Seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 30 Seconds | | 30 Seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 45 Seconds | | 45 Seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 60 Seconds | | 60 Seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 90 Seconds | | 90 Seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 Minutes | | 2 Minutes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 Minutes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 Minutes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p style="text-align: center;">Entry Delay 2 30 Seconds</p> | <p>Select "Entry Delay 2". The System scrolls between the following options:</p> <table style="width: 100%; border: none;"> <tr> <td style="width: 50%; border: none;">LYNX Touch</td> <td style="width: 5%; border: none;"> </td> <td style="width: 45%; border: none;">LYNX Touch (L5100CN) Canada</td> </tr> <tr> <td style="border: none;">None</td> <td style="border: none;"> </td> <td style="border: none;">None</td> </tr> <tr> <td style="border: none;">15 Seconds</td> <td style="border: none;"> </td> <td style="border: none;">15 Seconds</td> </tr> <tr> <td style="border: none;">30 Seconds</td> <td style="border: none;"> </td> <td style="border: none;">30 Seconds</td> </tr> <tr> <td style="border: none;">45 Seconds</td> <td style="border: none;"> </td> <td style="border: none;">45 Seconds</td> </tr> <tr> <td style="border: none;">60 Seconds</td> <td style="border: none;"> </td> <td style="border: none;">60 Seconds</td> </tr> <tr> <td style="border: none;">90 Seconds</td> <td style="border: none;"> </td> <td style="border: none;">90 Seconds</td> </tr> <tr> <td style="border: none;">2 Minutes</td> <td style="border: none;"> </td> <td style="border: none;">2 Minutes</td> </tr> <tr> <td style="border: none;">3 Minutes</td> <td style="border: none;"> </td> <td style="border: none;"></td> </tr> <tr> <td style="border: none;">4 Minutes</td> <td style="border: none;"> </td> <td style="border: none;"></td> </tr> </table> <p>UL installations: The Entry Delay must be set for a maximum of 45 seconds. SIA: The Entry delay must be set to a minimum of 30 seconds. The sum of entry delay 1 and the burglary abort window should not exceed 1 minute. "None" is only allowed for use in Commercial High-Security applications.</p> | LYNX Touch | | LYNX Touch (L5100CN) Canada | None | | None | 15 Seconds | | 15 Seconds | 30 Seconds | | 30 Seconds | 45 Seconds | | 45 Seconds | 60 Seconds | | 60 Seconds | 90 Seconds | | 90 Seconds | 2 Minutes | | 2 Minutes | 3 Minutes | | | 4 Minutes | | |
| LYNX Touch | | LYNX Touch (L5100CN) Canada | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| None | | None | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 Seconds | | 15 Seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 30 Seconds | | 30 Seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 45 Seconds | | 45 Seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 60 Seconds | | 60 Seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 90 Seconds | | 90 Seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 Minutes | | 2 Minutes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 Minutes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 Minutes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p style="text-align: center;">Exit Delay 60 Seconds</p> | <p>Select "Exit Delay". The System toggles between the following options:</p> <table style="width: 100%; border: none;"> <tr> <td style="width: 50%; border: none;">LYNX Touch</td> <td style="width: 5%; border: none;"> </td> <td style="width: 45%; border: none;">LYNX Touch (L5100CN) Canada</td> </tr> <tr> <td style="border: none;">45 Seconds</td> <td style="border: none;"> </td> <td style="border: none;">None</td> </tr> <tr> <td style="border: none;">60 Seconds</td> <td style="border: none;"> </td> <td style="border: none;">15 Seconds</td> </tr> <tr> <td style="border: none;">90 Seconds</td> <td style="border: none;"> </td> <td style="border: none;">30 Seconds</td> </tr> <tr> <td style="border: none;">2 Minutes</td> <td style="border: none;"> </td> <td style="border: none;">45 Seconds</td> </tr> <tr> <td style="border: none;"></td> <td style="border: none;"> </td> <td style="border: none;">60 Seconds</td> </tr> <tr> <td style="border: none;"></td> <td style="border: none;"> </td> <td style="border: none;">90 Seconds</td> </tr> <tr> <td style="border: none;"></td> <td style="border: none;"> </td> <td style="border: none;">2 Minutes</td> </tr> </table> <p>UL installations: Exit Delay must be set for a maximum of 60 seconds SIA: The Exit Delay must be set to a minimum of 45 seconds.</p> | LYNX Touch | | LYNX Touch (L5100CN) Canada | 45 Seconds | | None | 60 Seconds | | 15 Seconds | 90 Seconds | | 30 Seconds | 2 Minutes | | 45 Seconds | | | 60 Seconds | | | 90 Seconds | | | 2 Minutes | | | | | | |
| LYNX Touch | | LYNX Touch (L5100CN) Canada | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 45 Seconds | | None | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 60 Seconds | | 15 Seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 90 Seconds | | 30 Seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 Minutes | | 45 Seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 60 Seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 90 Seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 2 Minutes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p style="text-align: center;">Backlight Timeout No</p> | <p>Select "Backlight Timeout". The System toggles between No and 30 Seconds.</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Programming the Control

| SCREEN | ACTION |
|---|---|
| <p>Quick Arm Yes</p> | <p>Select "Quick Arm". The System toggles between Yes and No.</p> |
| <p>Quick Exit Yes</p> | <p>Select "Quick Exit". The System toggles between Yes and No.</p> |
| <p>Restart Exit Time Yes</p> | <p>Select "Restart Exit Time". The System toggles between Yes and No. SIA: The LYNX Touch default is "Yes".</p> |
| <p>Force Bypass No</p> | <p>Select "Force Bypass". The System toggles between Yes and No. UL installations: must be NO (no forced bypass)</p> |
| <p>Exit Warning Yes</p> | <p>Select "Exit Warning". The System toggles between Yes and No. SIA: The LYNX Touch default is "Yes" and is not selectable.</p> |
| <p>Auto Stay Arming Yes</p> | <p>Select "Auto Stay Arming". The System toggles between Yes and No. SIA: The LYNX Touch default is "Yes".</p> |
| <p>Lack of Usage Notify Disabled</p> | <p>Select "Lack of Usage Notify". The System scrolls between the following options: Disabled 1 Day 7 Days 27 Days 90 Days 180 Days 365 Days</p> |
| <p>Power-Up In Previous Yes</p> | <p>Select "Power-Up In Previous". The System toggles between Yes and No. Note: If the previous state was Armed Away or Stay, the system will not respond to sensor changes for 1 minute. This allows time for sensors such as PIRs to stabilize. UL installations: must be Yes (power up in previous state) SIA: The LYNX Touch default is "Yes" and is not selectable.</p> |
| <p>Display Alarm Cancel Yes</p> | <p>Select "Display Alarm Cancel". The System toggles between Yes and No.</p> |
| <p>Display Exit Time Yes</p> | <p>Select "Display Exit Time". The System toggles between Yes and No.</p> |
| <p>Cross Zone Delay None</p> | <p>Select "Cross Zone Delay". The System toggles between the following: None 30 Seconds 1 Minute 90 Seconds 2 Minutes 3 Minutes 4 Minutes Note: Cross zoning can not be used in conjunction with APL.</p> |
| <p>Cross Zone 1 Disabled</p> | <p>Select "Cross Zone 1". The System toggles between the following: Disabled Note: If Cross Zone Delay is enabled the system will display the zones that are programmed with the following Zone Types: Day/Night, Interior Follower and perimeter.</p> |
| <p>Cross Zone 2 Disabled</p> | <p>Select "Cross Zone 2". The System toggles between the following: Disabled Note: If Cross Zone Delay is enabled the system will display the zones that are programmed with the following Zone Types: Day/Night, Interior Follower and perimeter.</p> |

Programming the Control Communications Diagnostics

Communications Status – The system provides a status of the IP or GSM communications paths and performs a self-test of the AES encryption algorithm as follows:

| Message | | Meaning |
|------------------------|------------------|--|
| GSM: OR IP: | OK | Normal; No fault. (IP or GSM) |
| | Fault Reported! | No network connectivity and fault time has expired. (IP or GSM) |
| | Not Connected | No network connectivity over IP and fault time has NOT yet expired. |
| | Not Registered! | No network connectivity over GSM and fault time has NOT yet expired. |
| | No Physical Link | No network connectivity over IP and fault time is set to 0. |
| Encryption: | AES Passed! | Test successful. |
| | AES Failed! | Test failed. |
| | No Encryption! | No encryption algorithm set. |
| Alarmnet Registration: | Registered | Communication Device is Registered with AlarmNet. |
| | Not Registered | Communication Device is not Registered with AlarmNet. |

Ethernet Information – Displays IP information, if IP communication path is enabled.

Physical Link: Indicates status of the physical connection to the internet.
 DHCP: DHCP (Dynamic Host Configuration Protocol) indicated server is performing satisfactorily.
 NIC IP Address: Displays the IP address assigned to this device
 Subnet Mask: Displays the 32-bit address mask used to indicate the portion (bits) of the IP address that is being used for the subnet address.
 Gateway IP Address: Displays the IP address assigned to the Gateway.
 DNS Server IP Address: Displays the IP address assigned to the DNS (Domain Name System) server.

| Message | | Meaning |
|---------------|---------------------|-----------------------------------|
| Physical Link | 10 Mbps or 100 Mbps | Link speed of physical connection |
| | Bad | No physical connection |
| DHCP | OK | DHCP address resolved |
| | Bad | DHCP address not resolved |
| | Off | DHCP disabled |

GSM Information – Displays GSM information if GSM communication path is enabled.

| Status | Message | | Meaning |
|--------------------|---------------------------------------|---|---|
| GSM Registered | Cell Registration: | Home 2G | Registered Home with 2G Service |
| | | Home 3G | Registered Home with 3G/4G Service |
| | | Roaming | Registered Roaming |
| | Primary RSSI: | (See RSSI Note below) | Primary Site RSSI level signal strength (1 to 5 stars or "Not Present" will be displayed) |
| | | GPRS: (2G Only) (Always available in 3G/4G) | Yes No |
| | Country: | xxx | Country Code |
| | Network: | xxx | Network Code |
| | LAC | xxxxx | Local Area Code |
| | Cell: (2G only) Cell: (3G/4G only) | xxx | Base Station ID |
| | | xxxxxx | Base Station ID |
| | Base Station: (2G Only) | xx | Base Station Antenna Sector |
| | Primary Sync Code (3G/4G Only) | xxx | Primary Sync Code |
| | Channel: | xxxx | Control Channel in use |
| Second Site RSSI: | (See RSSI Note below) | Secondary Site RSSI level availability ("Present" OR "Not Present" will be displayed) | |
| GSM Not Registered | Searching For Coverage! | | Searching for cell network. |
| | SIM Error! | | No SIM card present or SIM card faulty |
| | Cell Registration: SIM Not Active | | SIM is not activated |
| | Cell Registration: Not Registered | | Not registered with cell network |

RSSI Note: Primary Site Signal strength is displayed by a series of 1 to 5 stars (* weak to ***** strong) or "Not Present" if there is no signal. To ensure a reliable installation at least 2 (**) stars should consistently be present. Secondary site presence is indicated by "Present" or "Not Present".

Programming the Control

Communications ID Numbers – Displays programmed SIM card information

| Message | | Meaning |
|----------------|----------------------|---|
| MAC: | xxxxxxxxxxxx | MAC Address indicates the unique identification number for installed communications module(s) |
| MAC CRC: | xxxx | MAC CRC number for installed communications module(s) |
| WiFi:* | xxxxxxxxxxxx | Physical MAC Address of the WiFi module |
| WiFi Ver: | x.x.x | WiFi module software version |
| SCID:** | xxxxxxxxxxxxxxxxxxxx | Displays the ID number assigned to the installed SIM card (SCID) |
| IMEI:** | xxxxxxxxxxxxxxx | Displays the ID number assigned to the installed GSM module. |

* This is the system MAC that should be referenced whenever speaking with technical support.

** Displayed if GSM communication path is enabled.

Test Communications – Performs network diagnostics and sends test alarms to AlarmNet. The following tests are available depending on the type of communications module installed.

Test Ethernet

This test is available if IP communication path is enabled. The network diagnostic process tests the integrity of the links between the LYNX Touch and the various connection points of AlarmNet Control that are known as “Redirectors”. If a physical link is detected and is ready, the following diagnostics are performed.

Testing Gateway... Traces the connection to the Gateway and displays the following:

Testing Gateway – Successful! A successful trace to Gateway. OR
Testing Gateway – Failed! Failed to reach Gateway.

Testing Redirector * Sequentially traces the connection to Redirector 1, 2 and 3 at AlarmNet Control. The following will be displayed.

Redirector * – Service OK Service at AlarmNet Control on Redirector 1, 2 or 3 is functioning. OR
Redirector * – Failed Error occurred on Redirector 1, 2 or 3.

* = Number of the director being tested is displayed

A summary of the tests is displayed after Redirector 3 is tested. The example shows that the tests of all three connection points, or Redirectors, were successful. If an error occurred at any point, the summary will display “Failed” next to the faulty Redirector.

Redirector 1 – Service OK
Redirector 2 – Service OK
Redirector 3 – Service OK

If no physical link is detected, the test is aborted and one of the following is displayed:

No Physical Link No physical link is detected.
Link Not Ready There is a link but it is not ready (address not resolved).

Send Any

If both IP and GSM communication paths are enabled and the LYNX Touch is registered, a Test alarm is sent over IP path. If that is not successful, it sends the alarm over GSM path and the following message is displayed: **Test Message Sent**

If the device is not registered, the following is displayed: **Test Message Failed – Not Registered**

Send GSM Message

If GSM communication path is enabled and the LYNX Touch is registered, a Test alarm to AlarmNet over the GSM path. The following message is displayed: **Test Message Sent**

If the device is not registered, the following message is displayed: **Test Message Failed – Not Registered**

Send Ethernet Message

If IP communication path is enabled and the LYNX Touch is registered, a Test alarm to AlarmNet over the IP path. The following message is displayed: **Test Message Sent**

If the device is not registered, the following message is displayed: **Test Message Failed – Not Registered**

Setup Communication – Performs registration of the LYNX Touch and its associated communication module with AlarmNet updates configuration files or reset factory defaults.

Registering the LYNX Touch

Once the LYNX Touch is initialized and a communications module is programmed, it must be registered to enable the account. Upon completion of the registration process, the LYNX Touch transmits a registration message and receives a registration validation indicating that the account is now enabled. Wait for the “Registration Success” message to appear, regardless of which registration method is used.

You can register the communications module by one of the following methods:

- Through the AlarmNet Direct website
- By Phone
- Through the LYNX Touch Diagnostics

Programming the Control

Register through AlarmNet Direct Website

If you have programmed the communications module through AlarmNet Direct, you must then transfer the data to the module, and register the module.

To do this, please go to: <https://services.alarmnet.com/AlarmNetDirect/userlogin.aspx>.

Log in and follow the on-screen prompts.

If you are not signed up for this service, click on “Dealer Signup” from the login screen to gain access to the Honeywell web-based programming.

Dealer Sign-Up Direct Link: https://services.alarmnet.com/AlarmNetDirectP_Sign-Up.

You will be instructed how to proceed upon completing the sign-up form. Only one sign-up per dealer is required. Once an initial user is established, additional logins may be created by that user.

Please have the following information available when programming the device:

1. Primary City ID (two-digit number)
2. Primary Central Station ID (two-digit hexadecimal number)
3. Primary Subscriber ID (four-digit number)
4. MAC ID and MAC CRC number (located on outside of box and on label inside module – *location to be confirmed*).

Once module is registered, you may log out of the AlarmNet Direct website.

Register by Phone

You can register the module by calling the AlarmNet Technical Assistance Center (TAC) at 1-800-222-6525.

You will need the following information:

- MAC number (found on the label).
- Subscriber information (provided by the central station), including a city code, CSID, and a subscriber ID.
- When instructed to do so, select **Register Device** in the LYNX Touch Diagnostics to complete the registration.

Register through LYNX Touch Diagnostics

Register the module using the LYNX Touch Diagnostics and the following procedure.

| SCREEN | ACTION | | | | | | |
|--|---|---|--|---|-------------------------|-----------------------|---|
| Comm. Diagnostics | <p>1. Select “Comm. Diagnostics” The System displays the following options depending upon the communication device that is installed:</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 33%; border-right: 1px solid black;">WiFi Location None</td> <td style="text-align: center; width: 33%; border-right: 1px solid black;">Configure WiFi</td> <td style="text-align: center; width: 33%;">Ethernet Information GSM Information</td> </tr> </table> <p>Use the down ▼ arrow to scroll to the next page of options. Use the ▲ arrow to return to the previous page:</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 33%; border-right: 1px solid black;">Communication Status</td> <td style="text-align: center; width: 33%; border-right: 1px solid black;">Test Communication</td> <td style="text-align: center; width: 33%;">Setup Communication Communication ID Numbers</td> </tr> </table> | WiFi Location None | Configure WiFi | Ethernet Information GSM Information | Communication Status | Test Communication | Setup Communication Communication ID Numbers |
| WiFi Location None | Configure WiFi | Ethernet Information GSM Information | | | | | |
| Communication Status | Test Communication | Setup Communication Communication ID Numbers | | | | | |
| Setup Communication | <p>2. Select “Setup Communication”. The System advances to the Registration screen and the following options are displayed:</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 50%; border-right: 1px solid black;">Register Device Update Server</td> <td style="text-align: center; width: 50%;">Register Device With PIN Factory Defaults</td> </tr> </table> <p>3. Select “Register Device”. The registration message is sent and the unit waits for the acknowledgement. (Refer to the table below for applicable registration messages.)</p> <p>Note: Register Device can be cancelled by selecting “Cancel”. The registration process is aborted and the message Registration Cancelled! is displayed.</p> | Register Device Update Server | Register Device With PIN Factory Defaults | | | | |
| Register Device Update Server | Register Device With PIN Factory Defaults | | | | | | |

Programming the Control

During the registration process the following messages may be displayed:

| Message | Meaning |
|--------------------------------|---|
| Getting Configuration File... | The configuration file is obtained from AlarmNet if the module was programmed through AlarmNet Direct or a previously programmed module was defaulted. |
| Registering... | The registration message is sent and the unit is waiting for the acknowledgement. |
| Registration Successful! | The module is registered and is now in full service and available for alarm reporting to the central station. |
| Registering – Try Later! | Error Message indicates the module is busy. |
| Registration Failed! | Error message followed by one of the messages below: |
| Invalid Configuration! | Indicates the configuration is invalid. |
| Timed Out. | Displayed if no response to the registration request is received. |
| Central Station Database Full. | Indicates CS database has more than 1000 subscribers. |
| Primary Sub ID Bad. | Indicates the city, central station, or customer number for the labeled account is not accepted. The ID information was either entered incorrectly, or the central station failed to pre-authorize programmed ID numbers with AlarmNet customer service. |
| Primary ID – Need PIN. | Indicates the city, central station, or customer number for the labeled account is not accepted. The ID information was either entered incorrectly, or the central station failed to pre-authorize programmed ID numbers with AlarmNet customer service. See the <i>Register Device With PIN</i> section. |
| Account Disabled. | Displayed if the account is disabled in AlarmNet. |

Register Device with PIN

This procedure is used to replace one LYNX Touch module with another.

| SCREEN | ACTION | | | | | | |
|--------------------------|--|----------------------|--------------------------|-----------------|--------------------------|--------------------|---------------------|
| Comm. Diagnostics | <p>1. Select “Comm. Diagnostics” The System displays the following options depending upon the communication device that is installed:</p> <table border="1"> <tr> <td>Communication Status</td> <td>Ethernet Information</td> <td>GSM Information</td> </tr> <tr> <td>Communication ID Numbers</td> <td>Test Communication</td> <td>Setup Communication</td> </tr> </table> | Communication Status | Ethernet Information | GSM Information | Communication ID Numbers | Test Communication | Setup Communication |
| Communication Status | Ethernet Information | GSM Information | | | | | |
| Communication ID Numbers | Test Communication | Setup Communication | | | | | |
| Setup Communication | <p>2. Select “Setup Communication”. The System advances to the Registration screen and the following options are displayed:</p> <table border="1"> <tr> <td>Register Device</td> <td>Register Device With PIN</td> </tr> <tr> <td>Update Server</td> <td>Factory Defaults</td> </tr> </table> <p>3. Select “Register Device With PIN”. Enter a 4-digit alphanumeric PIN number (provided by your central station, your dealer or an authorized AlarmNet representative) on the displayed keypad then select “Done”. (Refer to the table below for applicable registration messages.)</p> <p>Note: <i>Register Device With PIN</i> can be cancelled by selecting “Cancel”. The registration process is aborted and the message Registration Cancelled! is displayed.</p> | Register Device | Register Device With PIN | Update Server | Factory Defaults | | |
| Register Device | Register Device With PIN | | | | | | |
| Update Server | Factory Defaults | | | | | | |

During the registration process the following messages may be displayed:

| Message | Meaning |
|--------------------------|---|
| Registering... | The registration message is sent and the unit is waiting for the acknowledgement. |
| Registration Successful! | The PIN number is valid and module is registered and is now in full service and available for alarm reporting to the central station. The old module is unregistered. Additionally, AlarmNet sends a substitution alarm to the central station. |
| Registering – Try Later! | Error Message indicates the module is busy. |
| Registration Failed! | Error message followed by one of the messages below: |
| Invalid Configuration! | Indicates the configuration is invalid. |
| Timed Out. | Displayed if no response to the registration request is received. |
| Primary ID – Need PIN. | Indicates PIN that was entered is invalid. |

Programming the Control

Update Server

This procedure is used to upload the Configuration File to the Server.

| SCREEN | ACTION | | | | | | | | | |
|------------------------------|---|---|-----------------------------|-------------------------|---------------------|--|--------------------|-------------------------|-----------------------|---|
| Comm. Diagnostics | <p>1. Select "Comm. Diagnostics" The System displays the following options depending upon the communication device that is installed:</p> <table border="0" style="width: 100%; text-align: center;"> <tr> <td style="width: 33%;">WiFi Location None</td> <td style="width: 33%;">Configure WiFi</td> <td style="width: 33%;">Ethernet Information</td> </tr> <tr> <td></td> <td></td> <td style="text-align: center;">GSM Information</td> </tr> </table> <p>Use the down ▼ arrow to scroll to the next page of options. Use the ▲ arrow to return to the previous page:</p> <table border="0" style="width: 100%; text-align: center;"> <tr> <td style="width: 33%;">Communication Status</td> <td style="width: 33%;">Test Communication</td> <td style="width: 33%;">Setup Communication Communication ID Numbers</td> </tr> </table> | WiFi Location None | Configure WiFi | Ethernet Information | | | GSM Information | Communication Status | Test Communication | Setup Communication Communication ID Numbers |
| WiFi Location None | Configure WiFi | Ethernet Information | | | | | | | | |
| | | GSM Information | | | | | | | | |
| Communication Status | Test Communication | Setup Communication Communication ID Numbers | | | | | | | | |
| Setup Communication | <p>2. Select "Setup Communication". The System advances to the Registration screen and the following options are displayed:</p> <table border="0" style="width: 100%; text-align: center;"> <tr> <td style="width: 50%;">Register Device</td> <td style="width: 50%;">Register Device With PIN</td> </tr> <tr> <td>Update Server</td> <td>Factory Defaults</td> </tr> </table> <p>3. Select "Update Server" and select "Yes" when the confirmation screen appears. The device uploads its entire configuration file to the server. Selecting "No" will cancel the operation. (Refer to the table below for applicable registration messages.)</p> | Register Device | Register Device With PIN | Update Server | Factory Defaults | | | | | |
| Register Device | Register Device With PIN | | | | | | | | | |
| Update Server | Factory Defaults | | | | | | | | | |

During the upload process the following messages may be displayed:

| Message | Meaning |
|-------------------------------------|---|
| Updating Root File... | The root file is being uploaded. |
| Programming Done | Indicates the root file has been successfully uploaded. |
| Updating Configuration – Try Later! | Error message indicates the module is busy |
| Cannot Upload – Try Later! | Error message indicates the communication path(s) is not available. |
| Update Root File – Failed! | Error message indicates an error while uploading root file. |

Enroll the L5100-WiFi Module

The module can be enrolled using one of the following procedures:

- Scan Access Points
- Manual Configure Access Points
- WPS (If available)

| SCREEN | ACTION | | | | | | | | | |
|------------------------------|---|---|-------------------|-------------------------|--|--|--------------------|-------------------------|-----------------------|---|
| Comm. Diagnostics | <p>1. Select "Comm. Diagnostics" The System displays the following options depending upon the communication device that is installed:</p> <table border="0" style="width: 100%; text-align: center;"> <tr> <td style="width: 33%;">WiFi Location None</td> <td style="width: 33%;">Configure WiFi</td> <td style="width: 33%;">Ethernet Information</td> </tr> <tr> <td></td> <td></td> <td style="text-align: center;">GSM Information</td> </tr> </table> <p>Use the down ▼ arrow to scroll to the next page of options. Use the ▲ arrow to return to the previous page:</p> <table border="0" style="width: 100%; text-align: center;"> <tr> <td style="width: 33%;">Communication Status</td> <td style="width: 33%;">Test Communication</td> <td style="width: 33%;">Setup Communication Communication ID Numbers</td> </tr> </table> | WiFi Location None | Configure WiFi | Ethernet Information | | | GSM Information | Communication Status | Test Communication | Setup Communication Communication ID Numbers |
| WiFi Location None | Configure WiFi | Ethernet Information | | | | | | | | |
| | | GSM Information | | | | | | | | |
| Communication Status | Test Communication | Setup Communication Communication ID Numbers | | | | | | | | |

Programming the Control


| SCREEN | ACTION |
|------------------------------|--|
| WiFi Location None | 2. Select "WiFi Location". The System will scroll between "None" and "Speaker Side". After selecting "Speaker Side", the "Configure WiFi" option will be displayed. 3. Select "Configure WiFi". The following options will be displayed: Scan Access Points Manually Configure AP WPS* |

* If available

Enroll using Scan Access Points

Note: If the preferred access point is not available after scanning, manually select the network via the "Manually Configure Access Points" procedure.

1. Select "Scan Access Points". The available networks and signal strength are displayed. Use the down ▼ arrow to scroll to the next page of options. Use the ▲ arrow to return to the previous page.




2. Select the desired Network and then press the "Edit" button. The network information is displayed. Select the "Join" button. A confirmation screen will be displayed.
3. Select "OK", then select "Save" to confirm the selection.
4. Select the "↶" button two times. The Ethernet information will be displayed. Signal strength will be indicated by a series of colored bars along with the RSSI level (in dBm).

| Bars | Meaning | RSSI range (dBm) |
|-------------------|---------------|------------------------|
| 4 White | No connection | -255 (used internally) |
| 1 Yellow, 3 White | Weak | -81 or higher |
| 2 Yellow, 2 White | Fair | -71 to -80 |
| 3 Yellow, 1 White | Good | -51 to -70 |
| 4 Yellow | Excellent | -50 or less |

Manually Configure Access Points

Note: For WEP Security type, the LYNX Touch supports the Key Index 1 in open system authentication mode.

1. Select "Manually Configure AP", the following screen is displayed.



2. Select "SSID Name" and then enter a name (not to exceed 31 characters) on the displayed keyboard.
3. Select "Security". The system scrolls between the following options:
 Open
 WPA1
 WPA2
 WEP* When configuring for WEP encryption key on the access point, always use hexa-decimal type as the input method.
4. Select "Network Type". The system scrolls between "Infrastructure" and "Ad-Hoc".

Programming the Control

5. Select "DHCP". The system scrolls between "Yes" and "No". If "No" is selected the "Static" button is displayed.
Note: When entering a password, up to 31 characters can be entered. The system will only display the first 22 characters but will accept up to 31.
6. If a password is required, select "Key" and enter the password.
7. Select the "Static" button and go to step 8.
8. Select each of the following and enter the required information on the displayed keyboard:
 IP Address (Enter the 4-part address)
 Subnet Mask (Enter the 4-part address)
 Gateway IP Address (Enter the 4-part address)
 DNS Server IP Address (Enter the 4-part address)
9. Select "Save" when complete. Pressing "Save" will cause the panel to automatically attempt to join the configured access point every time the system is powered up.
10. Select "Join" when ready to connect with the access point. If the panel joins the access point successfully, it will automatically attempt to join this access point again on power up.

WiFi Protected Set-up (WPS) (If available)

Note: For WPS operation, press the WPS button on the access point first. Then press the WPS button within 2 minutes

1. Select "WPS", the system displays "Please Stand-by for WPS Operation...".
2. If the operation is successful the system displays "Device has been successfully added to the network." Select "OK".
3. If the operation is unsuccessful the system displays "Failed Operation. Device not added to the network." Select "OK".

Factory Defaults

This procedure resets the programming options to factory-default values.

| SCREEN | ACTION | | | | | | |
|--|---|---|--|---|-------------------------|-----------------------|---|
| Comm. Diagnostics | 1. Select "Comm. Diagnostics" The System displays the following options depending upon the communication device that is installed: <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 33%; text-align: center;">WiFi Location None</td> <td style="width: 33%; text-align: center;">Configure WiFi</td> <td style="width: 33%; text-align: center;">Ethernet Information GSM Information</td> </tr> </table> Use the down ▼ arrow to scroll to the next page of options. Use the ▲ arrow to return to the previous page: <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 33%; text-align: center;">Communication Status</td> <td style="width: 33%; text-align: center;">Test Communication</td> <td style="width: 33%; text-align: center;">Setup Communication Communication ID Numbers</td> </tr> </table> | WiFi Location None | Configure WiFi | Ethernet Information GSM Information | Communication Status | Test Communication | Setup Communication Communication ID Numbers |
| WiFi Location None | Configure WiFi | Ethernet Information GSM Information | | | | | |
| Communication Status | Test Communication | Setup Communication Communication ID Numbers | | | | | |
| Setup Communication | 2. Select "Setup Communication". The System advances to the Registration screen and the following options are displayed: <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; text-align: center;">Register Device Update Server</td> <td style="width: 50%; text-align: center;">Register Device With PIN Factory Defaults</td> </tr> </table> 3. Select "Factory Defaults" and select "Yes" when the confirmation screen appears. The device is reset to factory default values. Selecting "No" will cancel the operation. (Refer to the table below for applicable registration messages.) | Register Device Update Server | Register Device With PIN Factory Defaults | | | | |
| Register Device Update Server | Register Device With PIN Factory Defaults | | | | | | |

The following messages may be displayed:

| Message | Meaning |
|--|---|
| Default Configuration – Successful! | Indicates all programmed values are reset to the original factory settings. |
| Default Configuration Failed – Access Denied | Error message indicates the device does not have local programming access. |
| Default Configuration – Try Later! | Error message indicates the module is busy. |

Remote Programming/Control (Downloading)

General Information

The control panel can be remotely programmed from an IBM-compatible Personal Computer (PC), Compass Downloader, a HAYES compatible Modem or via a capable GSM or IP Communications Module. When connected to the COMPASS Downloader – “SERVICE UPDATE” appears on touch screen.

UL Downloading may only be performed if a technician is at the site.

Multiple security levels protect remote programming against compromise by attempts to defeat the system.

- 1. Security Code Handshake:** A download ID code is verified for authenticity before connection is established.
- 2. Site-Initiated Remote Programming:** The installer initiates downloading by selecting the “Initiate Download” button on the Installer programming screen.
- 3. Station-Initiated Remote Programming:** The operator calls the site from your office to initiate the download call. The Control hangs up and then calls back the PC via the preprogrammed telephone number. The unit can then be uploaded, downloaded, or controlled from your office.
- 4. Data Encryption:** Data passed between the PC and the Control is encrypted for security so that it is very difficult for a foreign device tapped into the phone line to take over communication and substitute system-compromising information.

Equipment required to download to a system at the premises

- Compass Downloader for Windows (at revision level supporting LYNX Touch).

Flexible Callback: If enabled in Installer Programming, the download operator can temporarily change the last 1, 2, or 3 digits (depending on selection) of the call back number. This allows the control to call back a computer other than the one programmed, which may be helpful at times of high computer traffic.

Remote Programming Information



If using Remote Programming, the LYNX Touch must be connected to the telephone line, GSM Cellular or to the Internet, as applicable.

The downloading system can perform many functions when in communication with the Control. Besides uploading and downloading, the status of the system can be observed and various commands can be initiated, as follows:

- Arm the system in the away mode; disarm the system.
- Bypass a zone.
- Force the system to accept a new program download.
- Shut down communication functions (for nonpayment of monitoring fees in an owned system).
- Shut down all security system functions (for nonpayment for a leased system).
- Inhibit local keypad programming (prevents account takeover).
- Command the system to upload a copy of its resident program to the office.
- Set the time
- View/Modify
- Read: arming status, AC power status, lists of faulted zones, bypassed zones, zones currently in alarm, zones currently in trouble, and RF sensors with low battery conditions; read control’s time.

- Notes:**
- (1) After the control and the PC have established valid communication, “Service Update” will be displayed on the LCD.
 - (2) The detailed operation of the download functions is covered in the installation instructions for the Compass Downloader for Windows.

Remote Programming/Control (Downloading)

Remote Programming Advisory Notes

- A copy of the program downloaded may be printed using the IBM PC-compatible computer's internal report generator, when an optional printer is connected (consult your PC manual for proper printer and connections).
- The approximate time for program upload or download for a complete program is shown below:

| Communication Method | Approximate Time |
|-----------------------------|-------------------------|
| PSTN | 380 secs. |
| GSM | 75 secs. |
| IP or WiFi | 30 secs. |

System Operation

Key/Touchscreen Operation

The keys and touchscreen allows the user to arm and disarm the system, and perform other system functions, such as bypassing zones. Zone and system conditions (ALARM, trouble, bypass) are displayed on the display. When an alarm occurs, console sounding and external sounding will occur, and the zone(s) in alarm will be displayed on the display. Pressing any key will silence the keypad sounder for 10 seconds (only once). Disarming the system will silence both console and external sounders. When the system is disarmed, any zones that were in an alarm condition during the armed period will be displayed (memory of alarm). To clear this display, simply repeat the disarm sequence by pressing the OFF key and entering the Security Code. The console also features chime annunciation, and three panic key icons for silent, audible, fire or personal emergency alarms. These keys can notify the central station of an alarm condition, if that service is connected.

Panic Key/Icons

There are three panic key icons that, if programmed, are displayed on the virtual keypad when the “PANIC” key is depressed for four seconds. The panic key screen will timeout if a selection is not made within ten seconds. The keys can be used to manually initiate alarms and send a report to the central station. Each can be individually programmed for 24-hour silent, audible, personal or fire emergency responses. The panic function is activated when the respective keys is pressed. The panic functions are identified by the system as follows:

| Zone | Function |
|------|-------------------|
| 95 | Fire Emergency |
| 96 | Medical Emergency |
| 99 | Police Emergency |

Important: For the silent panic functions to be of practical value, the system must be connected to a central station.

Security Codes

Installer Code



The installer programs the 4-digit Installer Code initially as part of the programming procedure. The factory default Installer Code is **4-1-1-2**, but may be changed in the Installer Code programming field. The Installer Code is the only code that allows entry into Installer Programming mode.

Master Code

In normal operation mode, the Master Code is used to enter the 4-digit User Security Codes.

Enter/Change the Master Code by installer.

The factory default Master Code for the LYNX Touch Control is set to 1-2-3-4. The Master Code is used to enter the 4-digit User Security Codes.

| SCREEN | ACTION |
|---|--|
|  | <ol style="list-style-type: none"> After entering the User Tools/Programming Menu, select the “Users” icon on the User Menu screen. The system displays the User Code Programming screen |
|  | <ol style="list-style-type: none"> Select “Master”, then select “Edit”. Enter a new four-digit Master Code on the displayed keypad The system will display the new code on the left side of the screen. Select “Done” when you are finished. The system returns to the User Code Programming screen. |

Secondary User Codes

In normal operation mode, the Master Security Code can be used to assign up to 14 secondary 4-digit security codes, including a Babysitter Code and a Duress Code. The Master Code can also be used to remove secondary codes from the system (individually). Refer to the LYNX Touch User Manual for additional information.

Reset Master User Code

1. After Entering the Installer Programming Mode, select “Reset Master Code” from the second page of the Installer Programming Tools menu.
2. The system displays a confirmation screen. Select the “Yes” key to reset the Master User Code to “1234”.
3. If confirmed, the Master Code will be reset back to “1-2-3-4”. This will be logged in the System Event Log as “Reset Master Code User 2 E655”. The system returns to the second page of the Installer Programming Tools menu. OR

If the reset failed, the system will display: “Command Failed. Unable to Reset Master Code”.

Security Code Notes

- The Master and Secondary security codes permit access to the system for arming, disarming, etc.
- The Installer Code can disarm the system only if it was used to arm it. In addition, the Installer Code cannot disarm the system if it was armed by pressing and holding a Quick-Arm button.
- The Babysitter Code can disarm the system only if it was used to arm it. In addition, the Babysitter Code cannot disarm the system if it was armed by pressing and holding a Quick-Arm button.
- Duress code sends a special code to the monitoring station when used to perform any system operation. Instruct users to be careful not to use this code for normal usage.
- Opening/closing reports are sent for the Installer Code, with the appropriate subscriber number. Master Code and set of secondary user codes are sent as Nos. 02 and 03–14, respectively, in Contact ID® format (with the appropriate user number).

System Operation

“Follow Me” System Announcement Feature

This feature allows the LYNX Touch to deliver a voice system message to the user phone numbers programmed by the installer. The LYNX Touch will first transmit reports to the Central Station and after receiving its kiss-off the system will dial the user phone numbers and begin transmitting the welcome message “System Message, Press Star to Play”. The system will dial the user phone numbers a maximum of eight times.

The “Follow Me” System announcements feature is only supported if PSTN line is available. The announcements are individually sent to the phone, numbers which are programmed as Phone 1 and Phone 2 respectively in the Reporter Programming section. System Follow Me announcements are triggered by a system event that belongs to one of the Event Groups enabled by Installer individually for the programmed phone number(s). The groups are listed below.

- All Bypassing actions by a user
- Any Open/Close (arming/disarming status changes)
- Any Alarms
- Any Alarm Restores
- Alarm Cancel by the user
- Any System Troubles
- Any Test
- Non-security Events

If a “*” key is not pressed, LYNX Touch will announce “System message Press * to Play” for 45 seconds before hanging up and redialing the programmed number. The control will make eight attempts before unsuccessfully ending the System “Follow Me” session and erasing all the events in the queue. The next call will be triggered by a new event from the Event Group enabled for the programmed number(s).

If a “*” key is pressed, LYNX Touch will play back a sequence of System “Follow Me” announcements from the queue in chronological order starting with the oldest one. The announcements will include “End of Message” at the end of the “Follow Me” announcements.

If a “*” key is pressed again during playback or within 15 seconds following the end of the playback, the control will repeat the sequence. Otherwise the system will hang up, successfully ending the System “Follow Me” session. Because the “*” key was pressed LYNX Touch will not redial the number again. The next call will be triggered by a new event from the Event Group enabled for the programmed number(s).

Note: The follow me system announcement will be terminated if any other event requires the system to send a report to the Central Station. Once the PSTN line is available the session will be resumed and the control will again make up to 8 delivery attempts.

| Follow Me Event Triggers | Follow Me Announcement |
|---------------------------------|------------------------|
| AC Loss | AC Loss |
| Audible Panic | Panic Alarm |
| Automatic Disarmed | Disarmed |
| Battery Failed Under Load | System Low Battery |
| Burglary Zone Bypass | Zone ** Bypassed |
| Carbon Monoxide Detected | Carbon Monoxide Alarm |
| Disarmed From AWAY or STAY | Disarmed |
| Emergency Alarm | Emergency Alarm |
| Entry/Exit Alarm | Perimeter Alarm |
| Exit Error Alarm (zone) | Perimeter Alarm |
| Expansion Module Tamper | Tamper Alarm |
| Expansion Module Failure | System Trouble |
| Expansion Module Tamper Alarm | Tamper Alarm |
| Expansion Module Tamper Trouble | Tamper Alarm |
| Fire Alarm | Fire Alarm |
| Fire Trouble | System Trouble |

| Follow Me Event Triggers | Follow Me Announcement |
|------------------------------|------------------------|
| Interior Alarm | Interior Alarm |
| Keypad Panic | Panic Alarm |
| Manual Test | System Test |
| Medical Alarm | Emergency Alarm |
| Perimeter Alarm | Perimeter Alarm |
| Remote Disarm | Disarmed |
| RF Sensor Lost | System Trouble |
| Sensor Low Battery or Tamper | Sensor Trouble |
| Silent Burglary | Silent Burglary |
| Siren Tamper | Tamper Alarm |
| System Inactivity | No Check In |
| System Low Battery | System Low Battery |
| Water Leakage Alarm | Auxiliary Alarm |
| Zone Bypass | Zone ** Bypassed |
| Zone Tamper (Alarm) | Tamper Alarm |
| Zone Trouble | System Trouble |

** = Zone Number

“Follow Me” Reminder Feature

This feature allows the user to schedule a time driven message. When activated, the system will dial the User 1 and/or User 2 phone numbers, which are programmed as Phone 1 and Phone 2 respectively by the installer (in the Reporter Programming section), and deliver a recorded message. The LYNX Touch will immediately begin transmitting the voice message and will repeat the message for 45 seconds. If the message has timed out, the system will redial the programmed number a maximum of seven additional times or until it is acknowledged. Pressing any key on the LYNX Touch keypad will terminate both the “Follow Me” reminder and the local reminder announcements.

- Notes:**
- (1) This feature is only supported if it has been programmed.
 - (2) The follow me reminder will be terminated if any other event requires the system to dial out, however, delivery of the local schedule reminder message will continue.
 - (3) If a Central Station report must be sent, the “Follow Me” Reminder message will be suspended. Once the PSTN line is available the session will be resumed and the control will again make up to 8 delivery attempts.

Remote Phone Control Feature

The remote phone control feature, which must be enabled, allows the user to access the security system from any off-site touch-tone telephone. The control will pick up the incoming call, based on the specified ring count, and will announce “SYSTEM ENTER CODE” every three seconds for the next nine seconds. During this period the panel will wait for a valid User Code to be entered. If a valid User Code is not entered or the nine second period expires a modem tone will be generated for remote programming (Compass Downloading). If a valid User Code has been entered, the control will announce the current system status and/or beeping sounds. Refer to the User Guide for additional information regarding this feature.

System Operation

System Displays

The following icons will be displayed on the Home screen along with specific zone status information (if applicable) to indicate system status.

| DISPLAY | DEFINITION |
|---------|---------------------------|
| | AC Loss |
| | Alarm (intrusion) |
| | Armed Away |
| | Armed Stay |
| | Battery Low |
| | Check Zones |
| | CO Alarm |
| | Disarmed Not Ready to Arm |
| | Disarmed Ready to Arm |
| | 90 RF Jam |
| | 94 Phone Line Cut |
| | 103 Comm. Trouble |

| DISPLAY | DEFINITION |
|---------|----------------------------------|
| | Door Open |
| | Window Open |
| | Exit Active |
| | Fire OR Heat Sensor |
| | Flood |
| | Glass Break |
| | Medical Alarm |
| | Motion |
| | Temperature |
| | Cover Tamper |
| | Reporter Failure |
| | Automation (Z-Wave Node Failure) |

| DISPLAY | DEFINITION |
|---------|---------------------|
| | Fault * Garage Door |
| | WiFi source present |
| | No WiFi source |

Zone Status Displays

The following icons will be displayed on the Zone Status screen along with specific zone status information when a zone has been Faulted, Bypassed or in Alarm.

| DISPLAY | DEFINITION |
|---------|----------------|
| | Alarm |
| | Fault (Yellow) |

| DISPLAY | DEFINITION |
|---------|---------------|
| | Ready |
| | Trouble (red) |

| DISPLAY | DEFINITION |
|---------|------------|
| | Bypass |

UL Audio alarm verification has not been evaluated by UL.

Audio Alarm Verification (Two-Way Voice Feature)

This feature allows the central station operator to listen, talk to or conduct a two-way conversation with an individual(s) at the premises. It also assists the operator in gathering information about the nature and location of the alarm that may be helpful in responding to police and fire departments. All LYNX Touch control panels are capable of supporting the Two-Way Voice feature. The LYNX Touch does not make system announcements when the Two-Way voice feature is active.

Activation



Fire and CO alarms will prevent the LYNX Touch from starting an AAV session. A new Fire or CO alarm will end an AAV session that is in progress.

The LYNX Touch sends the “alarm message” followed by a “Listen-in-to-Follow message” (Contact ID® code 606) to the Central Station. The Listen-in-to-Follow message causes the Central Station’s digital receiver to temporarily hold the phone line for approximately 1-minute. When the LYNX Touch receives the “kissoff” from the central station, indicating that the alarm message has been received, the Two-Way Voice (AAV) feature is activated in the (default) “Listen Mode” and sirens and keypad sounds are discontinued. The LYNX Touch transmits a beep acknowledgment to the Central Station, once per second. The beep alternates between two tones and indicates that the LYNX Touch is waiting for a session command from the Central Station operator. Once a command is issued the beep acknowledgement is discontinued, however, if a command is not issued within two minutes the system will “time out” and the call will be terminated.

Operator Commands

The Central Station operator begins the session, which last 5 minutes, by entering one of the valid AAV commands shown in the table below. The session may be extended 5 minutes, without changing the operating mode, by pressing the [7] key on the touch-tone phone. Selecting another operating mode also resets the session an additional 5 minutes. During the last minute of the 5 minute, session, the LYNX Touch generates two beeps every 30 seconds to alert the Central Station operator that the session is about to time out. The Central Station operator may then extend the session by pressing the [7] key on the touch-tone phone. If the session is not extended the phone line is disconnected, and the session is ended. Sessions may be ended at any time by pressing the [9] key on the touch-tone phone. The AAV modes are described as follows:

Note: When entering AAV commands make sure the Central Station receiver has been disconnected from the phone line, otherwise AAV commands may not go through.

| Key | Function |
|-----|--|
| 1 | Talk Mode: Pressing the [1] key on the touch tone phone, enables one-way voice communication from the central station to the violated premises, and allows the operator to talk communicate through the LYNX Touch speaker. In this mode the Red (Armed) and Green (Ready) LEDs blink alternately. |
| 2 | VOX (Voice) Mode: Pressing the [2] key on the touch-tone phone, enables two-way voice communications between the central station and the violated premises. In this mode the Red (Armed) and Green (Ready) LEDs blink alternately. |
| 3 | Listen Mode: Pressing the [3] key on the touch-tone phone, enables one-way audio from the violated premises to the central station. The Listen Mode is the start up default mode of the voice feature and allows the operator to listen through the LYNX Touch microphone. This mode does not affect the existing LED pattern. |
| 7 | Extends the session 5 minutes without changing its operating mode. |
| 9 | Ends the session and disconnects the phone line. |

System Operation

Event Log

The LYNX Touch Series event log is capable of recording and displaying up to 128 system events. The type of events that can be recorded is selectable and is programmed in the System Type programming field. The event log can be reviewed by entering the Installer Programming or Master User Programming mode. Refer to the LYNX Touch Series User Manual for additional information.

Note: In the unlikely condition that the backup battery becomes fully discharged when AC power is lost, any system activity performed after the low battery notification will not be saved in the event log. Additionally, the panel will revert to the status condition as before the low battery notification.

Contact ID® & SIA Event Log Codes

| CID Code | Definition |
|----------|---|
| 110 | Alarm, Fire |
| 121 | Alarm, Duress |
| 122 | Alarm, Silent |
| 123 | Alarm, Audible |
| 131 | Alarm, Perimeter |
| 132 | Alarm, Interior |
| 134 | Alarm, Entry/Exit |
| 135 | Alarm, Day/Night |
| 137 | Alarm, Tamper |
| 145 | Expansion Module Tamper |
| 146 | Silent Burglary |
| 150 | 24-Hour Non-Burglary |
| 162 | Carbon Monoxide Detected |
| 301 | Trouble, AC Loss |
| 302 | Trouble, Low System Battery |
| 305 | Trouble, System Reset |
| 316 | System Tamper* |
| 341 | Trouble, Case Tamper |
| 344 | Trouble, RF Receiver Jam Detect |
| 351 | Trouble, Telco 1 Fault |
| 353 | Trouble, Long Range Radio Transmitter Fault |
| 373 | Trouble, Fire Trouble |
| 374 | Trouble, Exit Error Alarm |
| 380 | Trouble, Sensor |
| 381 | Trouble, Loss of Supervision RF |
| 383 | Trouble, Sensor Tamper |
| 384 | RF Low Battery |
| 401 | Open/Close by User |
| 403 | Open/Close Automatic |
| 406 | Cancel |
| 407 | Remote Arm/Disarm |
| 408 | Quick Arm |
| 441 | Armed Stay |
| 455 | Auto-Arm Failed |
| 459 | Recent Close |
| 570 | Zone/Sensor Bypass |
| 601 | Manual Trigger Test Report |
| 602 | Periodic Test Report |
| 606 | Listen-in to follow |
| 607 | Walk Test |
| 623 | Event 90% Full |
| 627 | Program Mode Entry (Logged in Event Log Only) |
| 628 | Program Mode Exit (Logged in Event Log Only) |
| 654 | System Inactivity |
| 655 | Reset Master Code (Logged in Event Log Only) |
| 759 | Resident Monitor Zone Response |
| 760 | Resident Response Zone Response |
| 761 | General Monitor Zone Response |
| 762 | General Response Zone Response |

| SIA Code | Definition |
|----------|--|
| AT/AR | AC Trouble/AC Restoral |
| BA/BR | Burglary Alarm/Burglary Restoral |
| CA/CD | Automatic Closing/Closing Delinquent |
| CI | Fail to Close (Log only) |
| CL | Closing Report |
| CQ | Remote Closing |
| CR | Recent Closing |
| DF/DR | Door Forced/Door Restoral |
| EA | Exit Alarm |
| ES/EJ | Expansion Device Tamper/Expansion Tamper Restore |
| ET | Expansion Trouble |
| FA | Fire Alarm |
| FT/FJ | Fire Trouble/Fire Trouble Restore |
| HA/HR | Holdup Alarm/Holdup Restoral |
| GA/GR | Gas Alarm/Gas Restoral |
| FT/FJ | Fire Trouble/Fire Trouble Restore |
| LT/LR | Phone Line Trouble/Phone Line Restoral |
| OA | Automatic Opening |
| OC | Cancel Report |
| OP | Opening Report |
| OQ | Remote Opening |
| PA | Panic Alarm |
| RP | Automatic Test |
| RX | Manual Test |
| TA/TH | Tamper Alarm/Tamper Alarm Restore |
| TJ | Tamper Trouble Restore |
| TS/TE | Test Start/Test End |
| TT | Tamper Trouble |
| UA | Untyped Zone Alarm |
| UB/UU | Untyped Zone Bypass/Untyped Zone Unbypass |
| UT/UJ | Untyped Zone Trouble/Restore |
| XG/XH | RF Interference/RF Interference Restore |
| XT/XR | Transmitter Battery Trouble/Transmitter Battery Restoral |
| YT/YR | System Battery Trouble/System Battery Restoral |

*If APL is enabled, AlarmNet will generate a special comm. fail message (E316) if it does not hear from a unit within 15 minutes after a delayed alarm is delivered. This message is meant to alert the Central Station that the system has been tampered with and may have been compromised.

Central Station Messages

The following messages are sent by the L5100 communications modules (GSMVLP5-4G/GSMVLP5CN4G, ILP5 and L5100-WiFi) for the conditions listed below.

| Alarm Condition | Alarm Code | Restore Code |
|--|-------------------|---------------------|
| Power On / Reset | E339 C0803 | |
| Primary Communication Path Supervision | E350 C0951 | R350 C0951 |
| Secondary Communication Path Supervision | E350 C0952 | R350 C0952 |
| Test | 5555 5555 9 | |

The control panel sends its own general code (E353) for a trouble condition. The Control panel sends tamper trouble (E341), tamper alarm (E145), power loss (E301) and low battery (E302) messages.

Testing the System

TO THE INSTALLER

Regular maintenance and inspection (at least annually) by the installer and frequent testing by the user are vital to continuous satisfactory operation of any alarm system.

The installer should assume the responsibility of developing and offering a regular maintenance program to the user as well as acquainting the user with the proper operation and limitations of the alarm system and its component parts. Recommendations must be included for a specific program of frequent testing (at least weekly) to ensure the system's proper operation at all times.

Test Modes

The "Test" button provides access to the following functions and test modes:

| Option | Function |
|-----------------|--|
| Walk Test | Refer to the User Manual for additional information |
| RF Sniffer Test | Refer to the <i>Installing Wireless Zones</i> section of this manual for additional information. |
| Go-No-Go Test | Refer to the <i>Installing Wireless Zones</i> section of this manual for additional information. |
| Dialer Test | Refer to the to the paragraph in this section and the User Manual for additional information |
| Zone Discovery | Provides access to the Zone Discovery. Refer to the paragraph in this section for additional information regarding the Zone Discovery feature. |
| Diagnostics | Provides access to the Reboot Feature. Refer to the paragraph in this section for additional information regarding the Reboot feature. |

Testing the System

After installation is completed, the security system should be carefully tested, as follows:

1. With the system in the disarmed state, check that all zones are intact. If the "ready" LED is not lit, select the Zones icon to display the faulted zone(s). If necessary, restore faulted zone(s) so that the "ready" LED lights. Fault and restore every sensor individually to assure that it is being monitored by the system.

Armed System Test

Alarm messages will be sent to the central station during the following tests 1 and 2. **Notify the Central Station in advance that tests will be in progress.**

1. Arm the system and fault one or more zones. After 15 seconds (if optional dialer delay is selected), silence alarm sounder(s) by pressing OFF and entering the security code. Check entry/exit delay zones.
2. Check the keypad-initiated alarms that are in the system by selecting the Panic key. If the system has been programmed for audible emergency, the keypad will emit a steady alarm sound, and "ALARM" and zone number will be displayed. For LYNX Touch, silence the alarm pressing OFF and entering the Security Code. For LYNX Touch SIA configuration, silence the alarm by entering the Security Code.

If the system has been programmed for silent emergency, there will be no audible alarms or displays, but a report will be sent to the central station.

3. Notify the central station when all tests are finished, and verify results with them.
4. To test the wireless part of the system and the RF receiver, perform the two additional tests described in the *Installing Wireless Zones* section: Sniffer mode and Go/No Go Test.

Note: System Test mode and Go/No Go Test will be automatically terminated after 3-1/2 to 4 hours if the installer or user does not manually terminate it. This ensures that fire and panic zones will not remain disabled. However, Sniffer mode does not automatically expire. You must manually exit (by entering an OFF Sequence) Sniffer mode to return to normal operation. During the final 5 minutes the system will emit double beeps indicating that the end of Test mode is nearing.

Dialer Test

The Dialer Test checks that the phone connection to the central station is working properly. **Notify the Central Station in advance that tests will be in progress.**

1. With the System in the Installer Programming mode, select the "Test" button and then select the "Dialer Test" button.

Testing the System

2. If the test is successful the system will send the Manual Trigger Test Report (E601) to the Central Station. The test will not be recorded in the Event Log.
3. The system will make eight attempts to test the dialer for the Primary and eight attempts to test the Secondary Central Station. If the test is unsuccessful the system will display a “Reporter Failure” trouble message after 9-17 minutes.

Zone Discovery Mode



Zone Discovery mode requires Installer supervision when in use. The system is not fully operational for fire or life safety while Zone Discovery Mode is active.

Zone discovery mode can be used to remotely view all zones that have been programmed in the system for operation. The zones must have a response type programmed and in the case of RF zones, must also have a serial number programmed. All zones programmed (except for duress) will be displayed.

Enter Zone Discovery

1. With the System in the Installer Programming mode, select the “Test” button and then select the “Zone Discovery” button. The “Zone Discovery” button will be highlighted indicating that the mode is active.

Exit Zone Discovery

1. Enter an Off sequence. If you do not exit zone discovery mode manually, the system will automatically exit zone discovery mode in approximately 1-4 minutes dependent upon the number of zones that are programmed. The system beeps once and returns to the home screen.

Rebooting the System

The Reboot function allows you to restart the system if required. To reboot the system perform the following:

1. With the System in the Installer Programming mode, select the “Test” button and then select the “Diagnostics” button.
2. The system advances to the next screen. Select the “Reboot” button. A confirmation screen will appear.
3. Select “Yes”. The system will restart.

Note: After the reboot sequence is complete it is recommended that you perform a “Walk Test” to verify that all transmitters are operational in the system.

LYNX Touch Programming Default Values

| Program Function | Configuration 1 | Configuration 2 | Configuration 3 | Configuration 4 |
|-------------------------|-------------------------------------|---------------------|---------------------|---------------------|
| Installer Code | 4112 | 4112 | 4112 | 4112 |
| System Type | | | | |
| RF Jam | Disabled | Disabled | Disabled | Disabled |
| Speaker Phone | Enabled | Enabled | Enabled | Enabled |
| Two Way Voice | Disabled | Disabled | Disabled | Disabled |
| RF House Code | 0 | 0 | 0 | 0 |
| Phone Notification | Disabled | Disabled | Disabled | Disabled |
| Remote Phone | Enabled | Enabled | Enabled | Enabled |
| Phone Detect Time | 2 Minutes | 2 Minutes | 2 Minutes | 2 Minutes |
| Events - Log All | Press To Log All | Log All Set | Press To Log All | Press To Log All |
| Events - Log Alarm | Enabled | Enabled | Enabled | Enabled |
| Events - Log Bypass | Disabled | Enabled | Disabled | Disabled |
| Events - Log Open/Close | Disabled | Enabled | Disabled | Disabled |
| Events - Log Trouble | Enabled | Enabled | Enabled | Enabled |
| Non Security | Disabled | Enabled | Disabled | Disabled |
| Remote Access Serial | Disabled | Disabled | Disabled | Disabled |
| Multi Mode Serial | Disabled | Disabled | Disabled | Disabled |
| Date Time | | | | |
| Calendar | January 1, 2011 | January 1, 2011 | January 1, 2011 | January 1, 2011 |
| Enter Time | 10:00AM | 10:00AM | 10:00AM | 10:00AM |
| Time Zone | Eastern (EST) | Eastern (EST) | Eastern (EST) | Eastern (EST) |
| Day Light Savings time | Yes | Yes | Yes | Yes |
| Start Month | March | March | March | March |
| Start Week | Second | Second | Second | Second |
| End Month | November | November | November | November |
| End Week | First | First | First | First |
| Communicator | | | | |
| Communications Path | None | None | None | None |
| APL | Disabled | Disabled | Disabled | Disabled |
| City ID | None | None | None | None |
| CS ID | None | None | None | None |
| Sub ID | None | None | None | None |
| Supervision | 24 Hours | 24 Hours | 24 Hours | 24 Hours |
| Old Alarm Time | 10 Minutes | 10 Minutes | 10 Minutes | 10 Minutes |
| Remote Acc. Comm. | Disabled | Disabled | Disabled | Disabled |
| Multi Mode Comm. | Disabled | Disabled | Disabled | Disabled |
| GSM Fault Time | 00 | 00 | 00 | 00 |
| IP Fault Time | 00 | 00 | 00 | 00 |
| Use DHCP | Yes | Yes | Yes | Yes |
| NI IP Address | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 |
| Subnet Mask | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 |
| Gateway IP Address | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 |
| DNS Server IP Address | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 |
| Zones | See Zone Programming Default Values | | | |
| Reporter | | | | |
| Primary CS info | | | | |
| Phone Type | Contact Id: 4 Digit | Contact Id: 4 Digit | Contact Id: 4 Digit | Contact Id: 4 Digit |
| Communicator Type | None | None | None | None |
| Phone Number | Blank | Blank | Blank | Blank |
| Account Number | FFFF | FFFF | FFFF | FFFF |
| Dynamic Priority | None | None | None | None |
| Dynamic Delay | None | None | None | None |
| Report All | Press to Report All | Press to Report All | Press to Report All | Press to Report All |
| Report Alarms | Enabled | Enabled | Enabled | Enabled |
| Report Troubles | Enabled | Enabled | Enabled | Enabled |
| Report Open/Close | Disabled | Disabled | Disabled | Disabled |
| Report Tests | Enabled | Enabled | Enabled | Enabled |

LYNX Touch Programming Default Values

| Program Function | Configuration 1 | Configuration 2 | Configuration 3 | Configuration 4 |
|------------------------|---------------------|---------------------|---------------------|---------------------|
| Secondary CS info | | | | |
| Phone Type | None | None | None | None |
| Communicator Type | None | None | None | None |
| Phone Number | Blank | Blank | Blank | Blank |
| Account Number | FFFF | FFFF | FFFF | FFFF |
| Dynamic Priority | None | None | None | None |
| Dynamic Delay | None | None | None | None |
| Report All | Press to Report All | Press to Report All | Press to Report All | Press to Report All |
| Report Alarms | Enabled | Enabled | Enabled | Enabled |
| Report Troubles | Enabled | Enabled | Enabled | Enabled |
| Report Open/Close | Disabled | Disabled | Disabled | Disabled |
| Report Tests | Enabled | Enabled | Enabled | Enabled |
| Follow Me Phone 1 | | | | |
| Phone Type | None | None | None | None |
| Phone Number | Blank | Blank | Blank | Blank |
| Report All | Press To Report All | Press To Report All | Press To Report All | Press To Report All |
| Report Alarms | Disabled | Disabled | Disabled | Disabled |
| Report Troubles | Disabled | Disabled | Disabled | Disabled |
| Report Open/Close | Disabled | Disabled | Disabled | Disabled |
| Report Tests | Disabled | Disabled | Disabled | Disabled |
| Follow Me Phone 2 | | | | |
| Phone Type | None | None | None | None |
| Phone Number | Blank | Blank | Blank | Blank |
| Report All | Press To Report All | Press To Report All | Press To Report All | Press To Report All |
| Report Alarms | Disabled | Disabled | Disabled | Disabled |
| Report Troubles | Disabled | Disabled | Disabled | Disabled |
| Report Open/Close | Disabled | Disabled | Disabled | Disabled |
| Report Tests | Disabled | Disabled | Disabled | Disabled |
| Report Selection | | | | |
| Arm Away | Enabled | Enabled | Enabled | Enabled |
| Arm Stay | Enabled | Enabled | Enabled | Enabled |
| Disarm | Enabled | Enabled | Enabled | Enabled |
| Exit Error | Enabled | Enabled | Enabled | Enabled |
| Recent Closing | Enabled | Enabled | Enabled | Enabled |
| Event Log Full | Enabled | Enabled | Enabled | Enabled |
| Trouble | Enabled | Enabled | Enabled | Enabled |
| Trouble Restore | Enabled | Enabled | Enabled | Enabled |
| Alarm Restore | Enabled | Enabled | Enabled | Enabled |
| Alarm Cancel | Enabled | Enabled | Enabled | Enabled |
| Test | Enabled | Enabled | Enabled | Enabled |
| Test Restore | Enabled | Enabled | Enabled | Enabled |
| Bypass | Enabled | Enabled | Enabled | Enabled |
| Bypass Restore | Enabled | Enabled | Enabled | Enabled |
| AC Loss | Enabled | Enabled | Enabled | Enabled |
| AC Loss Restore | Enabled | Enabled | Enabled | Enabled |
| Low Battery | Enabled | Enabled | Enabled | Enabled |
| Low Battery Restore | Enabled | Enabled | Enabled | Enabled |
| RF Low Battery | Enabled | Enabled | Enabled | Enabled |
| RF Low Battery Restore | Enabled | Enabled | Enabled | Enabled |
| Options | | | | |
| PBX | Blank | Blank | Blank | Blank |
| Call Wait Cancel | Blank | Blank | Blank | Blank |
| Number of Reports | 2 Reports | 2 Reports | 2 Reports | 2 Reports |
| Alarm Report Delay | 30 Seconds | 30 Seconds | 30 Seconds | 30 Seconds |
| First Report Offset | 6 Hrs | 12 Hrs | 12 Hrs | 12 Hrs |
| Report Frequency | Never | 30 Days | Never | Never |

LYNX Touch Programming Default Values

| Program Function | Configuration 1 | Configuration 2 | Configuration 3 | Configuration 4 |
|--------------------------|-------------------|-------------------|-------------------|-------------------|
| Downloader | | | | |
| Phone Answer | Yes | Yes | Yes | Yes |
| Ans. Machine Defeat | Yes | Yes | Yes | Yes |
| Modem Speed (Future Use) | Slow | Slow | Slow | Slow |
| Ring Counter | 2 | 2 | 2 | 2 |
| Callback Number | Blank | Blank | Blank | Blank |
| Flexible Callback Number | No | No | No | No |
| | 1 | 1 | 1 | 1 |
| Sounder | | | | |
| Burglary Alarm Sound | Yes | Yes | Yes | Yes |
| Burglary Bell Timeout | 4 Minutes | 4 Minutes | 4 Minutes | 4 Minutes |
| Fire Bell Timeout | 4 Minutes | 4 Minutes | 4 Minutes | 4 Minutes |
| Arm Confirm | None | None | None | None |
| System Settings | | | | |
| Entry Delay 1 | 30 Seconds | 30 Seconds | 30 Seconds | 30 Seconds |
| Entry Delay 2 | 30 Seconds | 30 Seconds | 30 Seconds | 30 Seconds |
| Exit Delay | 60 Seconds | 60 Seconds | 60 Seconds | 60 Seconds |
| Backlight Timeout | No | No | No | No |
| Quick Arm | Yes | Yes | Yes | Yes |
| Quick Exit | Yes | Yes | Yes | Yes |
| Restart Exit Time | Yes | Yes | Yes | Yes |
| Force Bypass | No | No | No | No |
| Exit Warning | Yes | Yes | Yes | Yes |
| Auto Stay Arming | Yes | Yes | Yes | Yes |
| Lack Of Usage Notify | Disabled | Disabled | Disabled | Disabled |
| Power-Up In Previous | Yes | Yes | Yes | Yes |
| Display Alarm Cancel | Yes | Yes | Yes | Yes |
| Display Exit Time | Yes | Yes | Yes | Yes |
| Cross Zone Delay | None | None | None | None |
| Cross Zone 1 | Disabled | Disabled | Disabled | Disabled |
| Cross Zone 2 | Disabled | Disabled | Disabled | Disabled |
| Z-Wave | | | | |
| Z-Wave | Enabled-Installed | Enabled-Installed | Enabled-Installed | Enabled-Installed |
| Temperature | Fahrenheit | Fahrenheit | Fahrenheit | Fahrenheit |

LYNX Touch (L5100CN) Canada Programming Default Values

| Program Function | Configuration 1 | Configuration 2 | Configuration 3 | Configuration 4 |
|-------------------------|-------------------------------------|---------------------|---------------------|---------------------|
| Installer Code | 4112 | 4112 | 4112 | 4112 |
| System Type | | | | |
| RF Jam | Disabled | Disabled | Disabled | Disabled |
| Speaker Phone | Enabled | Enabled | Enabled | Enabled |
| Two Way Voice | Disabled | Disabled | Disabled | Disabled |
| RF House Code | 0 | 0 | 0 | 0 |
| Phone Notification | Disabled | Disabled | Disabled | Disabled |
| Remote Phone | Enabled | Enabled | Enabled | Enabled |
| Phone Detect Time | 2 Minutes | 2 Minutes | 2 Minutes | 2 Minutes |
| Events - Log All | Press To Log All | Log All Set | Press To Log All | Press To Log All |
| Events - Log Alarm | Enabled | Enabled | Enabled | Enabled |
| Events - Log Bypass | Disabled | Enabled | Disabled | Disabled |
| Events - Log Open/Close | Disabled | Enabled | Disabled | Disabled |
| Events - Log Trouble | Enabled | Enabled | Enabled | Enabled |
| Non Security | Disabled | Enabled | Disabled | Disabled |
| Remote Access Serial | Disabled | Disabled | Disabled | Disabled |
| Multi Mode Serial | Disabled | Disabled | Disabled | Disabled |
| Date Time | | | | |
| Calendar | January 1, 2011 | January 1, 2011 | January 1, 2011 | January 1, 2011 |
| Enter Time | 10:00AM | 10:00AM | 10:00AM | 10:00AM |
| Time Zone | Eastern (EST) | Eastern (EST) | Eastern (EST) | Eastern (EST) |
| Day Light Savings time | Yes | Yes | Yes | Yes |
| Start Month | March | March | March | March |
| Start Week | Second | Second | Second | Second |
| End Month | November | November | November | November |
| End Week | First | First | First | First |
| Communicator | | | | |
| Communications Path | None | None | None | None |
| APL | Disabled | Disabled | Disabled | Disabled |
| City ID | None | None | None | None |
| CS ID | None | None | None | None |
| Sub ID | None | None | None | None |
| Supervision | 24 Hours | 24 Hours | 24 Hours | 24 Hours |
| Old Alarm Time | 10 Minutes | 10 Minutes | 10 Minutes | 10 Minutes |
| Remote Acc. Comm. | Disabled | Disabled | Disabled | Disabled |
| Multi Mode Comm. | Disabled | Disabled | Disabled | Disabled |
| GSM Fault Time | 00 | 00 | 00 | 00 |
| IP Fault Time | 00 | 00 | 00 | 00 |
| Use DHCP | Yes | Yes | Yes | Yes |
| NI IP Address | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 |
| Subnet Mask | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 |
| Gateway IP Address | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 |
| DNS Server IP Address | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 | 255.255.255.255 |
| Zones | See Zone Programming Default Values | | | |
| Reporter | | | | |
| Primary CS Info | | | | |
| Phone Type | Contact Id: 4 Digit | Contact Id: 4 Digit | Contact Id: 4 Digit | Contact Id: 4 Digit |
| Communicator Type | None | None | None | None |
| Phone Number | Blank | Blank | Blank | Blank |
| Account Number | FFFF | FFFF | FFFF | FFFF |
| Dynamic Priority | None | None | None | None |
| Dynamic Delay | None | None | None | None |
| Report All | Press to Report All | Press to Report All | Press to Report All | Press to Report All |
| Report Alarms | Enabled | Enabled | Enabled | Enabled |
| Report Troubles | Enabled | Enabled | Enabled | Enabled |
| Report Open/Close | Disabled | Disabled | Disabled | Disabled |
| Report Tests | Enabled | Enabled | Enabled | Enabled |

LYNX Touch (L5100CN) Canada Programming Default Values

| Program Function | Configuration 1 | Configuration 2 | Configuration 3 | Configuration 4 |
|--------------------------|---------------------|---------------------|---------------------|---------------------|
| Secondary CS Info | | | | |
| Phone Type | None | None | None | None |
| Communicator Type | None | None | None | None |
| Phone Number | Blank | Blank | Blank | Blank |
| Account Number | FFFF | FFFF | FFFF | FFFF |
| Dynamic Priority | None | None | None | None |
| Dynamic Delay | None | None | None | None |
| Report All | Press to Report All | Press to Report All | Press to Report All | Press to Report All |
| Report Alarms | Enabled | Enabled | Enabled | Enabled |
| Report Troubles | Enabled | Enabled | Enabled | Enabled |
| Report Open/Close | Disabled | Disabled | Disabled | Disabled |
| Report Tests | Enabled | Enabled | Enabled | Enabled |
| Follow Me Phone 1 | | | | |
| Phone Type | None | None | None | None |
| Phone Number | Blank | Blank | Blank | Blank |
| Report All | Press To Report All | Press To Report All | Press To Report All | Press To Report All |
| Report Alarms | Disabled | Disabled | Disabled | Disabled |
| Report Troubles | Disabled | Disabled | Disabled | Disabled |
| Report Open/Close | Disabled | Disabled | Disabled | Disabled |
| Report Tests | Disabled | Disabled | Disabled | Disabled |
| Follow Me Phone 2 | | | | |
| Phone Type | None | None | None | None |
| Phone Number | Blank | Blank | Blank | Blank |
| Report All | Press To Report All | Press To Report All | Press To Report All | Press To Report All |
| Report Alarms | Disabled | Disabled | Disabled | Disabled |
| Report Troubles | Disabled | Disabled | Disabled | Disabled |
| Report Open/Close | Disabled | Disabled | Disabled | Disabled |
| Report Tests | Disabled | Disabled | Disabled | Disabled |
| Report Selection | | | | |
| Arm Away | Enabled | Enabled | Enabled | Enabled |
| Arm Stay | Enabled | Enabled | Enabled | Enabled |
| Disarm | Enabled | Enabled | Enabled | Enabled |
| Exit Error | Enabled | Disabled | Enabled | Enabled |
| Recent Closing | Enabled | Enabled | Enabled | Enabled |
| Event Log Full | Enabled | Enabled | Enabled | Enabled |
| Trouble | Enabled | Enabled | Enabled | Enabled |
| Trouble Restore | Enabled | Enabled | Enabled | Enabled |
| Alarm Restore | Enabled | Enabled | Enabled | Enabled |
| Alarm Cancel | Enabled | Enabled | Enabled | Enabled |
| Test | Enabled | Enabled | Enabled | Enabled |
| Test Restore | Enabled | Enabled | Disabled | Enabled |
| Bypass | Enabled | Enabled | Enabled | Enabled |
| Bypass Restore | Enabled | Enabled | Enabled | Enabled |
| AC Loss | Enabled | Enabled | Enabled | Enabled |
| AC Loss Restore | Enabled | Enabled | Enabled | Enabled |
| Low Battery | Enabled | Enabled | Enabled | Enabled |
| Low Battery Restore | Enabled | Enabled | Enabled | Enabled |
| RF Low Battery | Enabled | Enabled | Enabled | Enabled |
| RF Low Battery Restore | Enabled | Enabled | Enabled | Enabled |
| Options | | | | |
| PBX | Blank | Blank | Blank | Blank |
| Call Wait Cancel | Blank | Blank | Blank | Blank |
| Number of Reports | Unlimited | Unlimited | Unlimited | Unlimited |
| Alarm Report Delay | No Delay | 15 Seconds | No Delay | No Delay |
| First Report Offset | 6 Hrs | 12 Hrs | 12 Hrs | 12 Hrs |
| Report Frequency | Never | 30 Days | Never | Never |

LYNX Touch (L5100CN) Canada Programming Default Values

| Program Function | Configuration 1 | Configuration 2 | Configuration 3 | Configuration 4 |
|--------------------------|------------------------|------------------------|------------------------|------------------------|
| Downloader | | | | |
| Phone Answer | Yes | Yes | Yes | Yes |
| Ans. Machine Defeat | Yes | Yes | Yes | Yes |
| Modem Speed (Future Use) | Slow | Slow | Slow | Slow |
| Ring Counter | 2 | 2 | 2 | 2 |
| Callback Number | Blank | Blank | Blank | Blank |
| Flexible Callback Number | No | No | No | No |
| Number | 1 | 1 | 1 | 1 |
| Sounder | | | | |
| Burglary Alarm Sound | Yes | Yes | Yes | Yes |
| Burglary Bell Timeout | 4 Minutes | 4 Minutes | 4 Minutes | 4 Minutes |
| Fire Bell Timeout | 4 Minutes | 4 Minutes | 4 Minutes | 4 Minutes |
| Arm Confirm | None | None | None | None |
| Alarm Options | Unlimited | 2 | 2 | 2 |
| System Settings | | | | |
| Entry Delay 1 | 30 Seconds | 45 Seconds | 30 Seconds | 30 Seconds |
| Entry Delay 2 | 60 Seconds | 60 Seconds | 60 Seconds | 60 Seconds |
| Exit Delay | 60 Seconds | 60 Seconds | 60 Seconds | 60 Seconds |
| Backlight Timeout | No | No | No | No |
| Quick Arm | Yes | Yes | Yes | Yes |
| Quick Exit | Yes | Yes | Yes | Yes |
| Restart Exit Time | No | Yes | Yes | Yes |
| Force Bypass | No | No | No | No |
| Exit Warning | No | Yes | Yes | Yes |
| Auto Stay Arming | No | Yes | Yes | Yes |
| Lack Of Usage Notify | Disabled | Disabled | Disabled | Disabled |
| Power-Up In Previous | Yes | Yes | Yes | Yes |
| Display Alarm Cancel | No | Yes | Yes | Yes |
| Display Exit Time | Yes | Yes | Yes | Yes |
| Cross Zone Delay | 3 Minutes | None | None | None |
| Cross Zone 1 | Disabled | Disabled | Disabled | Disabled |
| Cross Zone 2 | Disabled | Disabled | Disabled | Disabled |
| Z-Wave | | | | |
| Z-Wave | Enabled-Installed | Enabled-Installed | Enabled-Installed | Enabled-Installed |
| Temperature | Fahrenheit | Fahrenheit | Fahrenheit | Fahrenheit |

Zone Programming Default Values

Zone Assignment/Alarm Response Types for Configuration 1

| Zone Number | Loop Number | Device Type | Response Type | Report | Chime | Supervision/ Input Type | Zone Descriptor |
|-------------|-------------|---------------|----------------------|--------|-------|-------------------------|-----------------|
| 1 | --- | New | n/a | Yes | No | EOLR | n/a |
| 2 | 2 | Door | Entry Exit 1 | Yes | Yes | Supervised | Front |
| 3 | 2 | Door | Entry Exit 1 | Yes | Yes | Supervised | Back |
| 4 | 2 | Window | Perimeter | Yes | Yes | Supervised | n/a |
| 5 | 1 | Motion Sensor | Interior w/Delay | Yes | No | Supervised | n/a |
| 46 | 1 | New | Not Used | No | Yes | Supervised | Main |
| 47 | 1 | New | Not Used | No | Yes | Supervised | Main |
| 48 | 1 | New | Not Used | No | Yes | Supervised | Main |
| 49 | 3 | 4 Button Key | Arm Away | Yes | No | Button | n/a |
| 50 | 2 | 4 Button Key | Disarm | Yes | No | Button | n/a |
| 51 | 4 | 4 Button Key | Arm Stay | Yes | No | Button | n/a |
| 52 | 1 | 4 Button Key | No Response | no | No | Button | n/a |
| 53 | 3 | 4 Button Key | Arm Away | Yes | No | Button | n/a |
| 54 | 2 | 4 Button Key | Disarm | Yes | No | Button | n/a |
| 55 | 4 | 4 Button Key | Arm Stay | Yes | No | Button | n/a |
| 56 | 1 | 4 Button Key | No Response | no | No | Button | n/a |
| 80 | n/a | Temperature | Not Used | Yes | No | High Temp | n/a |
| 81 | n/a | Temperature | Not Used | Yes | No | Low Temp | n/a |
| 82 | n/a | Temperature | Not Used | Yes | No | High Temp | n/a |
| 83 | n/a | Temperature | Not Used | Yes | No | Low Temp | n/a |
| 84 | n/a | Temperature | Not Used | Yes | No | High Temp | n/a |
| 85 | n/a | Temperature | Not Used | Yes | No | Low Temp | n/a |
| 95 | --- | Fire | Fire No Verification | Yes | No | Panic Trigger | n/a |
| 96 | --- | Medical | n/a | Yes | No | Panic Trigger | n/a |
| 97 | --- | --- | --- | Yes | No | Cover Tamper | n/a |
| 99 | --- | Police | 24-Hour Silent | Yes | No | Panic Trigger | n/a |

NOTE: Zone 1 is a hardwire zone; Zone 2 to 48 are RF zones (Zones 46 to 48 are reserved for Garage Door Zones); Zone 92 is Duress; Zone 99 is keypad panic

Zone Assignment/Alarm Response Types for Configuration 2

| Zone Number | Loop Number | Device Type | Response Type | Report | Chime | Supervision/ Input Type | Zone Descriptor |
|-------------|-------------|----------------|----------------------|--------|-------|-------------------------|-----------------|
| 1 | --- | New | n/a | Yes | No | EOLR | n/a |
| 2 | 2 | Door | Entry Exit 1 | Yes | Yes | Supervised | Front |
| 3 | 2 | Door | Entry Exit 1 | Yes | Yes | Supervised | Back |
| 4 | 2 | Door | Entry Exit 1 | Yes | Yes | Supervised | Garage |
| 5 | 1 | Motion Sensor | Interior w/Delay | Yes | No | Supervised | n/a |
| 6 | 1 | Smoke Detector | Fire No verification | Yes | No | Supervised | n/a |
| 46 | 1 | New | Not Used | No | Yes | Supervised | Main |
| 47 | 1 | New | Not Used | No | Yes | Supervised | Main |
| 48 | 1 | New | Not Used | No | Yes | Supervised | Main |
| 49 | 3 | 4 Button Key | Arm Away | Yes | No | Button | n/a |
| 50 | 2 | 4 Button Key | Disarm | Yes | No | Button | n/a |
| 51 | 4 | 4 Button Key | Arm Stay | Yes | No | Button | n/a |
| 52 | 1 | 4 Button Key | No Response | No | No | Button | n/a |
| 53 | 3 | 4 Button Key | Arm Away | Yes | No | Button | n/a |
| 54 | 2 | 4 Button Key | Disarm | Yes | No | Button | n/a |
| 55 | 4 | 4 Button Key | Arm Stay | Yes | No | Button | n/a |
| 56 | 1 | 4 Button Key | No Response | No | No | Button | n/a |
| 80 | n/a | Temperature | Not Used | Yes | No | High Temp | n/a |
| 81 | n/a | Temperature | Not Used | Yes | No | Low Temp | n/a |
| 82 | n/a | Temperature | Not Used | Yes | No | High Temp | n/a |
| 83 | n/a | Temperature | Not Used | Yes | No | Low Temp | n/a |
| 84 | n/a | Temperature | Not Used | Yes | No | High Temp | n/a |
| 85 | n/a | Temperature | Not Used | Yes | No | Low Temp | n/a |
| 95 | --- | Fire | Fire No Verification | Yes | No | Panic Trigger | n/a |
| 96 | --- | Medical | 24-Hour Auxiliary | Yes | No | Panic Trigger | n/a |
| 97 | --- | --- | --- | Yes | No | Cover Tamper | n/a |
| 99 | --- | Police | 24-Hour Audible | Yes | No | Panic Trigger | n/a |

NOTE: Zone 1 is a hardwire zone; Zone 2 to 48 are RF zones (Zones 46 to 48 are reserved for Garage Door Zones); Zone 92 is Duress; Zone 99 is keypad panic

Zone Programming Default Values

Zone Assignment/Alarm Response Types for Values 3 and 4

| Zone Number | Loop Number | Device Type | Response Type | Report | Chime | Supervision/ Input Type | Zone Descriptor |
|-------------|-------------|----------------|----------------------|--------|-------|-------------------------|-----------------|
| 1 | --- | New | n/a | Yes | No | EOLR | n/a |
| 2 | 2 | Door | Entry Exit 1 | Yes | Yes | Supervised | Front |
| 3 | 2 | Door | Entry Exit 1 | Yes | Yes | Supervised | Back |
| 4 | 2 | Window | Perimeter | Yes | No | Supervised | n/a |
| 5 | 2 | Window | Perimeter | Yes | No | Supervised | n/a |
| 6 | 2 | Window | Perimeter | Yes | No | Supervised | n/a |
| 7 | 2 | Window | Perimeter | Yes | No | Supervised | n/a |
| 8 | 1 | Motion Sensor | Interior w/Delay | Yes | No | Supervised | n/a |
| 9 | 1 | Smoke Detector | Fire No Verification | Yes | No | Supervised | n/a |
| 46 | 1 | New | Not Used | No | Yes | Supervised | Main |
| 47 | 1 | New | Not Used | No | Yes | Supervised | Main |
| 48 | 1 | New | Not Used | No | Yes | Supervised | Main |
| 49 | 3 | 4 Button Key | Arm Away | Yes | No | Button | n/a |
| 50 | 2 | 4 Button Key | Disarm | Yes | No | Button | n/a |
| 51 | 4 | 4 Button Key | No Response | Yes | No | Button | n/a |
| 52 | 1 | 4 Button Key | No Response | No | No | Button | n/a |
| 53 | 3 | 4 Button Key | Arm Away | Yes | No | Button | n/a |
| 54 | 2 | 4 Button Key | Disarm | Yes | No | Button | n/a |
| 55 | 4 | 4 Button Key | No Response | Yes | No | Button | n/a |
| 56 | 1 | 4 Button Key | No Response | No | No | Button | n/a |
| 80 | n/a | Temperature | Not Used | Yes | No | High Temp | n/a |
| 81 | n/a | Temperature | Not Used | Yes | No | Low Temp | n/a |
| 82 | n/a | Temperature | Not Used | Yes | No | High Temp | n/a |
| 83 | n/a | Temperature | Not Used | Yes | No | Low Temp | n/a |
| 84 | n/a | Temperature | Not Used | Yes | No | High Temp | n/a |
| 85 | n/a | Temperature | Not Used | Yes | No | Low Temp | n/a |
| 95 | --- | Fire | Fire No Verification | Yes | No | Panic Trigger | n/a |
| 96 | --- | Medical | n/a | Yes | No | Panic Trigger | n/a |
| 97 | --- | --- | --- | Yes | No | Cover Tamper | n/a |
| 99 | --- | Police | 24-Hour Silent | Yes | No | Panic Trigger | n/a |

NOTE: Zone 1 is a hardwire zone; Zone 2 to 48 are RF zones (Zones 46 to 48 are reserved for Garage Door Zones); Zone 92 is Duress; Zone 99 is keypad panic

Zone Response Type Matrix

| Device Type | Response Type | | | | | | | | | | | | | | | | | | | | | | | | | |
|--------------------------|---------------|--------------|-----------|------------------|-------------------|-----------------|------------------|-----------|-------------------|---------------------|----------------------|------------------------|-----------------|-------------------|-----------------|----------------|---------|----------|----------|----------|--------|-------------|-----------------|--------|----------------|---------|
| | Entry Exit 1 | Entry Exit 2 | Perimeter | Resident Monitor | Resident Response | General Monitor | General Response | Day/Night | Interior Follower | Interior With Delay | Fire No Verification | Fire With Verification | Carbon Monoxide | 24 Hour Auxiliary | 24 Hour Audible | 24 Hour Silent | Monitor | Not Used | Arm Stay | Arm Away | Disarm | No Response | Silent Burglary | Garage | Garage Monitor | Trouble |
| Door | x | x | x | x | x | x | x | | | | | | | | | | | | | | | | | | | |
| Window | x | x | x | x | x | x | x | | | | | | | | | | | | | | | | | | | |
| Motion Sensor | | | x | x | x | x | x | x | x | x | | | | | | | | | | | | | | | | |
| Glass Break | | | x | x | x | x | x | | | | | | | | | | | | | | | | | | | |
| Smoke Detector | | | | | | | | | | | x | x | | | | | | | | | | | | | | |
| Heat Sensor | | | | | | | | | | | x | | | | | | | | | | | | | | | |
| Carbon Monoxide Detector | | | | | | | | | | | | | x | | | | | | | | | | | | | |
| Temperature | | | | x | x | x | x | | | | | | | x | | | x | | | | | | | | | |
| Flood | | | | | | | | | | | | | | x | | | x | | | | | | | | | |
| Environmental | | | | x | x | x | x | | | | | | | x | | | x | | | | | | | | | |
| Medical | | | | | | | | | | | | | | x | x | | | x | | | | | | | | |
| Fire | | | | | | | | | | | x | | | | | | | x | | | | | | | | |
| Police | | | | | | | | | | | | | | x | x | x | | x | | | | | | | | |
| Garage Door | | | | | | | | | | | | | | | | | | | | | | | | x | x | |
| Other | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x |

Regulatory Agency Statements

Federal Communications Commission (FCC) Part 15

The user shall not make any changes or modifications to the equipment unless authorized by the Installation Instructions or User's Manual. Unauthorized changes or modifications could void the user's authority to operate the equipment.

CLASS B DIGITAL DEVICE STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

FCC IC Statement

This device complies with Part 15 of FCC Rules and RSS 210 of Industry Canada. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Cet appareil est conforme à la partie 15 des règles de la FCC & de RSS 210 des Industries Canada. Son fonctionnement est soumis aux conditions suivantes: (1) Cet appareil ne doit pas causer d'interférences nuisibles. (2) Cet appareil doit accepter toute interférence reçue y compris les interférences causant une réception indésirable.

TELEPHONE/MODEM INTERFACE

Federal Communications Commission (FCC) Part 68

This equipment complies with Part 68 of the FCC rules. On the front cover of this equipment is a label that contains the FCC registration number and Ringer Equivalence Number (REN). You must provide this information to the telephone company when requested.

This equipment uses the following USOC jack: RJ31X

This equipment may not be used on telephone-company-provided coin service. Connection to party lines is subject to state tariffs. This equipment is hearing-aid compatible.

Industry Canada

NOTICE: The Industry Canada Label identifies certified equipment. This certification means that the equipment meets telecommunications network protective, operational and safety requirements as prescribed in the appropriate Terminal Equipment Technical Requirements document(s). The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be coordinated by a representative designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves but should contact appropriate electric inspection authority, or electrician, as appropriate.

AVIS: L'étiquette d'Industrie Canada identifie le matériel homologué. Cette étiquette certifie que le matériel est conforme aux normes de protection, d'exploitation et de sécurité des réseaux de télécommunications, comme le prescrivent les documents concernant les exigences techniques relatives au matériel terminal. Le Ministère n'assure toutefois pas que le matériel fonctionnera à la satisfaction de l'utilisateur.

Avant d'installer ce matériel, l'utilisateur doit s'assurer qu'il est permis de le raccorder aux installations de l'entreprise locale de télécommunication. Le matériel doit également être installé en suivant une méthode acceptée de raccordement. L'abonné ne doit pas oublier qu'il est possible que la conformité aux conditions énoncées ci-dessus n'empêche pas la dégradation du service dans certaines situations.

Les réparations de matériel homologué doivent être coordonnées par un représentant désigné par le fournisseur. L'entreprise de télécommunications peut demander à l'utilisateur de débrancher un appareil à la suite de réparations ou de modifications effectuées par l'utilisateur ou à cause de mauvais fonctionnement.

Pour sa propre protection, l'utilisateur doit s'assurer que tous les fils de mise à la terre de la source d'énergie électrique, de lignes téléphoniques et des canalisations d'eau métalliques, s'il y en a, sont raccordés ensemble. Cette précaution est particulièrement importante dans les régions rurales.

Avertissement : L'utilisateur ne doit pas tenter de faire ces raccordements lui-même; il doit avoir recours à un service d'inspection des installations électriques, ou à un électricien, selon le cas.

Ringer Equivalence Number Notice:

The **Ringer Equivalence Number (REN)** assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed 5.

AVIS : L'indice d'équivalence de la sonnerie (IES) assigné à chaque dispositif terminal indique le nombre maximal de terminaux qui peuvent être raccordés à une interface. La terminaison d'une interface téléphonique peut consister en une combinaison de quelques dispositifs, à la seule condition que la somme d'indices d'équivalence de la sonnerie de tous les dispositifs n'exécède pas 5.

RF Exposure



WARNING: The LYNX Touch must be installed to provide a separation distance of at least 7.8 in (20 cm) from all persons and not co-located or operated in conjunction with any other transmitter except in accordance with FCC multi-transmitter product procedures.

WARNING
THE LIMITATIONS OF THIS ALARM SYSTEM

While this System is an advanced design security system, it does not offer guaranteed protection against burglary, fire or other emergency. Any alarm system, whether commercial or residential, is subject to compromise or failure to warn for a variety of reasons. For example:

- Intruders may gain access through unprotected openings or have the technical sophistication to bypass an alarm sensor or disconnect an alarm warning device.
- Intrusion detectors (e.g., passive infrared detectors), smoke detectors, and many other sensing devices will not work without power. Battery-operated devices will not work without batteries, with dead batteries, or if the batteries are not put in properly. Devices powered solely by AC will not work if their AC power supply is cut off for any reason, however briefly.
- Signals sent by wireless transmitters may be blocked or reflected by metal before they reach the alarm receiver. Even if the signal path has been recently checked during a weekly test, blockage can occur if a metal object is moved into the path.
- A user may not be able to reach a panic or emergency button quickly enough.
- While smoke detectors have played a key role in reducing residential fire deaths in the United States, they may not activate or provide early warning for a variety of reasons in as many as 35% of all fires, according to data published by the Federal Emergency Management Agency. Some of the reasons smoke detectors used in conjunction with this System may not work are as follows. Smoke detectors may have been improperly installed and positioned. Smoke detectors may not sense fires that start where smoke cannot reach the detectors, such as in chimneys, in walls, or roofs, or on the other side of closed doors. Smoke detectors also may not sense a fire on another level of a residence or building. A second floor detector, for example, may not sense a first floor or basement fire. Finally, smoke detectors have sensing limitations. No smoke detector can sense every kind of fire every time. In general, detectors may not always warn about fires caused by carelessness and safety hazards like smoking in bed, violent explosions, escaping gas, improper storage of flammable materials, overloaded electrical circuits, children playing with matches, or arson. Depending on the nature of the fire and/or location of the smoke detectors, the detector, even if it operates as anticipated, may not provide sufficient warning to allow all occupants to escape in time to prevent injury or death.
- Passive Infrared Motion Detectors can only detect intrusion within the designed ranges as diagrammed in their installation manual. Passive Infrared Detectors do not provide volumetric area protection. They do create multiple beams of protection, and intrusion can only be detected in unobstructed areas covered by those beams. They cannot detect motion or intrusion that takes place behind walls, ceilings, floors, closed doors, glass partitions, glass doors, or windows. Mechanical tampering, masking, painting or spraying of any material on the mirrors, windows or any part of the optical system can reduce their detection ability. Passive Infrared Detectors sense changes in temperature; however, as the ambient temperature of the protected area approaches the temperature range of 90° to 105°F (32° to 40°C), the detection performance can decrease.
- Alarm warning devices such as sirens, bells or horns may not alert people or wake up sleepers if they are located on the other side of closed or partly open doors. If warning devices are located on a different level of the residence from the bedrooms, then they are less likely to waken or alert people inside the bedrooms. Even persons who are awake may not hear the warning if the alarm is muffled by noise from a stereo, radio, air conditioner or other appliance, or by passing traffic. Finally, alarm warning devices, however loud, may not warn hearing-impaired people.
- Telephone lines needed to transmit alarm signals from a premises to a central monitoring station may be out of service or temporarily out of service. Telephone lines are also subject to compromise by sophisticated intruders.
- Even if the system responds to the emergency as intended, however, occupants may have insufficient time to protect themselves from the emergency situation. In the case of a monitored alarm system, authorities may not respond appropriately.
- This equipment, like other electrical devices, is subject to component failure. Even though this equipment is designed to last as long as 10 years, the electronic components could fail at any time.

The most common cause of an alarm system not functioning when an intrusion or fire occurs is inadequate maintenance. This alarm system should be tested weekly to make sure all sensors and transmitters are working properly. The security keypad (and remote keypad) should be tested as well.

Wireless transmitters (used in some systems) are designed to provide long battery life under normal operating conditions. Longevity of batteries may be as much as 4 to 7 years, depending on the environment, usage, and the specific wireless device being used. External factors such as humidity, high or low temperatures, as well as large swings in temperature, may all reduce the actual battery life in a given installation. This wireless system, however, can identify a true low battery situation, thus allowing time to arrange a change of battery to maintain protection for that given point within the system.

Installing an alarm system may make the owner eligible for a lower insurance rate, but an alarm system is not a substitute for insurance. Homeowners, property owners and renters should continue to act prudently in protecting themselves and continue to insure their lives and property.

We continue to develop new and improved protection devices. Users of alarm systems owe it to themselves and their loved ones to learn about these developments.

UL Notices

1. For UL Residential Burglar Alarm installations with line security, total exit delay time must not exceed 60 seconds. For UL Burglar Alarm installations without line security, total exit delay time must not exceed 120 seconds.
2. Periodic testing must be at least every 24 hours.
3. Remote downloading without an alarm company technician on-site (unattended downloading) is not permissible for UL installations.
4. Auto-disarming is not a UL Listed feature.
5. As SIA limits for delay of alarm reporting and sounding can exceed UL limits for commercial and residential applications, the following UL requirements per UL681 are provided:
The maximum time that a control unit shall be programmed to delay the transmission of a signal to a remote monitoring location, or to delay the energizing of a local alarm sounding device to permit the alarm system user to enter and disarm the system, or to arm the system and exit shall not exceed:
 - a) 60 seconds for a system with standard line security or encrypted line security,
 - b) 120 seconds for a system without standard line security or encrypted line security, or
 - c) 120 seconds for a system that does not transmit an alarm signal to a remote monitoring location.

SIA Quick Reference Guide

| Programming Section | Feature | Range | Shipping Default | SIA Requirement |
|--|--------------------|--|--|----------------------------------|
| Installation and Setup Guide or Programming Guide | | | | |
| Reporter/ Report Selection | Exit Error | Enabled or Disabled | Enabled | Enabled |
| | Recent Closing | Enabled or Disabled | Enabled | Enabled |
| | Alarm Cancel | Enabled or Disabled | Enabled | Enabled |
| Reporter/Options | Call Wait Cancel | Enabled or Disabled | Field is blank (a PBX prefix is entered to enable) | Enabled if User has call waiting |
| | Number of Reports | 1 to 6 Reports | 2 Reports | 2 Reports |
| | Alarm Report Delay | 15, 30 and 45 seconds | 30 Seconds | 30 Seconds* |
| System Settings | Entry Delay # 1 | 30, 45, 60 and 90 seconds and 2, 3 or 4 minutes | 30 Seconds | 30 Seconds minimum |
| | Entry Delay # 2 | 30, 45, 60 and 90 seconds and 2, 3 or 4 minutes | 30 Seconds | 30 Seconds minimum |
| | Exit Delay | 45, 60, 90 seconds and 2 minutes | 60 Seconds | 45 seconds minimum |
| | Restart Exit Time | Enabled or Disabled | Yes (Enabled) | Enabled |
| | Exit Warning | Not selectable | Always enabled | Enabled |
| | Auto Stay Arming | Enabled or Disabled | Yes (Enabled) | Enabled |
| | Cross Zone Delay | 30 seconds and 2 minutes (in 30 second increments), 3 minutes and 4 minutes | None (Disabled) | Enabled and two zones programmed |
| Zones | Fire Alarms | Zone Type "Fire with Verification" must be selected for Fire Zone 95 | Disabled | Disabled |
| User Guide | | | | |
| User Functions/ User Access | Duress | Duress Code is Programmed by Master User as User 16 | Disabled | Disabled |
| System Functions/ Testing the System** | System Test | System tests provided as a User Function | n/a | n/a |
| | Communications | While the system is in Test mode, no alarm reports are sent to the central station | Disabled | Disabled |

* Combined Entry Delay and Abort Window should not exceed 1 minute.

** Refer to the User Guide for procedures on Testing the System.

Note: Using the Call Waiting Cancel feature on a non-Call Waiting line will prevent successful communication to the central station.

Specifications

LYNX Touch Series Security Controls

Physical:

Dimensions: 8.5" W x 6" H x 1.875" D

Electrical:

Voltage Input: 9 Vdc from plug-in 2.7A power supply

Rechargeable Backup Battery: Nickel-metal hydride battery pack rated at 7.2 Vdc

Communication:

Formats Supported: ADEMCO Contact ID® Reporting, 10 characters/sec., DTMF (TouchTone) Data Tones, 1400/2300Hz Handshake, 1400Hz KISSOFF.

SIA/DCS Format, 2225Hz Handshake, Data Tones, 2025/2235Hz, baud

Line Seize: Double Pole

Ringer Equivalence: 0.5B

ACTA Registration No.: US: AC3AL05BL5000

Hardwire Zone:

2K ohms, End of Line Resistor (EOLR), 200 ohms max wire resistance, dry contacts only

Trigger Output:

1k ohms to ground when closed (output low) 3ma

Contacting Technical Support

PLEASE, before you call Technical Support, be sure you:

- READ THE INSTRUCTIONS!
- Check all wiring connections.
- Determine that the power supply and/or backup battery are supplying proper voltages.
- Verify your programming information where applicable.
- Note the proper model number of this product, and the version level (if known) along with any documentation that came with the product.
- Note your Honeywell customer number and/or company name.

Having this information handy will make it easier for us to serve you quickly and effectively.

| |
|---|
| <i>Technical Support:</i>1-800-645-7492 (8 a.m.-10 p.m. E.S.T.) |
| <i>MyWebTech:</i> http://www.honeywell.com/security/hsc/resources/MyWebTech |

Glossary

AES – Advanced Encryption Standard

APL – Advanced Protection Logic

dBm – decibals milliwatt (power ratio)

DHCP – Dynamic Host Configuration Protocol, which provides a mechanism for allocating IP addresses dynamically so that addresses can be reused when hosts no longer need them.

DNS – Domain Name System, which is a distributed hierarchical naming system used to resolve domain names (e.g., www.yahoo.com) into numerical IP addresses (e.g., 204.17.25.1).

Gateway IP Address – A gateway (sometimes called a router) is a computer and/or software used to connect two or more networks (including incompatible networks) and translates information from one network to the other. The Gateway IP address is the IP address for the gateway.

GPRS – General Packet Radio Service

GSM – Global System for Mobile communications, which is an international standard for digital mobile phone systems used for cellular communication.

IMEI – International Mobile Equipment Identity number

IP – Internet Protocol

IP Address – A unique number consisting of four parts separated by periods, sometimes called a "dotted quad.," for example: 204.17.29.11, assigned to every computer/workstation connected to the Internet. IP numbers can be "static" (assigned and unchanging) or "dynamic," assigned via DHCP at each and every startup.

ISP – Internet Service Provider

MAC ID – Media Access Code; located on the module label.

NIC – Network Interface Card

RSSI – Received Signal Strength Indication

SCID – SIM Card ID

Subnet Mask – A Subnet is a portion of a network that shares a network address with other portions of the network, and is distinguished by a subnet number. The Subnet Mask is a 32-bit address mask used in IP to indicate the bits of an IP address that are being used for the subnet address.

WEP – Wired Equivalent Privacy

WPA – WiFi Protected Access

WPS – WiFi Protected Setup

– Index –

24-Hour Silent 52
 300-03864-1 5
 300-03866..... 5
 300-04063..... 5, 9
 300-04065..... 5, 9
 300-04705..... 5, 9
 5800 Series Transmitter Loop Numbers 15
 5800 Series Transmitters..... 5, 13
 5802MN 13
 5802MN2..... 13
 5804..... 13
 5804BD 13
 5804BDV..... 13
 5804E 13
 5805-6..... 13
 5806..... 15
 5816..... 13
 5817..... 13

A

AC Power 9
 AC Power Loss..... 9
 ADEMCO Contact ID 5, 72
 Armed System Test 59
 Audio Alarm Verification
 (Two-Way Voice Feature)..... 57
 Auto Stay Arming..... 40

B

Babysitter Code 53
 Backup Battery..... 9, 72
 Button Transmitters 13

C

Case Tamper 5
 Change Installer Code..... 22
 Communication Modules..... 10
 Communications ID Numbers 44
 Communications Status 43
 Installing/Configuring Communication & Home
 Automation Modules 10
 Contact ID Event Log Codes..... 58
 Contact ID Reporting 72
 Contacting Technical Support 73
 Cross Zone 1/Cross Zone 2 40
 Cross Zone Delay 40, 41, 42

D

Dashboard Screen 16
 Data Encryption 50
 Desktop Mounting..... 6
 Diagnostics..... 44
 Diagnostics..... 43
 Dialer Delay..... 59
 Dialer Test 59
 Dip Switches 13
 Disarm 16
 Display Alarm Cancel 40
 Display Exit Time..... 40
 Duress Code..... 53

E

Enroll The WiFi Module 47
 Enter Installer Programming Mode..... 18
 Enter/Change The Master Code 52
 Entry Delay1/Entry Delay 2 40
 Entry/Exit Burglary 20
 Ethernet Information 43
 Exit Delay 5, 17, 20, 40, 59, 70
 Exit Door..... 40
 Exit Warning..... 40
 Exiting Program Mode 19

F

Factory Defaults 49
 Features 5
 Flexible Callback..... 50
 Follow Me Reminder Feature 55
 Follow Me System Announcement 54
 Force Bypass..... 40

G

Garage..... 21
 Garage Monitor 21
 General Programming Information..... 18
 Go/No Go Test..... 14
 GSM Information 43
 GSMVLP5-4G/GSMVLP5CN4G GSM Communication
 Module 10, 25

H

Home Screen..... 16
 House Identification 13

I

ILP-5 25
 ILP5 Ethernet Communications Module 10, 11
 Installer Code 52
 Installer Menu..... 17
 Installing Wireless Zones..... 14, 15
 Installing/Configuring Communication & Home
 Automation Modules 11, 12

K

Key/Touchscreen Operation..... 52
 Keys 13

L

L5000DM 6
 L5100-WiFi Module..... 12
 L5100-ZWAVE Home automation Module..... 12
 Lack of Usage Notify..... 40
 Liquid Crystal Display (LCD) Touch-Screen 16
 Loading Factory Defaults 18
 LYNX Touch (L5100CN) Canada Programming Default
 Values 65
 LYNX Touch Programming Default Values..... 62
 LYNXRCHKIT-SC 5
 LYNXRCHKIT-SHA..... 5

LYNX Touch Installation and Setup Guide

| M | |
|---|--------|
| Master Code | 52 |
| Master Security Code | 53 |
| Master User Security Code | 52 |
| Memory of Alarm | 52 |
| Menu Screens..... | 17 |
| Mounting Base..... | 6 |
| N | |
| Navigating Menus | 16 |
| Navigation Keys..... | 16 |
| News..... | 21 |
| O | |
| Operator Commands | 57 |
| P | |
| Panic Key/Icons..... | 52 |
| Plug-in Power Supply | 9 |
| Power-up in Previous..... | 40 |
| Program Date and Time..... | 25 |
| Program Keys | 31 |
| Program the Communications Module..... | 26 |
| Program the Z-Wave Module | 28 |
| Program Zones | 29 |
| Q | |
| Quick Arm..... | 40 |
| Quick Exit | 40 |
| R | |
| Range..... | 13 |
| Reboot..... | 60 |
| Rebooting the System | 60 |
| Register by Phone | 45 |
| Register Device with Pin | 46 |
| Register through Alarmnet Direct Website..... | 45 |
| Register through LYNX Touch Diagnostics | 45 |
| Registering The LYNX Touch | 44 |
| Regulatory Agency Statements..... | 68 |
| Remote Phone Control..... | 55 |
| Remote Programming..... | 50 |
| Remote Programming/Control | 50 |
| Reporter | 33, 34 |
| Reset Master User Code..... | 53 |
| Resident Monitor Zone Types..... | 5 |
| RF Sniffer Test Mode..... | 14 |

| S | |
|---|-----------|
| Secondary User Codes | 53 |
| Security Code..... | 40 |
| Security Code Handshake..... | 50 |
| Security Codes | 52 |
| Setup Communication | 44 |
| SIA (DC-03)..... | 5 |
| SIA Event Log Codes..... | 58 |
| Silent Burglary | 21 |
| Site-Initiated Remote Programming | 50 |
| Sniffer Mode..... | 59 |
| Sounder | 39 |
| Specifications | 72 |
| Station-Initiated Remote Programming..... | 50 |
| Super High Capacity Battery..... | 10 |
| Supervised RF..... | 13 |
| System Features | 5 |
| System Operation | 52, 53 |
| System Settings | 40 |
| T | |
| Technical Support..... | 73 |
| Test Communications..... | 44 |
| Test Ethernet..... | 44 |
| Test Modes | 59 |
| Testing the System..... | 59, 60 |
| Touch-Screen Display..... | 16 |
| Traffic..... | 21 |
| Transmitter Battery Life..... | 13 |
| Transmitter Input Type | 13 |
| Transmitter Loop Numbers | 15 |
| Transmitter Supervision | 13 |
| U | |
| Unsupervised Button | 13 |
| Unsupervised RF | 13 |
| Update Server..... | 47 |
| User Menu | 17 |
| W | |
| Wall Mounting..... | 6 |
| Weather..... | 21 |
| Wireless Buttons | 13 |
| Wireless Keypads | 5, 13, 14 |
| Wireless Zones | 13 |
| Wiring Connections | 6 |
| World Wide Web Address..... | 73 |
| Z | |
| Zone Discovery..... | 60 |
| Zone Programming Default Values | 66, 67 |
| Zone Response Type Definitions | 20 |

Notes: Connection of the fire alarm signal to a fire alarm headquarters or a central station shall be permitted with the approval of the local authority having jurisdiction. The burglar alarm signal shall not be connected to a police emergency number. The System must be checked by a qualified technician once every three years

THIS EQUIPMENT SHOULD BE INSTALLED IN ACCORDANCE WITH THE NATIONAL FIRE PROTECTION ASSOCIATION STANDARDS ANSI/NFPA 70 NATIONAL ELECTRIC CODE AND NFPA 72 NATIONAL FIRE ALARM CODE CHAPTER 2 (NATIONAL FIRE PROTECTION ASSOC. BATTERY MARCH PARK, QUINCY, MA 02169), PRINTED INFORMATION DESCRIBING PROPER INSTALLATION, EVACUATION PLANNING AND REPAIR SERVICE IS TO BE PROVIDED WITH THIS EQUIPMENT.

LYNX TOUCH SERIES ALSO COMPLIES WITH THE FOLLOWING:
CANADIAN STANDARDS ASSOCIATION (CSA) C22.1
CANADIAN ELECTRICAL CODE, PART 1, SAFETY STANDARD FOR ELECTRICAL INSTALLATIONS AND CANULC-3540
INSTALLATION OF RESIDENTIAL FIRE WARNING SYSTEMS.


THIS DEVICE COMPLIES WITH PART 15 OF FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

WARNING
TO PREVENT RISK OF SHOCK, DISCONNECT TELEPHONE LINE AT TELECOM JACK BEFORE SERVICING THIS UNIT

UL INSTALLATIONS THE MINIMUM WIRE SIZE USED FOR TELEPHONE INSTALLATIONS MUST BE #26 GAGE

NOTE: THE HARDWIRE ZONE CANNOT BEUSED AS A FIRE ZONE.

*** IMPORTANT ***
Be sure to observe polarity when connecting the power supply to the terminal strip.



COMPLIES WITH FCC RULES, PART 68 FCC REGISTRATION No. AC3AL05BL5000 RINGER EQUIVALENCE: 0.5B

THE LYNX TOUCH CONTROLS ARE COMPATIBLE WITH THE FOLLOWING INTEGRAL RECHARGEABLE BATTERY PACKS:
P/N 300-03864-1/LYNXRCHKIT-SC
P/N 300-03866/LYNXRCHKIT-SHA
REPLACE EVERY FOUR YEARS

WEEKLY TESTING IS REQUIRED TO ENSURE PROPER OPERATION OF THIS SYSTEM

WARNING
THIS UNIT MAY BE PROGRAMMED TO INCLUDE AN ALARM VERIFICATION FEATURE THAT WILL RESULT IN A DELAY OF THE SYSTEM ALARM SIGNAL FROM THE INDICATED FIRE CIRCUITS. THE TOTAL DELAY (CONTROL UNIT PLUS SMOKE DETECTORS) SHALL NOT EXCEED 60 SECONDS. NO OTHER INITIATING DEVICES SHALL BE CONNECTED TO THESE CIRCUITS UNLESS APPROVED BY THE LOCAL AUTHORITY HAVING JURISDICTION.

| CIRCUIT (ZONE) | CONTROL UNIT DELAY-SEC | SMOKE DETECTOR MODEL | DELAY-SEC |
|----------------|------------------------|----------------------|------------|
| 02-48 ZT16 | 30 seconds | 5806W3 | 10 seconds |

LYNX TOUCH SERIES SUMMARY OF CONNECTIONS

WARRANTY INFORMATION

For the latest warranty information, please visit:

www.honeywell.com/security/hsc/resources/wa

Honeywell

2 Corporate Center Drive, Suite 100

P.O. Box 9040, Melville, NY 11747

Copyright © 2012 Honeywell International Inc.

www.honeywell.com/security



800-10614V1 12/12 Rev. A